

**Mid Ulster
Rotating Electrics Ltd**



Specialists in Starters, Alternators & Auto Electrical Parts

solenoids

solenoid shutdown-Kits

Externally switched



090095 Solenoid Shutdown Kit
 24 V, 1.1 a/ hold, 46 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Left, Hold rating 178N,
 Elect. connection Cable, Function Pull,
 Mount. type Flange/bracket,
 switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090096 Solenoid Shutdown Kit
 12 V, 1.1 a/ hold, 46 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Right, Hold rating 178N,
 Elect. connection Cable, Function Pull,
 Mount. type Flange/bracket,
 switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090099 Solenoid Shutdown Kit
 24 V, 0.5 a/ hold, 25 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Left, Hold rating 178N,
 Elect. connection Cable, Function Pull,
 Mount. type Flange/bracket,
 switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090100 Solenoid Shutdown Kit
 24 V, 0.5 a/ hold, 25 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Right, Hold rating 178N,
 Elect. connection Cable, Function Pull,
 Mount. type Flange/bracket,
 switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090103 Solenoid Shutdown Kit
 servicing: Nippondenso, Zexel
 12 V, 1.1 a/ hold, 55 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Left, Hold rating 178N,
 Elect. connection Cable, Function Pull,
 Mount. type Flange/bracket,
 switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090104 Solenoid Shutdown Kit
 servicing: Nippodenso, Zexel
 12 V, 1.1 a/ hold, 55 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Right, Hold rating 178N,
 Elect. connection Cable,
 Function Pull, switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090105 Solenoid Shutdown Kit
 servicing: Nippodenso, Zexel
 24 V, 0.63 a/ hold, 29 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Left, Hold rating 178N,
 Elect. connection Cable,
 Function Pull, switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090106 Solenoid Shutdown Kit
 servicing: Nippodenso, Zexel
 24 V, 0.63 a/ hold, 29 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Right, Hold rating 178N,
 Elect. connection Cable,
 Function Pull, switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090107 Solenoid Shutdown Kit
 12 V, 1.1 a/ hold, 55 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Left, Hold rating 178N,
 Elect. connection Multiplug,
 switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090108 Solenoid Shutdown Kit
 24 V, 0.63 a/ hold, 29 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Left, Hold rating 178N,
 Elect. connection Multiplug,
 Function Pull, switch External
This solenoid can't switch off by itself, it will have to be controlled externally.

internally switched



090097 Solenoid Shutdown Kit
 12 V, 1.1 a/ hold, 46 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Left, Hold rating 178N,
 Elect. connection Connection, Function Pull,
 Mount. type Flange/bracket, switch Internal
This solenoid can switch off the pull coil, and no external 'control' is necessary.



090098 Solenoid Shutdown Kit
 12 V, 1.1 a/ hold, 46 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Right, Hold rating 178N,
 Elect. connection Connection,
 Function Pull, switch Internal
This solenoid can switch off the pull coil, and no external 'control' is necessary.



090101 Solenoid Shutdown Kit
 24 V, 0.5 a/ hold, 25 a/ pull,
 Pull rating 89N at 25.40 mm,
 Mount. side Left, Hold rating 178N,
 Elect. connection Connection,
 Function Pull, switch Internal
This solenoid can switch off the pull coil, and no external 'control' is necessary.



090102 Solenoid Shutdown Kit
 24 V, 0.5 a/ hold, 25 a/ pull,
 Pull rating 89N at 25.40 mm,
 Hold rating 178N,
 Elect. connection Connection,
 Function Pull, switch Internal
This solenoid can switch off the pull coil, and no external 'control' is necessary.

Contact Details

Sales Team

+44 (0)28 867 65354

Email: info@rotatingelectrics.co.uk

Unit A11-12,

Kilcronagh Business Park,

Cookstown,

Co. Tyrone,

BT80 9HJ

solenoid shutdown

Externally switched



090109 Shutdown Solenoid
12 V, 0.7 a/ hold, 30 a/ pull,
t hread size 6, t hread type mm,
Pull rating 40N at 25.40 mm,
r eturn spring 9N, Hold rating 89N,
Plunger External, Function Pull,
Elect. connection Connection,
Mount. type Flange/bracket,
switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090110 Shutdown Solenoid
24 V, 0.25 a/ hold, 17 a/ pull,
t hread size 6, t hread type mm,
Pull rating 40N at 25.40 mm,
r eturn spring 9N, Hold rating 89N,
Plunger External, Function Pull,
Elect. connection Connection,
Mount. type Flange/bracket,
switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090111 Shutdown Solenoid
12 V, 0.6 a/ hold, 44 a/ pull,
t hread size 1/4", t hread type Inches,
Pull rating 75N at 25.40 mm,
r eturn spring 35N, Hold rating 178N,
Plunger External, Function Pull,
Elect. connection Connection,
Mount. type Flange/bracket,
switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090113 Shutdown Solenoid
24 V, 0.3 a/ hold, 23 a/ pull,
t hread size 6, t hread type mm,
Pull rating 75N at 25.40 mm,
r eturn spring 35N, Hold rating 178N,
Plunger External, Function Pull,
Elect. connection Connection,
Mount. type Flange/bracket,
switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090199 Shutdown Solenoid
12 V, 1.1 a/ hold, 46 a/ pull,
t hread size 6, t hread type mm,
Pull rating 89N at 25.40 mm,
r eturn spring 17N, Hold rating 178N,
Plunger External, Function Pull/push,
Elect. connection Cable,
Mount. type Flat w/ 2 fixing holes,
switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090200 Shutdown Solenoid
24 V, 4 a/ hold, 18 a/ pull,
t hread size 6, t hread type mm,
Pull rating 67N at 25.40 mm,
r eturn spring 17N, Hold rating 178N,
Plunger External, Elect. connection Cable,
Function Pull/push, switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090206 Shutdown Solenoid
servicing: Yanmar Diesel
12 V, Plunger Internal, switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090216 Shutdown Solenoid
servicing: Kubota
12 V, 0.7 a/ hold, 30 a/ pull,
Pull rating 44N at 25.40 mm,
r eturn spring 17N, Hold rating 85N,
Plunger External,
Elect. connection Multiplug,
type Stop solenoid,
Mount. type Flange, switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090225 Shutdown Solenoid
servicing: Perkins
12 V, Plunger Internal, switch External
This solenoid can't switch off by itself, it will have to be controlled externally.



090226 Shutdown Solenoid
 24 V, 24 V 2, 0.5 a/ hold, 25 a/ pull,
 t hread size 6, t hread type mm,
 Pull rating 111N at 25.40 mm,
 r eturn spring 7N, Hold rating 182N,
 Plunger External,
 Elect. connection Multiplug,
 Function Pull, switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090228 Shutdown Solenoid
 servicing: Yanmar Motors
 12 V, Plunger Internal, switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090267 Shutdown Solenoid
 servicing: Volvo wheel loader
 24 V, 0.86 a/ hold, 39 a/ pull,
 Pull rating 129N at 25.4mm,
 Hold rating 182N, Plunger Cable,
 Elect. connection Multiplug,
 Function Pull, switch External
 Syncro start/Woodward.



090281 Shutdown Solenoid
 servicing: Volvo
 24 V, 0.5 a/ hold, 25 a/ pull,
 t hread size 6, t hread type mm,
 Pull rating 89N at 25.40 mm,
 Hold rating 236N, Plunger External,
 Elect. connection Multiplug,
 Function Pull/push,
 Mount. type Bracket, switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090348 Shutdown Solenoid
 12 V, 1.1 a/ hold, 46 a/ pull,
 t hread size 6, t hread type mm,
 Pull rating 111N at 25.40 mm,
 r eturn spring 4-8N, Hold rating 182N,
 Plunger External,
 Elect. connection Cable, Function Pull,
 Mount. type Flat w/ 2 fixing holes,
 switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090368 Shutdown Solenoid
 12 V, 12 V 2, 0.86 a/ hold, 61 a/ pull,
 Pull rating 129N at 25.4mm,
 Hold rating 182N, Plunger Cable,
 Elect. connection Multiplug,
 Function Pull, switch External
 Syncro start/Woodward.



090370 Shutdown Solenoid
 servicing: Kubota D722, Z482
 12 V, 1.1 a/ hold, 46 a/ pull,
 Plunger External, Elect. connection Cable,
 Mount. type Flat w/ 2 fixing holes,
 switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090371 Shutdown Solenoid
 servicing: Kubota D722, Z482
 24 V, 0.5 a/ hold, 25 a/ pull,
 Plunger External,
 Elect. connection Cable, switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090373 Shutdown Solenoid
 12 V, Plunger External, switch External
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*



090431 Shutdown Solenoid
 24 V, 24 V 2, 0.57 a/ hold,
 30 a/ pull, t hread size 5/16"-24,
 t hread type Inches, Pull rating 165N,
 r eturn spring 80-115N, Hold rating 391N,
 Plunger External, Function Pull,
 Mount. type Flange/bracket,
 switch External, insulated return Yes
*This solenoid can't switch off by itself, it
 will have to be controlled externally.*

internally switched



090160 Shutdown Solenoid
12 V, 0.7 a/ hold, 30 a/ pull,
t hread size 6, t hread type mm,
Pull rating 40N at 25.40 mm,
r eturn spring 17N, Hold rating 89N,
Plunger External, switch Internal,
Elect. connection Connection,
Mount. type Flange/bracket, *This
solenoid can switch off the pull coil, and no
external 'control' is necessary.*



090161 Shutdown Solenoid
24 V, 0.25 a/ hold, 17 a/ pull,
t hread size 6, t hread type mm,
Pull rating 40N at 25.40 mm,
r eturn spring 17N, Hold rating 89N,
Plunger Internal, Function Pull,
Elect. connection Connection,
Mount. type Flange/bracket,
switch Internal
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*



090168 Shutdown Solenoid
12 V, 0.6 a/ hold, 44 a/ pull,
t hread size 6, t hread type mm,
Pull rating 75N at 25.40 mm,
r eturn spring 35N, Hold rating 178N,
Plunger External, switch Internal,
Elect. connection Connection,
Mount. type Flange/bracket, *This
solenoid can switch off the pull coil, and no
external 'control' is necessary.*



090169 Shutdown Solenoid
24 V, 0.3 a/ hold, 23 a/ pull,
t hread size 6, t hread type mm,
Pull rating 75N at 25.40 mm,
r eturn spring 35N, Hold rating 178N,
Plunger External, Function Pull,
Elect. connection Connection,
Mount. type Flange/bracket,
switch Internal, aux terminal Yes
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*



090210 Shutdown Solenoid
12 V, 1.1 a/ hold, 46 a/ pull,
t hread size 1/4"-28 stud.,
t hread type Inches,
Pull rating 89N at 25.40 mm,
r eturn spring 9N, Hold rating 178N,
Plunger Internal, Function Pull,
Elect. connection Connection,
Mount. type Flange/bracket,
switch Internal, aux terminal Yes
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*



090224 Shutdown Solenoid
12 V, 0.25 a/ hold, 17 a/ pull,
t hread size 6, t hread type mm,
Pull rating 40N at 25.40 mm,
r eturn spring 17N, Hold rating 89N,
Plunger Internal, switch Internal
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*



090268 Shutdown Solenoid
servicing: Kubota 5 series
12 V, Plunger Internal, switch Internal
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*



090297 Shutdown Solenoid
24 V, 1.1 a/ hold, 46 a/ pull,
t hread size 6, t hread type mm,
Pull rating 107N at 25.40 mm,
r eturn spring 7-11N, Hold rating 169N,
Plunger External, switch Internal,
aux terminal Yes
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*



090317 Shutdown Solenoid
24 V, 0.3 a/ hold, 20 a/ pull,
Pull rating 98N at 32.00 mm,
r eturn spring 45N, Hold rating 245N,
Plunger Internal, switch Internal,
coil commander w/
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*



090318 Shutdown Solenoid
12 V, 0.65 a/ hold, 37 a/ pull,
Pull rating 98N at 32.00 mm,
r eturn spring 45N, Hold rating 245N,
Plunger Internal, switch Internal
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*



090334 Shutdown Solenoid
servicing: Sisu Diesel 8366 40253
12 V, Plunger Internal, switch Internal
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*



090402 Shutdown Solenoid
servicing: Kubota super 5 series
24 V, Plunger Internal, switch Internal
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*



090430 Shutdown Solenoid
servicing: Kubota
12 V, Plunger Internal, switch Internal
*This solenoid can switch off the pull coil,
and no external 'control' is necessary.*

Pull coil timer Modules



090115 Pull Coil Timer
12 V, no./ wires 3



090116 Pull Coil Timer
24 V, no./ wires 3

Electro Valve



080787 Electro Valve
12 V, t thread M12-1.5, Electro valve Yes



080791 Electro Valve
12 V, t thread M14-1.5, Electro valve Yes

advance solenoids



080941 Actuator
servicing: Ford
12 V



080942 Actuator
servicing: Renault
12 V



081117 Actuator
12 V



081120 Actuator
12 V



080940 Actuator
servicing: Fiat, Renault
12 V

solenoid stop



080177 Solenoid Stop
12 V, 12 V 2, Filter w/o,
insulated return No



080178 Solenoid Stop
24 V, 24 V 2, Filter w/o,
insulated return No



080207 Solenoid Stop
12 V, 12 V 2, Filter w/o,
insulated return No



080208 Solenoid Stop
24 V, 24 V 2, Filter w/o,
insulated return No

Pkg. 10



080209 Solenoid Stop
12 V, 12 V 2, Filter w/o,
insulated return No

Pkg. 10



080210 Solenoid Stop
24 V, 24 V 2,
Elect. connection Connection,
Filter w/o, insulated return Yes



080211 Solenoid Stop
24 V, 24 V 2, Filter w/o,
insulated return No



080212 Solenoid Stop
12 V, 12 V 2,
Elect. connection Connection,
Filter w/o, insulated return Yes



080595 Solenoid Stop
12 V, 12 V 2, Filter w/o,
insulated return No

Pkg. 10



080680 Solenoid Stop
12 V, 12 V 2, Filter w/



080873 Solenoid Stop
12 V, 12 V 2, Filter w/o



080926 Solenoid Stop
24 V, 24 V 2

Pkg. 10



080929 Solenoid Stop
12 V, 12 V 2, Elect. connection Cable,
Filter w/o, insulated return Yes

Pkg. 10



080994 Solenoid Stop
12 V, 12 V 2, Filter w/o,
insulated return No
w/o thread on the electrical connection.

Pkg. 10



080995 Solenoid Stop
12 V, 12 V 2,
Elect. connection Multiplug, Filter w/o,
insulated return Yes



080996 Solenoid Stop
24 V, 24 V 2,
Elect. connection Multiplug, Filter w/o,
insulated return Yes

Pkg. 10



080998 Solenoid Stop
12 V, 12 V 2, Filter w/o,
insulated return No



081000 Solenoid Stop
12 V, 12 V 2, Function Push, type Coil,
Filter w/o, insulated return No



081001 Solenoid Stop
24 V, 24 V 2, Elect. connection Cable,
Function Pull, Filter w/o,
insulated return Yes
Insulated.



081002 Solenoid Stop
24 V, 24 V 2, Elect. connection Cable,
Function Push, Filter w/o,
insulated return Yes
Insulated.



081166 Solenoid Stop
12 V, 12 V 2, Filter w/o,
insulated return No

Pumps & Pump Parts

Electrical Bilge Pumps