

4 step set-up



Handlebar

- Release this lever
- Set the brakes and gears to a position that suits you
- Re-fix the lever



Headset

- Lift the handlebar stem into position
- Fix the headset into position
- Lock the lever with the catch



Seatpost

- Open the lever to release the seatpost
- Set the height of your saddle
- Re-fix the lever



Pedal

- Flip pedals out from their compact position
- To fold them back in, press the pedal in towards the bike and then twist

You are almost ready to take charge of the road...



Screen instructions

Electrify your ride

- Hold the "power" button for two seconds to turn on/off

Light her up

- Hold down "level up" for two seconds to turn on front light
- The rear light is powered via a button on the light itself

Take charge of your speed

- Toggle between power modes using "level up/down"

Take it easy

- Hold down "level down" for two seconds to enable walk assist
****WARNING - bike will lurch forward if stationary****

Battery Removal

- To remove and charge the battery away from your bike, unscrew the bolt (Top right photo) and pull the seat post all the way up until it is free from the bike
- For charging whilst in the bike, simply plug in the charging cable under the saddle



Battery Removal

Bedding in brakes

The key is to heat and cool the brakes in a repeatable and consistent manner without accidentally scoring the pads or rotor by braking too hard, too soon.

- Hop on your bike somewhere with plenty of room. Pedal up to a moderate speed – 15km/h or so.
- Sit down in the saddle and apply the brakes evenly, without skidding, until speed drops to a walking pace.
- Release the brakes while you're still moving.
- Repeat 10 times. You will feel brake power increasing with each repetition. Be careful not to skid as brake power increases with each repetition.
- Perform the same set of steps, but increase speed to 25km/h.
- Repeat 5-6 times.

Maintenance

Looking after your battery

- Fully charge your battery before first use
- Charge your battery for at least 2 hours, once a month
- When not in use, store your battery in a dry environment ideally between 12-22°C
- Charge battery before storing or prior to periods of non-use

Before each ride

- Ensure that all quick release levers are securely fastened:
 1. Seat post lever
 2. Frame lever with safety catch
 3. Stem folding lever with safety catch
 4. Stem adjustment lever
 5. Handlebar adjustment lever
 6. Folding pedals

- Ensure tyres are inflated between the min. and max. pressures indicated
- Ensure pedals are fitted securely
- Ensure handlebars and stem are secured and free from play
- Ensure your battery and all connections are free from damage
- Fasten your helmet

After each ride

- Clean your estarli using water and a damp cloth to remove dirt and grit
- Do not clean your bike using a pressure wash
- Clean your brakes using a damp cloth (do not grease your brakes or brake discs)
- Keep the drivetrain clean and lubricated
- Keep your tyres inflated
- Keep the nuts and bolts tight, but don't over-tighten them
- Make sure your brakes are adjusted correctly, check and change brake pads if necessary

Further information

- For manuals and support videos please visit: www.estarli.co.uk/support/e20