

MERTIK MAXITROL® myfire® – Initial App Setup

ANDROID APP ON
Google Play



DOWNLOAD THE MYFIRE APP

To download the myfire app search for “myfire” at Google Play.

For more information go to:
www.myfireapp.com




WELCOME SCREEN

Touch anywhere on the screen to start the app setup.



CHOOSE LANGUAGE, TEMPERATURE SCALE AND TIME FORMAT

1. Choose language
2. Choose °C or °F
3. Choose 12 or 24 hour clock
4. Touch **“Next”** button to continue.




REGISTRATION

NOTICE

You must register before logging in. If you have already registered go directly to login. Registration is one time only. Touch the **“Register”** button.


or

Login and accept the **“Terms and Conditions”**. Touch **“Login”** button.



REGISTRATION – PRIVACY POLICY

1. Fill in your data.
2. Create a password at least 8 characters in length.
3. Confirm password.
4. Accept the “Privacy Policy”.
5. Touch “**Register**” button.



Phone:

E-mail:

Password: *8-character min.*


Confirm Password:

✓ To log in you must accept the [Privacy Policy](#)

Back Register


REGISTRATION – PRIVACY POLICY

Touch “OK” in pop-up.




REGISTRATION – EMAIL

Touch the link in the confirmation email for verification.




REGISTRATION – VERIFICATION

You will be shown a verification message that you have successfully registered the myfire app.




LOGIN

1. Auto fill email
2. Type in password.
3. Accept Terms and Conditions.



CONNECT SMART DEVICE TO MYFIRE WI-FI BOX

Touch the  icon.



CONNECT SMART DEVICE TO MYFIRE WI-FI BOX

A pop up message tells you to go to your Smart Device Wi-Fi settings.




GOOGLE ANDROID – WI-FI SETTINGS

In the Google Android device Wi-Fi settings connect your Google Android device to the myfire Wi-Fi Box:

1. Select the following:

`myfire_WiFi-Box_<number>`




GOOGLE ANDROID – WI-FI SETTINGS

In the Google Android device Wi-Fi settings connect your Google Android device to the myfire Wi-Fi Box:

2. Enter the following password in pop-up:

MYFIREPLACE




CONNECT MYFIRE WI-FI BOX TO WI-FI ROUTER

Fill in the following data:

- Select an individual name for your fire.
- Type in name (SSID) of your Wi-Fi Router.
- Type in password of your Wi-Fi Router.

Touch **“Connect”** button.



CONNECT SMART DEVICE TO WI-FI ROUTER

Touch **“OK”** if correct.



CONNECTING PROCESS

The process of connecting the myfire Wi-Fi Box to your Wi-Fi Router can take a few seconds.

When the connection is established the myfire Wi-Fi Box leaves the Access Point Mode (Hot Spot) and is connected to your Wi-Fi Router.




CONFIRM FIREPLACE SETTINGS

If your fireplace is equipped with fan, light and AUX touch the circle to activate the corresponding function.

- ⌂ After setting up the myfire Wi-Fi Box and myfire app, the time has to be synchronized in the settings of the myfire app.

When setup is complete, confirm fireplace settings by touching **“Finish”** button.




CONNECTED MYFIRE WI-FI BOXES

A list of all connected myfire Wi-Fi Boxes is now displayed. Touch **“Start APP”** button to finish installation process and app setup.

Icon explanation:

- ✓ Setup complete
- ⇩ Software updates for myfire Wi-Fi Box available
- ▶ Setup incomplete
- ! myfire Wi-Fi Box is not compatible



CONGRATULATIONS

The myfire app is ready to go and the home screen is displayed.

