

# SOPIVA

ASSEMBLY INSTRUCTIONS  
KOONTIOHJEET



**SELKA**


**SELKA**store

# ASSEMBLY INSTRUCTIONS


Congratulations! You chose a **SELKA** product!  
Hope you will enjoy using it as much as we  
enjoyed making it!

## PACKAGE INCLUDES:

- A** 4 pcs M6x10 mm allen screw
- B** 2 pcs M6x40 mm thread pin
- C** 2 pcs M6x12 mm crown nut
- D** 1 pcs hex key



1.



## TABLE COMPONENTS:


- 1** Table top
- 2** Table leg
- 3** Table pedestal

2.



Protect the table top with the cardboard and attach the leg.

3.



Place the (A) allen screws by hand and then tighten carefully with the (D) hex key.

4.




Fasten the (B) thread pins to the table leg by turning them few rounds.

5.



Turn the table sideways and attach the pedestal.

6.



Use the **(D)** hex key to fasten the **(C)** crown nuts to the **(B)** thread pins.

7.



Turn the table upright and you're finished!

8.



## ADJUSTING THE HEIGHT

### LIFT THE TABLE

Release the gas spring lever. Gas spring will lift the table upwards. Lock the lever in wanted height.

### LOWER THE TABLE

Release the gas spring lever. Push the table top downwards. Use body weight to assist. Lock the lever in wanted height.




# KOONTIOHJEET


Onnittelut! Valitsit **SELKA** tuotteen!  
Toivottavasti nautit sen käytöstä yhtä paljon  
kuin me nautimme sen valmistuksesta!

## PAKKAUS SISÄLTÄÄ:

- A** 4 kpl M6x10 mm kuusiokoloruuvi
- B** 2 kpl M6x40 mm vaarnaruuvi
- C** 2 kpl M6x12 mm koristemutteri
- D** 1 kpl kuusiokoloavain



1.



## PÖYDÄN OSAT:


- 1** Pöytälevy
- 2** Pöydänjalka
- 3** Jalusta

2.



Suojaa pöytälevy pahvilla ja kohdista jalka.

3.



Kohdista **A** kuusiokoloruuvit käsin ja kiristä varovasti **D** kuusiokoloavaimella.

4.



Kiinnitä **B** vaarnaruuvit pöydänjalkaan kiertämällä niitä muutaman kierroksen.

5.



Käännä pöytä sivuttain lattiaa vasten ja kiinnitä jalusta.

6.



Kiinnitä **C** koristemutterit **B** vaarnaruuveihin **D** kuusiokoloavaimella.

7.



Nosta pöytä pystyasentoon ja olet valmis!

8.



## KORKEUDEN SÄÄTÖ

### PÖYDÄN NOSTAMINEN

Vapauta pöydän jalassa oleva vipu, jolloin pöytä nousee ylöspäin. Lukitse vipu haluttuun korkeuteen.

### PÖYDÄN LASKEMINEN

Vapauta pöydän jalassa oleva vipu. Paina pöytää alaspäin. Käytä kehosi painoa apuna. Lukitse vipu haluttuun korkeuteen.



**Max kantavuus**  
**20 kg**

**SELKA**