

Control Panel Operation Manual

E04 “The Resetting Process”

Press and hold both the “Up” and “Down” buttons, PLEASE DO NOT LET YOUR HANDS GO UNTIL THE TABLE DECLINES to the lowest point and completes the rebound, then press “up” button to adjust the height

If you let your hand go during the process, you may damage the motor permanently.

Set Memory Position

Press “S” button, then press 1,2,3 or 4 to lock the position at your preference.

“CM” and “Inch” Switch

Press “s” and “down” buttons at the same time to switch “CM” and “Inch”.

Set Maximum Height

Hold “S” button for a few seconds, then hold “3” button together until “-L-” showing on the control panel.

Set Minimum Height

Hold “S” button for a few seconds, then hold “1” button together until “-L-” showing on the control panel.

Clear Minimum or Maximum height

Hold “S” button for a few seconds, then hold “2” button together until “-C-” showing on the control panel.

One touch Model

Hold “S” button until the screen flashes, then press “1” button to adjust “H-0” to “H-1” by pressing “up” or “down” button.

Sensitivity Setting

Hold “S” button until the screen flashes, then press “3” button with the “G-” showing on the control panel, then press “up” or “down” button to adjust the sensitivity level from 1-4 at your preference.