



Lock & Key Assembly




Head Hold Down Rods




Coin Mechanism



Chute Guard



"Candy Flap" Chute Door



Note:

Do not "over-tighten" the lock when putting the lid back on your machine. Just "snug up" the lock so the lid is tight. You need to push down on the key when it is in the lock to move it. In other words, "depress the key" into the lock and turn. Use cooking spray and spray the threads and inside the lock.

