





PRODUCT SHEET

DESCRIPTION





MATERIALS



The wooden poles are laminated pine wood which makes them ultra strong and they are coated with a rustic varnish to protect them.

On top of the center poles, there is an option to install unique pennant flags, these flags can also be personalized (in your desired color or logo)

Keep in mind that an extra space of 1,5m around the tent is needed to anchor and install the tent.



COLORS

Available colors are ivory & midnight blue.

SIDEWALLS / HEATING

Silhouette tents can all be fully closed with an easy to adapt sidewall system, where you can choose between clear and / or solid sidewalls. This makes it easy to heat or air condition the tent. You can thus enjoy the feel of both an open or closed tent.





CONNECTION

A Silhouette walkway can connect 2 Silhouette tents, and can also be closed on the sides with solid or transparent sidewalls.



TECHNICAL DRAWING





What's included?

- 1x 8x13m Oval Canopy + Tentbag
- 2x 5m Centre Pole
- 12x 2,30m Sidepoles
- 12x Steel Pegs (1,00m)
- 12x Peq Covers

- 12x 50mm Ratchets
 - 2x Bamboo Flagstaff & Flag
 - 12x Sidewalls (6,00m) solid or clear
- 2x Sidewalls (3,00m) solid or clear

LONG TERM INSTALLATION

For (semi-)permanent builds we recommend adding baseplates under the poles for extra protection. This will greatly increase your pole's lifespan and structural integrity. For this tent, you will require following quantities (not included in a standard set):

12x small baseplate

A Silhouette tent has a long-term estimated lifespam of 2-3 year. If you wish to extend this lifespan up to 7-10 year, upgrade to a ferrari sailcloth.

In case of a long term installation it's important to check the tension on the tent (at least every month), and to keep the tent free of snow or ice by heating the tent.

Our tents are able to carry high winds up to 12Okm/h. When winds reach more then 75km/h its important to open the sidewalls so that the wind can blow through the tent. It is very important at that moment that the tent is still firmly anchored all around.

It is necessary to permanently melt the snow on top of your tent. The best way to do this is to heat the tent with a special heating device.

Ideally the tent should be heated before it starts snowing. This prevents the tent from collapsing under the weight of snow or ice. So always keep an eye of possible snowfall in the Winter, if you live in a region where snowfall is possible.

EXAMPLE FORMULAS

1. Ceremony

£ 150

2. Cocktail 💆 🙈 95

3. Walking dinner A 📉 🕅

4. Seated dinner hard 88 55