

Hey Sexy!

**Congratulations! You are on your way to Heavenly Orgasms, with the AdultLuxe Rose Tongue Clit Tickler with Thrusting Dildo. Here's your quick operating guide.**

### How to Operate

Fully charge the product before using. Indicator lights will flash while it is being charged and will stop flashing when it is charged.

- a. Long press the ON/OFF button for 2 seconds to go into the standby mode. Short press the ON/OFF button to start the first Telescopic Mode and one more press to start the next Telescopic Mode. There are 10 different Telescopic Modes to cycle through.
- b. With the standby mode, short press on the Tongue Licking button to start the first Licking Mode. Click on it one more time to start the next Licking Mode. There are 10 different licking modes to cycle through.

### Cleaning & After Care

- 1). After use, your toy should be cleaned with warm water & antibacterial soap.
- 2). Please ensure that you dry the toy with a soft clean towel and store it within the pouch provided. Keep in a dust-free environment. You use an ear bud to clean the internals.
- 3). Avoid keeping the toy in direct sunlight.

### Safety Recommendations

- 1). Try not to exceed the recharge period beyond 24 hours.
- 2). Avoid sharing the product with others.
- 3). To avoid causing injury and damage, please ensure you use a water-based lubricant.
- 4). Stop using your toy if you find it uncomfortable.
- 5). Ensure that you store your toy out of reach of children and pets. Duh! No, really, they think it is theirs to chew on and play with!

### Warranty

Your toy has a 1-Year warranty from the date of purchase against any manufacturing defects or malfunctions.

All man-made damages, including regular wear and tear damages, are beyond the scope of this warranty. Because of the special nature of adult products, items once used and opened cannot be returned. Please check carefully before use.



info@adultlux.com  
ADULTLUXE.COM



### Specifications:

Materials: Silicone & ABS  
 Vibration Modes: 10 Licking Modes & 10 Telescopic Modes  
 Noise Range: ≤50dB  
 Waterproof Grade: IPX-7  
 Battery Type: Enclosed Lithium  
 Charging Time: 3 Hours  
 Working Duration: 1 Hour  
 Input Voltage: 5V≅500mA  
 Magnetic USB Charging  
 Product Size: 55\*55\*300mm