



Placement and Maintenance

Your Nord Bench is designed for indoor use on level floors. Furniture with hard lacquer, wax polish or painted surface should be dusted with a dry cloth. Spillages should be wiped up as soon as possible. Our furniture will endure most temperatures in the home but it is best to avoid placing furniture next to heat sources such as radiators or fires.




Tool Provided:

T1 Wrench (M13) x 1

T2 Allen Key (M4) x 1

H1 Headless Bolt (8x74mm) x 4





H2 Bolt (6x55mm) x 8

H3 Fixing Head x 4







H4 Hex Nut x 4

Step 1


Unpack and identify the parts listed below. It is required to have **2 people to carry and assemble** the units over 50lbs. The assembly workspace should be a non-marring surface such as carpet. For missing hardware pieces, visit our website www.mossdesign.us





Step 2 - Fix the headless bolt to legs.

Fix 4 headless bolts H1 to the legs C2, by hand.



Step 4 - Fix the legs by using bolts.

