
Margolis Glass Pendant

ARHAUS

your home

parts enclosed:

Α	Wire Connector	3
В	Mounting Bracket	1
С	Mounting Screw	2
D	Ground Screw	1
Е	Canopy	1
F	Hex Nut	2
G	Nipple	1
Н	Lock Washer	1
I	Screw Collar Loop	1
J	Threaded Ring	1
K	Chain	1
L	Fixture Loop	1
М	Ball Nut	4
N	Pendant Body	1
Ο	Screw	4
Р	Glass Shade	1



caution:

BEFORE INSTALLING CHANDELIER, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

important safety instructions:

- This chandelier is meant for indoor use, DRY LOCATIONS ONLY.
- 2. Do not use the electric cord to support the weight of the chandelier.
- 3. These instructions are provided for your safety. It is important that they are read carefully and completely before beginning the installation of this lighting fixture.
- 4. For your safety, it is strongly recommended that two people install the lighting fixture.
- 5. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- 6. Save these instructions.

warning:

- To reduce the risk of fire, electrical shock or personal injury, always turn off the chandelier and allow it to cool prior to replacing light bulbs.
- 2. Do not touch the bulbs when the chandelier is turned on. Do not look directly at lit bulbs.
- 3. Keep flammable materials away from lit bulbs.

to assemble:

Remove all parts and hardware from box along with any plastic protective packaging. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 2. Unscrew Ball Nut (M) from Pendant Body, and remove the Glass Shade (P).
- 3. Attach the Mounting Bracket (B) onto the Ceiling Outlet Box using Mounting Screws (C). Tighten screws with a screwdriver until secure.
- Attach one Hex Nut (F) to the top, and the other Hex Nut (F) to the bottom of the Nipple (G). Put the Lock Washer (H) in before attaching the Screw Collar Loop (I) to the bottom end of the Nipple (G).
- 5. Secure the top of Nipple (G) to the Mounting Bracket (B) with the Hex Nut (F), exposing approximately 2" of its thread.

Margolis Glass Pendant



your home

- 6. Pull out the fixtures 2 wire power cord and bare copper ground wire woven through the Chain (K)
- 7. Slide the Canopy (E) and the Threaded Ring (J) up the Chain (K).
- 8. Connect Chain (K) to Fixture Loop (L) and hang up to Screw Collar Loop (I) by using quick links. Close the opening of quick links by screwing the nut clockwise.
- Gently pull existing Ground, Hot, and Neutral Junction Box wires down from the Ceiling Junction Box and allow them to hang
- 10. Carefully inspect the chandelier's fixture wires. The Neutral Fixture Wire is ribbed. The Hot Fixture Wire is smooth, and the Ground Fixture Wire is in copper.
- 11. Attach the Ground Wire from the fixture to the Ground Junction Box Wire. It usually has green insulation around it or is bare wire. Fasten these together with a Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. If the Ceiling Outlet Junction Box does not have a Ground Junction Box Wire, insert the Ground Screw (D) into the Mounting Bracket (B) where it's marked "Ground", facing down and wrap the fixture's ground wire around the Ground Screw (D). Tighten the Ground Screw (D) to clamp Ground Fixture Wire between the head of Ground Screw (D) and Mounting Bracket (B). IT IS IMPERATIVE THAT THE CEILING OUTLET JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED!
- 12. Connect the Neutral Fixture Wire to the Neutral Junction Box Wire. It usually has white insulation around it. Fasten these together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed.
- 13. Connect the Hot Fixture Wire to Hot Junction Box Wire. It usually has black insulation around it. Fasten these together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. Do not reverse the hot and neutral connections or safety will be compromised.
- 14. Gently and neatly tuck the wire connections into the Ceiling Outlet Junction Box.
- 15. Place the Canopy (E) over the Ceiling Outlet Junction Box and secure it in place by screwing the Threaded Ring (J) onto the Screw Collar Loop (I).
- 16. Insert ONE (1) 40-Watt maximum Type A standard medium base incandescent light bulb (not included) or ONE (1) 9-watt maximum compact fluorescent light bulb (not included) or ONE (1) 6-watt maximum LED light bulb (not included) into the socket. DO NOT EXCEED SPECIFIED WATTAGE.

- 17. Attach Glass Shade (P) onto the Pendant Body (N) by tightening the Ball Nut (M).
- 18. Restore power to junction box and test the fixture.
- 19. Installation is now completed.

care instructions:

- 1. Wipe clean with a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the chandelier's finish.

LIGHTING PARTS SKUS

CATEGORY	SKU	DESCRIPTION	STATUS	COLLECTION	ROUTE
LIGHTING	91594L70CH	MARGOLIS PENDANT 12 FT CHAIN	Α	PT-MARGOLI	PART
		PAINTED GLD 12 FT HANGING CHN			
LIGHTING	91594L70CH6	MARGOLIS PENDANT 6 FT CHAIN	Α	PT-MARGOLI	PART
		PAINTED GLD 6 FT HANGING CHN			
LIGHTING	91594L70CN	MARGOLIS PENDANT CANOPY	Α	PT-MARGOLI	PART
		ASSEMBLY PARTS FOR CANOPY			


Margolis SM Glass Pendant 66594H651

ARHAUS

your home

parts enclosed:

Α	Wire Connector	3
В	Mounting Bracket	1
С	Mounting Screw	2
D	Ground Screw	1
Ε	Canopy	1
F	Hex Nut	2
G	Nipple	1
Н	Lock Washer	1
l	Screw Collar Loop	1
J	Threaded Ring	1
K	Chain	1
L	Fixture Loop	1
M	Ball Nut	3
N	Pendant Body	1
0	Screw	3
Р	Glass Shade	1
Q	Quick Link	2



cautions:

BEFORE INSTALLING CHANDELIER, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

important safety instructions:

- 1. WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.
- To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- This fixture is meant for indoor use, DRY LOCATIONS ONLY.
- Do not use the electric cord to support the weight of the chandelier.
- These instructions are provided for your safety. It is important that they are read carefully and completely before beginning the installation of this lighting fixture.
- 6. For your safety, it is strongly recommended that two people install the lighting fixture.
- 7. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- 8. Save these instructions.

warnings:

- To reduce the risk of fire, electrical shock or personal injury, always turn off the chandelier and allow it to cool prior to replacing light bulbs.
- 2. Do not touch the bulbs when the chandelier is turned on. Do not look directly at lit bulbs.
- 3. Keep flammable materials away from lit bulbs.

to assemble:

Remove all parts and hardware from box along with any plastic protective packaging. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 2. Unscrew Ball Nut (M) from Pendant Body, and remove the Glass Shade (P).
- 3. Attach the Mounting Bracket (B) onto the Ceiling Outlet Box using Mounting Screws (C). Tighten screws with a Screwdriver until secure.
- 4. Attach one Hex Nut (F) to the top, and the other Hex Nut (F) to the bottom of the Nipple (G). Put the Lock Washer(H) in before attaching the Screw Collar Loop (I) to the bottom end of the Nipple (G).
- 5. Secure the top of Nipple (G) to the Mounting Bracket (B) with the Hex Nut (F), exposing approximately 2" of its thread.

Margolis SM Glass Pendant 66594H651

ARHAUS

your home

- 6. Pull out the fixtures 2 wire power cord and bare copper ground wire woven through the Chain (K)
- 7. Slide the Canopy (E) and the Threaded Ring (J) up the Chain (K).
- 8. Connect Chain (K) to Fixture Loop (L) and hang up to Screw Collar Loop (I) by using Quick Links (Q). Close the opening of Quick links by screwing the nut clockwise.
- 9. Gently pull existing Ground, Hot, and Neutral Junction Box Wires down from the Ceiling Junction Box and allow them to hang
- 10. Carefully inspect the chandelier's fixture wires. The Neutral Fixture Wire is ribbed. The Hot Fixture Wire is smooth, and the Ground Fixture Wire is in copper.
- 11. Attach the Ground Wire from the fixture to the Ground Junction Box Wire; It usually has green insulation around it or is bare wire. Fasten them together with a Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. If Ceiling Outlet Junction Box does not have a Ground Junction Box Wire, insert the Ground Screw (D) into the Mounting Bracket (B) where it's marked "Ground", facing down and wrap the fixture's ground wire around the Ground Screw (D). Tighten the Ground Screw (D) to clamp Ground Fixture Wire between the head of Ground Screw (D) and Mounting Bracket (B). IT IS IMPERATIVE THAT THE CEILING OUTLET JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED!
- 12. Connect the Neutral Fixture Wire to the Neutral Junction Box Wire; it usually has white insulation around it. Fasten them together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed.
- 13. Connect the Hot Fixture Wire to Hot Junction Box Wire; it usually has black insulation around it. Fasten them together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. Do not reverse the hot and neutral connections or safety will be compromised.
- 14. Gently tuck the wire connections neatly into the Ceiling Outlet Junction Box.
- 15. Place the Canopy (E) over the Ceiling Outlet Junction Box and secure it in place by screwing the Threaded Ring (J) onto the Screw Collar Loop (I).
- 16. Insert ONE (1) 40-Watt maximum Type A standard medium base incandescent light bulb (not included) or ONE (1) 9-watt maximum compact fluorescent light bulb (not included) or ONE (1) 6-watt maximum LED light bulb (not included) into the socket. DO NOT EXCEED SPECIFIED WATTAGE.

- 17. Attach Glass Shade (P) onto the Pendant Body (N) by tightening the Ball Nut (M). **IMPORTANT**: Adjust the orientation of Glass Shade (P) until all 3 screws (O) at the top of Glass Shade (P) align with 3 holes on the cross bar of Pendant Body (N). Tighten the Ball Nut (M) to ensure Glass shade (P) and Pendant Body (N) are firmly attached together.
- 18. Restore power to junction box and test the fixture.
- 19. Installation is now completed.


care instructions:

- 1. Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.



parts enclosed:

Part	Description	Qty.
Α	lock collar	1
В	mounting Bracket	1
C	nipples	3
D	canopy	1
E	chain	1
F	open ring	1
G	loop	1
H	cable	1
1	naked earth cable	1
J	ceiling loop	1



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box.
- 2. Remove the mounting bracket (B) from the canopy (D) by loosening the lock collar (A).
- 3. Taking off the open ring (F) and use the dimensions of the fixture as a guide, shorten the chain (E) as needed using a pair of chain pliers.
- 4. Use the open ring (F) to link the chain (E) and the loop (G), then put the cable (H) and the naked earth cable (I) through the chain (E) in every 3-4 rings until through the ceiling loop (J).
- 5. INSURE THE ELECTRICITY SUPPLY IS TURNED OFF.
- 6. Affix the mounting bracket (B) on the outlet box.
- 7. Wrap both safety cable with nipples (C), push the cable into the outlet box.
- 8. Attach the canopy (D) to the mounting bracket (B) and secure with lock collar (A).
- 9. Install the bulbs on the sockets.
- 10. Installation is complete, turn on power at fuse or circuit breaker.

care instructions:

Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

PARTS INVENTORY

Super Category	Product ID	Description	Stat	Collection	Route
LIGHTING	912036H554CH	MARLOW RUST CHAND 12 FT CHAIN 12 FT HANGING CHAIN	Α	PT-MARLOW	PART
LIGHTING	912036H554C6	MARLOW RUST CHAND 6 FT CHAIN 6 FT HANGING CHAIN	A	PT-MARLOW	PART
LIGHTING	912036H554CN	MARLOW RUST CHAND CANOPY ANTIQUE RUST CANOPY	A	PT-MARLOW	PART




your home

MARQUEE BRONZE TASK FLOOR LAMP

parts enclosed:

(A)	Finial (1)

- (B) Acrylic Diffuser (1)
- (C) Acrylic Tube (1)
- (D) G-9 LED Bulb (1)
- (E) Lamp Body (1)



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

ETL NO: ETL5018481,ETL RATING: DRY, MAX BULB WATTAGE: LED 9W

BULB: (1) G-9 LED [BULB INCLUDED]

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.
- 5. The shade can only rotate 350 degrees. It cannot be turned upward, as it will dislocate the swivel joint.
- 6. When adjusting the height of the lamp, guide the wire for easier movement.

to assemble:

- 1. Remove lamp parts from carton.
- 2. Place the lamp base (E) on a flat surface.
- 3. Remove the finial (A), acrylic diffuser (B), and acrylic tube (C).
- 4. Install the bulb (D) into the socket.
- 5. Replace the acrylic tube (C) onto the socket.
- 6. Install the acrylic diffuser (B) inside the shade with the glossy surface facing out.
- 7. Screw the finial (A) completely.
- 8. Plug in the lamp.

care instructions:




MARQUEE BRONZE TASK TABLE LAMP

your home

parts enclosed:

(1)

- (B) Acrylic Diffuser (1)
- (C) Acrylic Tube (1)
- (D) G-9 LED Bulb (1)
- (E) Lamp Body (1)



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

ETL NO: ETL5018481,ETL RATING: DRY, MAX BULB WATTAGE: LED 9W

BULB: (1) G-9 LED [BULB INCLUDED]

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.
- 5. The shade can only rotate 350 degrees. It cannot be turned upward, as it will dislocate the swivel joint.

to assemble:

- 1. Remove lamp parts from carton.
- 2. Place the lamp base (E) on a flat surface.
- 3. Remove the finial (A), acrylic diffuser (B), and acrylic tube (C).
- 4. Install the bulb (D) into the socket.
- 5. Replace the acrylic tube (C) onto the socket.
- 6. Install the acrylic diffuser (B) inside the shade with the glossy surface facing out.
- 7. Screw the finial (A) completely.
- 8. Plug in the lamp.

care instructions:




your home

MARQUEE BRONZE TASK FLOOR LAMP

parts enclosed:

(A)) Finial (1)

- (B) Acrylic Diffuser (1)
- (C) Acrylic Tube (1)
- (D) G-9 LED Bulb (1)
- (E) Lamp Body (1)



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

ETL NO: ETL5018481,ETL RATING: DRY, MAX BULB WATTAGE: LED 9W

BULB: (1) G-9 LED [BULB INCLUDED]

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.
- 5. The shade can only rotate 350 degrees. It cannot be turned upward, as it will dislocate the swivel joint.
- 6. When adjusting the height of the lamp, guide the wire for easier movement.

to assemble:

- 1. Remove lamp parts from carton.
- 2. Place the lamp base (E)on a flat surface.
- 3. Remove the finial (A), acrylic diffuser (B), and acrylic tube (C).
- 4. Install the bulb (D)into the socket.
- 5. Replace the acrylic tube (C) onto the socket.
- 6. Install the acrylic diffuser (B) inside the shade with the glossy surface facing out.
- 7. Screw the finial (A) completely.
- 8. Plug in the lamp.
- 9. The lampshade only swivels 350 degrees. Damage will occur if the lampshade is turned upside down.

care instructions:




MARQUEE BRONZE TASK TABLE LAMP

your home

parts enclosed:

- (A) Finial (1)
- (B) Acrylic Diffuser (1)
- (C) Acrylic Tube (1)
- (D) G-9 LED Bulb (1)
- (E) Lamp Body (1)



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

ETL NO: ETL5018481,ETL RATING: DRY, MAX BULB WATTAGE: LED 9W

BULB: (1) G-9 LED [BULB INCLUDED]

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.
- 5. The shade can only rotate 350 degrees. It cannot be turned upward, as it will dislocate the swivel joint.

to assemble:

- 1. Remove lamp parts from carton.
- 2. Place the lamp base (E) on a flat surface.
- 3. Remove the finial (A), acrylic diffuser (B), and acrylic tube (C).
- 4. Install the bulb (D) into the socket.
- 5. Replace the acrylic tube (C) onto the socket.
- 6. Install the acrylic diffuser (B) inside the shade with the glossy surface facing out.
- 7. Screw the finial (A) completely.
- 8. Plug in the lamp.
- 9. The lampshade only swivels 350 degrees. Damage will occur if the lampshade is turned upside down.


care instructions:

ARHAUS

vourhome

parts enclosed:

ITEM	DIAGRAM	DESCRIPTION	QTY
(A)	***************************************	Backplate Screw	2
(B)	()−40 = 10	Mounting Plate & green ground screw	1
(C)	ammalmB	Mounting Screw	2
(D)	0000000000	Switch Chain	1
(E)	888	Wire connector	3
(F)	(Backplate	1
(G)		Finial	1
(H)	5	Bulb (not included)	1
(I)	0	Diffuser	1



care instructions:

Wipe all surfaces with a soft, dry cloth. Do not use any harsh cleaners (including ammonia-based products) or abrasives on the fixture as they will damage the surface.

important safety instructions:

CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommended wattage of one 4.5watt Type G9 LED lightbulb for this fixture.

warnings:

- 1. All wires are connected. Do not remove the fixture from packaging by pulling on the wires as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- Carefully remove all parts from the box and remove all protective coverings.
 Take care not to lose any small parts.
- 2. Turn OFF power at the outlet box where the lamp will be installed.
- Attach the Mounting Plate (B) to outlet box using the Mounting Screws (C), tighten with a screwdriver. Ensure the side of the Mounting Plate (B) marked "GND" is facing out.
- 4. While holding the fixture, connect the black wire from fixture to the hot wire (usually black or smooth) from the outlet box using a wire connector (E). Connect the white wire from fixture to the neutral wire (usually white or ribbed) from the outlet box using a wire connector (E). DO NOT REVERSE THE HOT AND NEUTRAL WIRE CONNECTIONS; OTHERWISE, SAFETY WILL BE COMPROMISED.
- 5. If the outlet box has a ground wire (green or bare copper), connect the green ground wire from the fixture to it using a wire connector (E). If the outlet box does not have a ground wire, connect the green ground wire from the fixture to the green ground screw provided on the Mounting Plate (B).
- 6. Tuck these wire connections neatly into the outlet box, place the Backplate (F) over the Mounting Plate (B) and align the two holes on the Backplate (F) with the corresponding holes on the Mounting Plate (B), secure the Backplate (F) with the Backplate Screws (A) until the fixture is secured to the wall.
- Install the proper light bulb (H) (not included) in accordance with the fixture's specifications (DO NOT EXCEED THE SPECIFIED WATTAGE RATING).
- 3. Attach the Diffuser (I) to the Harp and secure in place with the Finial (G).
- Installation is completed. Turn on the power at the circuit breaker or fuse box. Pull the Switch Chain (D) to activate the fixture.

Ancel Table Lamp



parts enclosed:

- (A) Finial (1)
- (B) Harp Top (1)
- (C) Harp (1)
- (D) Harp Caps (2)
- (E) Socket (1)
- (F) Saddle (1)
- (G) Lamp Base (1)
- (H) Shade
- (I) Bulb (not included)

(diagram / line drawing)

important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.
- 3. This fixture has been rated for up to one (1) 150WATT max or smaller 3way Type A or max 18W 3W SBLED Lamp

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2.. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Raise the Harp Caps (D) and insert the bottom ends of the Harp (C) into the Saddle (F).
- 2. Lower the Harp Caps (D) until they cover the two-pronged Saddle (F).
- 3. Unscrew the Finial (A) from the Harp Top (B)
- 4. Place the Shade (H) over the Harp (C) making sure the Harp Top (B) extends through the top ring of the Shade (H).
- 5. Secure the Shade (H) by turning the Finial (A) onto the Harp Top (B).
- 6. Insert the specified light bulb into the socket (E). DO NOT EXCEED THE SPECIFIED WATTAGE.

care instructions:

- 1. Wipe clean with a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.




MERCURY RISING FLOOR LAMP

your home

parts enclosed:

A. Glass shade (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E355648, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 13 W

BULB: 1 X A-15 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- Carefully remove all parts from the box and remove all protective coverings. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- 2. Remove ring (C) from the holder (B).
- 3. Insert the holder (B) into the shade (A) & tighten the ring (C) with holder (B) keeping the shade (A) in middle.

care instructions:




MERCURY RISING TASK LAMP

your home

parts enclosed:

A. Glass shade (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E355648, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 13 W

BULB: 1 X A-15 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- Carefully remove all parts from the box and remove all protective coverings. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- 2. Remove ring (C) from the holder (B).
- 3. Insert the holder (B) into the shade (A) & tighten the ring (C) with holder (B) keeping the shade (A) in middle.

care instructions:

PARTS INVENTORY


Super	Product ID	Description	Stat	Collection	Route
Category					
LIGHTING	918947L138SH	MERCURY RISING DESK LAMP SHADE	Α	PT-MERCURY	PART
		GLASS SHADE FOR DESK LAMP			
LIGHTING	918947L0390SH	MERCURY RISING FLOOR LAMPSHADE	Α	PT-MERCURY	PART
		REPLACEMENT SHADE			

MICHA SQUARE TABLE LAMP BASE



Parts enclosed:

A- FINIAL- 1 PIECE B- HARP- 1 PIECE



Important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO-E492403, UL RATING: DRY, BULB WATTAGE-100W CONVERSION TO MAX 23W SBCFL OR 9W SBLED

Bulb: 1xType A (Not included)

Warning:-

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

To assemble:

- 1. Carefully remove all part from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Attach Harp (B) to the Saddle(C).
- 4. Unscrew Finial (A) & place shade on Harp (B) and tighten finial (A) to harp (B).
- 5. Restore Power to the circuit breaker and test lamp fixture.


Care instructions:

MICHA TALL TABLE LAMP BASE



Parts enclosed:

A- FINIAL- 1 PIECE B- HARP- 1 PIECE



Important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO-E492403, UL RATING: DRY, BULB WATTAGE-100W CONVERSION TO MAX 23W SBCFL OR 9W SBLED

Bulb: 1xType A (Not included)

Warning:-

- 1. Do not remove the lamp from its packaging by pulling onthe power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

To assemble:


- 1. Carefully remove all part from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Attach Harp (B) to the Saddle(C).
- 4. Unscrew Finial (A) & place shade on Harp (B) and tighten finial (A) to harp (B).
- 5. Restore Power to the circuit breaker and test lamp fixture.

Care instructions:

MINA FLOOR LAMP

ARHAUS vour home

parts enclosed:



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO:E252747,UL RATING: DRY, MAX BULB WATTAGE: 40 W CONVERSION TO MAX LED WATTAGE: 4-5 W BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all packaging from the box and remove all plastic covering.
- 2. Use the shade adjustment loader (B) to adjust shade height.
- 3. Use the legs adjustment knobs (A) to adjust legs height.
- 4. Insert CFL bulb into socket (D).
- 5. Plug into proper electrical outlet and test the floor lamp by using in-line switch (C).

care instructions:




MYLES MARTINI FLOOR LAMP

your home

parts enclosed:

A. Finial (1) B. Harp (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Attach harp (B) to the saddle (C).
- 4. Unscrew finial (A) place shade on harp (B) and tighten finial (A) to harp (B).
- 5. Restore power to the circuit breaker and test lamp fixture.

care instructions:


LIGHTING PARTS SKUS

CATEGORY	SKU	DESCRIPTION	STATUS	COLLECTION	ROUTE
LIGHTING	913507L170F	MYLES FLOOR LAMP FINIAL BRASS FINIAL REPLACEMENT	Α	PT-MYLES	PART
LIGHTING	913507L170H	MYLES FLOOR LAMP HARP BRASS HARP REPLACEMENT	Α	PT-MYLES	PART

ARHAUS vourhome

parts enclosed:

ІТЕМ	DIAGRAM	DESCRIPTION	QTY
	SIMONAM	2233111 11014	3'''
(A)	858	Wire Connectors	3
(B)		Mounting Plate with Green Ground Screw	1
(C)		Outlet Box Screws	2
(D)		Mounting Screws	3
(E)	(0)	Canopy Assembly	1
(F)	4x 🖘 4x 🖘	Pipe with Nipple	4*24" 4*12" 4*6"
(G)		Glass Shade	5
(H)		Socket Ring	5
(1)		Bulb (not included)	5



warnings:

All wires are connected. When unpacking, be carefully not to remove the fixture from packaging by pulling on the power cord as a bad connection may result. Do not connect electricity until the fixture is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

important safety instructions:

CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.

- 1. We recommend installation by a licensed electrician.
- 2. This fixture has been rated for 5 x 1.5 watt type T14 LED lightbulb (40-watt incandescent bulb equivalent). To avoid the risk of fire, do not exceed the recommended wattage.

to assemble:

- 1. Shut off power at the outlet box where the fixture will be installed.
- 2. Carefully remove all parts from the box and remove all plastic coverings.
- 3. Place the Glass Shades (G) over the socket and secure in place with the Socket Rings (H).
- Determine the desired hanging height, feed the fixture wires through the Pipes with Nipples (F) and the Canopy Assembly (E), tighten the Pipes (F) to fixture body and the Canopy Assembly (E).
- Attached the Mounting Plate (B) to the outlet box using the Outlet Box Screws (C). Ensure the side of the Mounting Plate (B) marked "GND" is facing out.
- 6. While holding the fixture, connect the black wire from fixture to the hot wire (usually black or smooth) from the outlet box using a wire connector (A). Connect the white wire from fixture to the neutral wire (usually white or ribbed) from the outlet box using a wire connector (A). DO NOT REVERSE THE HOT AND NEUTRAL WIRE CONNECTIONS; OTHERWISE, SAFETY WILL BE COMPROMISED.
- 7. If the outlet box has a ground wire (green or bare copper), connect the green ground wire from the fixture to it using a wire connector (A). If the outlet box does not have a ground wire, connect the green ground wire from the fixture to the green ground screw provided on the Mounting Plate (B).
- Tuck these wire connections neatly into the outlet box, place the Canopy
 (E) over the Mounting Plate (B), secure the canopy with the Mounting Screws (D).
- Install the proper light bulb (not included) in accordance with the fixture's specifications (DO NOT EXCEED THE SPECIFIED WATTAGE RATING).
- Installation is completed. Turn on the power at the circuit breaker or fuse box. Turn the light switch to activate the fixture.


care instructions:

Wipe all surfaces with a soft, dry cloth. Do not use any harsh cleaners (including ammonia-based products) or abrasives on our lamp, as they will damage the finish.



parts enclosed:

ITEM	DIAGRAM	DESCRIPTION	QTY
(A)	222	Wire Connectors	3
(B)		Mounting Plate & green ground screw	1
(C)	6	Mounting Screw	2
(D)	*	Canopy Screw	3
(E)		Canopy	1
(F)		Glass Shade	3
(G)		Light Bulb (not included)	3
(H)		Socket Ring	3



care instructions:

Wipe all surfaces with a soft, dry cloth. Do not use any harsh cleaners (including ammonia-based products) or abrasives on the fixture as they will damage the surface.

important safety instructions: CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.

- 1. We recommend installation by a licensed electrician.
- This fixture has been rated for three 5 watt type T14 OR A19 LED lightbulb (40-watt incandescent bulb equivalent). To avoid the risk of fire, do not exceed the recommended wattage.

warnings:

- 1. All wires are connected. Do not remove the fixture from packaging by pulling on the wires as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.


to assemble:

- Carefully remove all parts from the box and remove all protective coverings. Take care not to lose any small parts.
- 2. Turn OFF power at the outlet box where the fixture will be installed.
- Attach the Mounting Plate (B) to outlet box using the Mounting Screws (C), tighten with a screwdriver. Ensure the side of the Mounting Plate (B) marked "GND" is facing out.
- 4. While holding the fixture, connect the black wire from fixture to the hot wire (usually black or smooth) from the outlet box using a wire connector (A). Connect the white wire from fixture to the neutral wire (usually white or ribbed) from the outlet box using a wire connector (A). DO NOT REVERSE THE HOT AND NEUTRAL WIRE CONNECTIONS; OTHERWISE, SAFETY WILL BE COMPROMISED.
- 5. If the outlet box has a ground wire (green or bare copper), connect the green ground wire from the fixture to it using a wire connector (A). If the outlet box does not have a ground wire, connect the green ground wire from the fixture to the green ground screw provided on the Mounting Plate (B).
- 6. Tuck these wire connections neatly into the outlet box, align the three holes of the Canopy (E) with the corresponding holes on the Mounting Plate (B), secure the Canopy (E) with the Canopy Screws (D) until the fixture is secured to the ceiling.
- 7. Place the Glass Shades (F) over the sockets and secure in place with the Socket Rings (H).
- Install the proper light bulb (not included) in accordance with the fixture's specifications (DO NOT EXCEED THE SPECIFIED WATTAGE RATING).
- 9. Installation is completed. Turn on the power at the circuit breaker or fuse box. Turn the light switch to activate the fixture.



parts enclosed:

ITEM	DIAGRAM	DESCRIPTION	QTY
(A)	888	Wire Connectors	3
(B)		Mounting Plate with Green Ground Screw	1
(C)		Outlet Box Screws	2
(D)	89 89 99	Mounting Screws	3
(E)	0	Canopy Assembly	1
(F)	4x ————————————————————————————————————	Pipe with Nipple	4*18" 4*12" 4*6"
(G)		Glass Shade	5
(H)		Socket Ring	5
(I)		Bulb (not included)	5



warnings:

All wires are connected. When unpacking, be careful not to remove the fixture from packaging by pulling on the power cord as a bad connection may result. Do not connect electricity until the fixture is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

important safety instructions:

CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.

- 1. We recommend installation by a licensed electrician.
- This fixture has been rated for 5 x 1.5 watt type T14 LED lightbulb (40-watt incandescent bulb equivalent). To avoid the risk of fire, do not exceed the recommended wattage.

to assemble:

- 1. Shut off power at the outlet box where the fixture will be installed.
- 2. Carefully remove all parts from the box and remove all plastic coverings.
- 3. Place the Glass Shades (G) over the socket and secure in place with the Socket Rings (H).
- 4. Determine the desired hanging height, feed the fixture wires through the Pipes with Nipples (F) and the Canopy Assembly (E), tighten the Pipes (F) to fixture body and the Canopy Assembly (E).
- Attached the Mounting Plate (B) to the outlet box using the Outlet Box Screws (C). Ensure the side of the Mounting Plate (B) marked "GND" is facing out.
- 6. While holding the fixture, connect the black wire from fixture to the hot wire (usually black or smooth) from the outlet box using a wire connector (A). Connect the white wire from fixture to the neutral wire (usually white or ribbed) from the outlet box using a wire connector (A). DO NOT REVERSE THE HOT AND NEUTRAL WIRE CONNECTIONS; OTHERWISE, SAFETY WILL BE COMPROMISED.
- 7. If the outlet box has a ground wire (green or bare copper), connect the green ground wire from the fixture to it using a wire connector (A). If the outlet box does not have a ground wire, connect the green ground wire from the fixture to the green ground screw provided on the Mounting Plate (B).
- Tuck these wire connections neatly into the outlet box, place the Canopy
 (E) over the Mounting Plate (B), secure the canopy with the Mounting Screws (D).
- Install the proper light bulb (not included) in accordance with the fixture's specifications (DO NOT EXCEED THE SPECIFIED WATTAGE RATING).
- 10. Installation is completed. Turn on the power at the circuit breaker or fuse box. Turn the light switch to activate the fixture.


care instructions:


Wipe all surfaces with a soft, dry cloth. Do not use any harsh cleaners (including ammonia-based products) or abrasives on our lamp, as they will damage the finish.

$\underset{\mathrm{vourhome}}{ARHAUS}^{*}$

parts enclosed:

ITEM	DIAGRAM	DESCRIPTION	QTY
(A)	888	Wire Connectors	3
(B)		Mounting Plate with Green Ground Screw	1
(C)	=	Outlet Box Screws	2
(D)	6m 6m 6m	Mounting Screws	3
(E)	(-)	Canopy Assembly	1
(F)	4x 🖘 4x 🖘	Pipe with Nipple	4*18" 4*12" 4*6"
(G)		Glass Shade	5
(H)		Socket Ring	5
(1)		Bulb (not included)	5
(J)		Upper Pivot Joint	1
(K)		Lower Pivot Joint	1
(L)	<i>B</i> -	Handle	1






to assemble to slopped ceiling:

- Shut off power at the outlet box where the fixture will be installed.
- 2. Carefully remove all parts from the box and remove all plastic coverings.
- 3. Place the Glass Shades (G) over the socket and secure in place with the Socket Rings (H).
- Determine the desired hanging height, feed the fixture wires through the Pipes with Nipples (F) and the Canopy Assembly (E), tighten the Pipes (F) to fixture body.
- 5. Screw the Lower Pivot Joint (K) to the Pipe (F), refer to Fig.2.
- 6. Screw the Upper Pivot Joint (J) to the Canopy (E), refer to Fig.1.
- 7. Attach the Upper Pivot Joint (J) to the Lower Pivot Joint (K), tighten with the Handle (L), refer to Fig.3.
- Attach the Mounting Plate (B) to the outlet box using the Outlet Box Screws (C). Ensure the side of the Mounting Plate (B) marked "GND" is facing out.
- 9. While holding the fixture, connect the black wire from fixture to the hot wire (usually black or smooth) from the outlet box using a wire connector (A). Connect the white wire from fixture to the neutral wire (usually white or ribbed) from the outlet box using a wire connector (A). DO NOT REVERSE THE HOT AND NEUTRAL WIRE CONNECTIONS; OTHERWISE, SAFETY WILL BE COMPROMISED.
- 10. If the outlet box has a ground wire (green or bare copper), connect the green ground wire from the fixture to it using a wire connector (A). If the outlet box does not have a ground wire, connect the green ground wire from the fixture to the green ground screw provided on the Mounting Plate (B).
- Tuck these wire connections neatly into the outlet box, place the Canopy (E) over the Mounting Plate (B), secure the canopy with the Mounting Screws (D).
- Install the proper light bulb (not included) in accordance with the fixture's specifications (DO NOT EXCEED THE SPECIFIED WATTAGE RATING).
- 13. Installation is completed. Turn on the power at the circuit breaker or fuse box. Turn the light switch to activate the fixture.



parts enclosed:

ITEM	DIAGRAM	DESCRIPTION	QTY
(A)	222	Wire Connectors	3
(B)		Mounting Plate & green ground screw	1
(C)	6	Mounting Screw	2
(D)	*	Canopy Screw	3
(E)		Canopy	1
(F)		Glass Shade	3
(G)		Light Bulb (not included)	3
(H)		Socket Ring	3



care instructions:

Wipe all surfaces with a soft, dry cloth. Do not use any harsh cleaners (including ammonia-based products) or abrasives on the fixture as they will damage the surface.

important safety instructions: CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.

- 1. We recommend installation by a licensed electrician.
- This fixture has been rated for three 5 watt type T14 OR A19 LED lightbulb (40-watt incandescent bulb equivalent). To avoid the risk of fire, do not exceed the recommended wattage.

warnings:

- 1. All wires are connected. Do not remove the fixture from packaging by pulling on the wires as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.


to assemble:

- Carefully remove all parts from the box and remove all protective coverings. Take care not to lose any small parts.
- 2. Turn OFF power at the outlet box where the fixture will be installed.
- Attach the Mounting Plate (B) to outlet box using the Mounting Screws (C), tighten with a screwdriver. Ensure the side of the Mounting Plate (B) marked "GND" is facing out.
- 4. While holding the fixture, connect the black wire from fixture to the hot wire (usually black or smooth) from the outlet box using a wire connector (A). Connect the white wire from fixture to the neutral wire (usually white or ribbed) from the outlet box using a wire connector (A). DO NOT REVERSE THE HOT AND NEUTRAL WIRE CONNECTIONS; OTHERWISE, SAFETY WILL BE COMPROMISED.
- 5. If the outlet box has a ground wire (green or bare copper), connect the green ground wire from the fixture to it using a wire connector (A). If the outlet box does not have a ground wire, connect the green ground wire from the fixture to the green ground screw provided on the Mounting Plate (B).
- 6. Tuck these wire connections neatly into the outlet box, align the three holes of the Canopy (E) with the corresponding holes on the Mounting Plate (B), secure the Canopy (E) with the Canopy Screws (D) until the fixture is secured to the ceiling.
- 7. Place the Glass Shades (F) over the sockets and secure in place with the Socket Rings (H).
- Install the proper light bulb (not included) in accordance with the fixture's specifications (DO NOT EXCEED THE SPECIFIED WATTAGE RATING).
- 9. Installation is completed. Turn on the power at the circuit breaker or fuse box. Turn the light switch to activate the fixture.



parts enclosed:

ITEM	DIAGRAM	DESCRIPTION	QTY
(A)	888	Wire Connectors	3
(B)		Mounting Plate with Green Ground Screw	1
(C)		Outlet Box Screws	2
(D)	89 89 99	Mounting Screws	3
(E)	0	Canopy Assembly	1
(F)	4x ————————————————————————————————————	Pipe with Nipple	4*18" 4*12" 4*6"
(G)		Glass Shade	5
(H)		Socket Ring	5
(I)		Bulb (not included)	5



warnings:

All wires are connected. When unpacking, be careful not to remove the fixture from packaging by pulling on the power cord as a bad connection may result. Do not connect electricity until the fixture is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the light bulb.

Do not touch bulb when fixture is turned on or look directly at lit bulb. Keep flammable materials away from lit bulb.

important safety instructions:

CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.

- 1. We recommend installation by a licensed electrician.
- This fixture has been rated for 5 x 1.5 watt type T14 LED lightbulb (40-watt incandescent bulb equivalent). To avoid the risk of fire, do not exceed the recommended wattage.

to assemble:

- 1. Shut off power at the outlet box where the fixture will be installed.
- 2. Carefully remove all parts from the box and remove all plastic coverings.
- 3. Place the Glass Shades (G) over the socket and secure in place with the Socket Rings (H).
- 4. Determine the desired hanging height, feed the fixture wires through the Pipes with Nipples (F) and the Canopy Assembly (E), tighten the Pipes (F) to fixture body and the Canopy Assembly (E).
- Attached the Mounting Plate (B) to the outlet box using the Outlet Box Screws (C). Ensure the side of the Mounting Plate (B) marked "GND" is facing out.
- 6. While holding the fixture, connect the black wire from fixture to the hot wire (usually black or smooth) from the outlet box using a wire connector (A). Connect the white wire from fixture to the neutral wire (usually white or ribbed) from the outlet box using a wire connector (A). DO NOT REVERSE THE HOT AND NEUTRAL WIRE CONNECTIONS; OTHERWISE, SAFETY WILL BE COMPROMISED.
- 7. If the outlet box has a ground wire (green or bare copper), connect the green ground wire from the fixture to it using a wire connector (A). If the outlet box does not have a ground wire, connect the green ground wire from the fixture to the green ground screw provided on the Mounting Plate (B).
- Tuck these wire connections neatly into the outlet box, place the Canopy
 (E) over the Mounting Plate (B), secure the canopy with the Mounting Screws (D).
- Install the proper light bulb (not included) in accordance with the fixture's specifications (DO NOT EXCEED THE SPECIFIED WATTAGE RATING).
- 10. Installation is completed. Turn on the power at the circuit breaker or fuse box. Turn the light switch to activate the fixture.


care instructions:


Wipe all surfaces with a soft, dry cloth. Do not use any harsh cleaners (including ammonia-based products) or abrasives on our lamp, as they will damage the finish.

$\underset{\mathrm{vourhome}}{ARHAUS}^{*}$

parts enclosed:

ITEM	DIAGRAM	DESCRIPTION	QTY
(A)	888	Wire Connectors	3
(B)		Mounting Plate with Green Ground Screw	1
(C)	=	Outlet Box Screws	2
(D)	6m 6m 6m	Mounting Screws	3
(E)	(-)	Canopy Assembly	1
(F)	4x 🖘 4x 🖘	Pipe with Nipple	4*18" 4*12" 4*6"
(G)		Glass Shade	5
(H)		Socket Ring	5
(1)		Bulb (not included)	5
(J)		Upper Pivot Joint	1
(K)		Lower Pivot Joint	1
(L)	<i>B</i> -	Handle	1





to assemble to slopped ceiling:

- Shut off power at the outlet box where the fixture will be installed.
- 2. Carefully remove all parts from the box and remove all plastic coverings.
- 3. Place the Glass Shades (G) over the socket and secure in place with the Socket Rings (H).
- Determine the desired hanging height, feed the fixture wires through the Pipes with Nipples (F) and the Canopy Assembly (E), tighten the Pipes (F) to fixture body.
- 5. Screw the Lower Pivot Joint (K) to the Pipe (F), refer to Fig.2.
- 6. Screw the Upper Pivot Joint (J) to the Canopy (E), refer to Fig.1.
- 7. Attach the Upper Pivot Joint (J) to the Lower Pivot Joint (K), tighten with the Handle (L), refer to Fig.3.
- Attach the Mounting Plate (B) to the outlet box using the Outlet Box Screws (C). Ensure the side of the Mounting Plate (B) marked "GND" is facing out.
- 9. While holding the fixture, connect the black wire from fixture to the hot wire (usually black or smooth) from the outlet box using a wire connector (A). Connect the white wire from fixture to the neutral wire (usually white or ribbed) from the outlet box using a wire connector (A). DO NOT REVERSE THE HOT AND NEUTRAL WIRE CONNECTIONS; OTHERWISE, SAFETY WILL BE COMPROMISED.
- 10. If the outlet box has a ground wire (green or bare copper), connect the green ground wire from the fixture to it using a wire connector (A). If the outlet box does not have a ground wire, connect the green ground wire from the fixture to the green ground screw provided on the Mounting Plate (B).
- Tuck these wire connections neatly into the outlet box, place the Canopy (E) over the Mounting Plate (B), secure the canopy with the Mounting Screws (D).
- Install the proper light bulb (not included) in accordance with the fixture's specifications (DO NOT EXCEED THE SPECIFIED WATTAGE RATING).
- 13. Installation is completed. Turn on the power at the circuit breaker or fuse box. Turn the light switch to activate the fixture.

ARHAUS

OAKLEY-WOOD LAMP BASE


your home

Parts Enclosed:

A. FINIAL - 1 Pc.

B. HARP - 1 Pc.

C. SADDLE - 1 Pc.



Important Safety Instructions:

1. To avoid risk of fire, DO NOT exceed the recommended Wattage for this Fixture.

UL NO: E492403, UL RATING: DRY, BULB WATTAGE- 150 W CONVERSION TO MAX 35 W SBCFL OR 28 W SBLED BULB: 2x TYPE A (NOT INCLUDED)

Warnings:

- 1. DO NOT Remove the lamp from its packaging by pulling on the power cord/ wire, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. DO NOT touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

To Assemble:


- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Attach Harp (B) to the Saddle (C).
- 4. Unscrew Finial (A) & place Shade on Harp (B) and tighten Finial (A) to harp (B).
- 5. Restore power to the circuit breaker and test lamp fixture.

Care Instructions:



PARTS ENCLOSED:

- (A)Mounting Plate (1)
- (B)Canopy (1)
- (C)Ring (1)
- (D)Allen Key (1)
- (E)Mounting Plate Loop (1)
- (F)Plastic Wire Connector (3)
- (G)Green Ground Screw (1)
- (H)Mounting Screw (2)
- (I)Loop (1)
- (J)Upper Chain Link (1)
- (K)Lower Chain Link (1)
- (L)Shade (2)
- (M)Socket Ring (2)
- (N)Bulb (2)
- (0)Rod(1)



IMPORTANT SAFETY INSTRUCTIONS:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

WARNINGS:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

TO ASSEMBLE:

- 1. Shut off the main electrical supply from the main fuse box/circuit breaker.
- 2. Carefully unpack all fixture parts and hardware. Lay items out on a clear workspace.
- 3. Attach the ground wire from the fixture to the ground junction box wire from the outlet box (Usually green or bare wire). Or wrap the fixture's ground wire around Green ground screw (G), and then fix the green ground screw into the Mounting plate (A).
- 4. Connect the hot wire to the hot junction box wire (usually black or smooth) with a plastic wire connector (F) and wrap the connection with electrical tape. Connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a Plastic wire connector (F) and wrap the connection with electrical tape.
- 5. Attach the Mounting plate (A) to the outlet box using the Mounting screws (F). Tighten with a screwdriver.
- 6. Attach the Canopy (B) to the Mounting plate (A) using the Ring (C) and tighten it.
- 7. Connect the Loop (I) and the lower Chain link (K). Connect the Mounting plate loop (E) and the upper Chain link (J).
- 8. Fasten the Rod (D) to the Loop (I) and tighten with the Allen Key (D) provided
- 9. Attach the Shade (L) to the socket and tighten with the Socket Ring (M).
- 10. Insert the bulbs (N) into the sockets.
- 11. Restore power to the junction box and test lamp fixture.
- 12. Installation is complete.


CARE INSTRURCTIONS:

- 1. Wipe clean using a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals and abrasives to clean light fixture as they may damage the finish.



PARTS ENCLOSED:

- (A) Shade (1)
- (B) Base (1)
- (C) Ring (1)
- (D) Post (1)
- (E) Allen key (1)
- (F) Bulb (1)
- (G) Switch (1)



IMPORTANT SAFETY INSTRUCTIONS:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

WARNINGS:


- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

TO ASSEMBLE:

- 1. Carefully unpack all parts from the box and remove all covering from the packaging.
- 2. Fasten the Post (D) to the Base (B) and tighten with the Allen Key (E) provided.
- 3. Attach the Shade (A) to the socket and tighten with the Ring (C).
- 4. Insert the bulb (F) into the socket.
- 5. Plug into the electrical outlet and turn on the switch (G).
- 6. Assembly is complete.

CARE INSTRURCTIONS:

- 1. Wipe clean using a soft,dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals and abrasives to clean light fixture as they may damage the finish.



PARTS ENCLOSED:

- (A) Shade (1) (B) Ba ≈ (1) (C) Ring (1) (D) Post (1)

- (E) Alley key (1)
- (F) Bulb (1)
- (G) Switch (1)

IMPORTANT SAFETY INSTRUCTIONS:
The following instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your light fixture.

WE RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN. This fixture has been rated for up to (1) 75-watt maximum TYPE A bulb. To avoid the risk of fire, do not exceed the recommended wattage.

WARNINGS:

All wires are connected. When unpacking, be careful not to pull wires as a bad connection might result. Do not connect to electricity until your light fixture is fully assembled.

To reduce the risk of fire, electrical shock, or personal injury, always turn offlight facture and allow it to cool prior to replacing light bulb(s).

This light fluture may contain lead, a chemical know to the State of California to cause cancer, birth defects and other reproductive harm. Wash hands after installing, handling, deaning or otherwise touching this light fixture.

TO ASSEMBLE:

- 1. Carefully unpack all parts from the box and remove all covering/packaging.
- 2. Fasten the Post (D)to the Base (B) and tighten with the Allen Key (E)provided.
- 3. Attach the Shade (A) to the socket and tighten with the Ring (C).
- 4. Insert the 9 watt LED bulb (F) into the socket.
- 5. Plug into the electrical outlet and turn on the switch (G).
- 6. Assembly is complete.

RECOMMENDED CARE

Wipe clean using a soft, dry cloth or static duster. Always a void the use of harsh chemicals and abrasives to clean light fixture as they may damage the fnish.




This Product is Listed to applicable UL Standard and requirements by UL.



parts enclosed:

ITEM	DIAGRAM	DESCRIPTION	QTY
(A)		Screw	2
(B)	200	Wire connectors	3
(C)	(>'50 ≟'()	Mounting plate & green ground	1
(D)	©= ©=	Screw, #8-32	2
(E)		CANOPY	1
(F)		SOCKET	1
(G)		Bulb (Not included)	1
(H)		Tool	1



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the junction box where the lamp will be installed.
- 3. Install Mounting plate (C) to the Junction box with Screw (A).
- Pull the ground wire from ceiling outlet box, and attach ground wire (usually green of bare wire) from ceiling box to ground wire on Mounting Plate (C) with a screw.
- 5. Attach positive wire from ceiling (usually black or smooth) to positive wire on fixture with a Wire Connector (B) and wrap this connector with electrical tape.
- 6. Attach neutral wire from ceiling box (usually white or ribbed) with neutral wire on the fixture with a Wire Connector (B), and wrap this connector with electrical tape.
- 7. Install Canopy (E) with Mounting plate (C) by use Screw(D).
- 8. Insert the light bulb (I).
- 9. Restore power to the junction box and test ceiling light fixture.
- 10. Use Tool (H) to unlock the screw and adjust the wire length.

care instructions:

Do not use polishes or cleaners on your pendant.

WIPE WITH A CLEAN SOFT CLOTH




your home

OLIVER FLOOR LAMP

parts enclosed:

A. Finial (1) B. Shade (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE:2x40W CONVERSION TO MAX LED WATTAGE: 12 W BULB: 2 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Unscrew finial (A) place shade on lamp body (C) tighten finial (A) lamp body (C).
- 4. Restore power to the circuit breaker and test lamp fixture.

care instructions:




your home

OLIVER TABLE LAMP

parts enclosed:

A. Finial (1) B. Shade (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE:2x40W CONVERSION TO MAX LED WATTAGE: 12 W BULB: 2 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Unscrew finial (A) place shade on lamp body (C) tighten finial (A) lamp body (C).
- 4. Restore power to the circuit breaker and test lamp fixture.

care instructions:




OMBRA NATURAL TABLE LAMP

your home

parts enclosed:

A. Finial (1)

B. Shade (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Unscrew finial (A) place shade (B) on harp (C) and tighten finial (A) to harp (C).
- 4. Restore power to the circuit breaker and test lamp fixture.

care instructions:




OMBRA WHITE TABLE LAMP

your home

parts enclosed:

A. Finial (1)B. Shade (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W

BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Unscrew finial (A) place shade (B) on harp (C) and tighten finial (A) to harp (C).
- 4. Restore power to the circuit breaker and test lamp fixture.


care instructions:

Do not use polishes or cleaners on your lamp. Just wipe with soft, lint free cloth.

sour home

parts enclosed:

1700	OUTCOM	DESCRIPTION -	917
XA),		Sound manifing plats & green ground	į
(0).	=	Scree	2
(0)	••	Hex nux	-2
(t))	\odot	Сапору	Ţ
(<u>F</u>)	00	Cylinder ous	2
Œ	=	Mounting Scree	2
(6)	888	Tire connector	3
(8)		Speket	Ţ
Œ	0	Bulb (Not Included)	ĭ



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- To avoid the risk of fire, do not exceed the recommended wattage for this focure.

warnings:

- Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on or look directly at lif bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the junction box where the lamp will be installed.
- Pull the ground wire from ceiling outlet box, and attach ground wire (usually green of bare wire) from ceiling box to ground wire on Mounting. Plate (A) with a screw.
- Attach positive wire from ceiling (usually black or smooth) to positive wire on fixture with a Wire Connector (G) and wrap this connector with electrical tape.
- Attach neutral wire from ceiling box (usually white or ribbed) with neutral wire on the fixture with a Wire Connector (G), and wrap this connector with electrical tape.
- 6. Install Canopy (D) with Mounting plate (A) by use Cylinder nuts (E).
- 7. Install the bulb (I),

care instructions:


Do not use polishes or cleaners on your pendant.

WIPE WITH A CLEAN SOFT CLOTH



parts enclosed:

ITEM	DIAGRAM	DESCRIPTION	QTY
(A)	888	Wire Connectors	3
(B)		Mounting plate & green ground screw	1
(C)	8	Mounting Screw	2
(D)	*	Canopy Screw	3
(E)		Canopy	1
(F)		Pipe	4*6" 4*12" 4*18"
(G)		Socket	1
(H)		Glass Shade	1
(1)		Socket Collar	1
(J)		Light bulb (not included)	1



care instructions:

Wipe all surfaces with a soft, dry cloth. Do not use any harsh cleaners (including ammonia-based products) or abrasives on the fixture as they will damage the surface.

important safety instructions: CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT BRANCH CIRCUIT CONDUCTOR.

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommended wattage of one 60-watt Type A, T, or G incandescent bulb for this fixture.

warnings:

- 1. All wires are connected. Do not remove the fixture from packaging by pulling on the wires as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- Carefully remove all parts from the box and remove all protective coverings. Take care not to lose any small parts.
- Turn OFF power at the outlet box where the fixture will be installed.
- 3. Determine desired hanging height, feed the wires though Pipes (F) and Canopy (E).
- Attach the Mounting Plate (B) to outlet box using the Mounting Screws (C), tighten with a screwdriver. Ensure the side of the Mounting Plate (B) marked "GND" is facing out.
- 5. While holding the fixture, connect the black wire from fixture to the hot wire (usually black or smooth) from the outlet box using a wire connector (A). Connect the white wire from fixture to the neutral wire (usually white or ribbed) from the outlet box using a wire connector (A). DO NOT REVERSE THE HOT AND NEUTRAL WIRE CONNECTIONS; OTHERWISE, SAFETY WILL BE COMPROMISED.
- 6. If the outlet box has a ground wire (green or bare copper), connect the green ground wire from the fixture to it using a wire connector (A). If the outlet box does not have a ground wire, connect the green ground wire from the fixture to the green ground screw provided on the Mounting Plate (A).
- 7. Tuck these wire connections neatly into the outlet box, raise the Canopy (E) over Mounting Plate (B) and align the holes on the Canopy (E) with the corresponding holes on the Mounting Plate (B), secure the Canopy (E) with Canopy Screws (D) until the fixture is secured to the ceiling.
- 8. Place the Glass Shade (H) over Socket (G) and secure by screwing Socket Collar (I).
- Install the proper light bulb (not included) in accordance with the fixture's specifications (DO NOT EXCEED THE SPECIFIED WATTAGE RATING).
- Installation is completed. Turn on the power at the circuit breaker or fuse box. Turn the light switch to activate the fixture.

PALLADIAN SCONCE LARGE



parts enclosed:

Sconce body (1)


T8 LED Bulb (1)

Finial (1)

Washer (3)

Mounting screw (4)

Wiring nut (3)



important safety instructions:

- 1. Installation by a licensed electrician is strongly recommended.
- 2. Turn off circuit breakers and power supply to the fixture. Failure to disconnect power supply prior to installation may result in serious injury.

warnings:

All wires are connected. When unpacking, be careful not to pull wires, as a bad connection may result.

to assemble:

- 1. Connect bare ground wire from fixture to bare ground wire from outlet box using wire connector (A).
- 2. Attach mounting plate (B) to J-Box using screws (C).
- 3. Attach wall plate (D) to mounting plate (B) and secure with screw (F) and washer (E) .
- 4. Insert bulb (G) into the socket (H).
- 5. Place top plate (I) onto threaded rod (L) and secure with washer (J) and finial (K).
- 6. Assembly is complete.

care instructions:

Wipe with a clean, dry cloth. Do not use acid or corrosive liquid to clean the lamp.

PALLADIAN SCONCE SMALL



parts enclosed:

Sconce body (1)


T9 LED Bulb (1)

Finial (1)

Washer (3)

Mounting screw (4)

Wiring nut (3)



important safety instructions:

- 1. Installation by a licensed electrician is strongly recommended.
- 2. Turn off circuit breakers and power supply to the fixture. Failure to disconnect power supply prior to installation may result in serious injury.

warnings:

All wires are connected. When unpacking, be careful not to pull wires, as a bad connection may result.

to assemble:

- 1. Connect bare ground wire from fixture to bare ground wire from outlet box using wire connector (A).
- 2. Attach mounting plate (B) to J-Box using screws (C).
- 3. Attach wall plate (D) to mounting plate (B) and secure with screw (F) and washer (E) .
- 4. Insert bulb (G) into the socket (H).
- 5. Place top plate (I) onto threaded rod (L) and secure with washer (J) and finial (K).
- 6. Assembly is complete.

care instructions:

Wipe with a clean, dry cloth. Do not use acid or corrosive liquid to clean the lamp.


Paloma 3-Arm Floor Lamp 66594L218

ARHAUS

your home

Parts enclosed:

Α	Locking Ring	3
В	Lamp Shade	3
D	Lamp Arm	1
Е	Screw	1
F	Lamp Body Tube	1
G	Lamp Base	1
Н	Flat Washer	1
I	Ribbed Washer	1
J	Hex Nut	1
K	Wrench	1



important safety instructions:

- 1. To avoid the risk of fire, do not exceed the recommended wattage.
- 2. This portable lamp has a polarized plug as a safety feature to reduce the risk of electric shock (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

warnings:

- 1. Do not remove the lamp from packaging by pulling on the power cord as a bad connection or damage may result.
- 2. To reduce the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch the bulbs when the lamp is turned on or look directly at lit bulbs.
- 4. Keep flammable materials away from lit bulbs.
- 5. Remove the clear shade cover prior to use.
- 6. This portable lamp is meant for indoor use, dry locations only.
- 7. This lamp has been rated for up to three (3) 40-Watt maximum Type A standard medium base incandescent light bulb (not included) or three (3) 9-watt compact fluorescent light bulb (not included) or three (3) 6-Watt LED light bulb (not included).
- 8. Remove the silica gel pack from the socket before plugging the lamp in.
- 9. Save these instructions.

To assemble:

- 1 Unpack all the parts from carton carefully.
- 2 Insert the Lamp Body Tube (F) into the hole at the Round Base (G).
- 3 Attach the Flat Washer (H) and then the Ribbed Washer (I) to the bottom end of the Lamp Body Tube (F) and secure the Lamp Body Tube (F) to the Round Base (G) with the Hex Nut (J) by using the Wrench (K) provided. It is important to ensure the Lamp Body Tube (F) is fully inserted into the Round Base (G), and that the Hex Nut (J) is tightened securely so that the lamp body remains straight.
- 4 Insert the Arm Section (D) into Lamp Body Tube (F). Make sure the screw hole on the Arm Section (D) is aligned with the screw hole on the Lamp Body Tube (F). Then secure it by tightening the Screw (E).
- 5 Place the Shades (B) onto the Lamp Socket (C), and then secure it with the Locking Ring (A).
- 6 Insert three (3) 40-Watt MAXIMUM TYPE A standard incandescent light bulbs (not included) or three (3) 9-Watt MAXIMUM compact fluorescent light bulbs (not included) or three (3) 6-Watt MAXIMUM LED light bulbs into the socket (not included). DO NOT EXCEED SPECIFIED WATTAGE.

ARHAUS

Paloma 3-Arm Floor Lamp 66594L218

your home

- 7 Remove the protective plastic from the electrical plug.
- 8 Plug the lamp into proper electrical outlet and test this lamp.

Care instructions:

- 1. Wipe clean with a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to lamp finish.

Made in China


Paloma Large Chandelier 66594H622

ARHAUS

your home

parts enclosed:

Α	Wire Connector	3
В	Mounting Bracket	1
С	Mounting Screw	2
D	Ground Screw	1
Е	Canopy	1
F	Hex Nut	2
G	Nipple	1
Н	Lock Washer	1
I	Screw Collar Loop	1
J	Threaded Ring	1
K	Chain	1
L	Fixture Loop	1
M	Quick Link	2



caution:

BEFORE INSTALLING THIS FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

important safety instructions:

- WE RECOMMEND INSTALLATION BY A LICENSED FLECTRICIAN.
- 2. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- This fixture is meant for indoor use, DRY LOCATIONS ONLY.
- Do not use the electric cord to support the weight of the fixture.
- 5. These instructions are provided for your safety. It is important that they are read carefully and completely before beginning the installation of this lighting fixture.
- 6. For your safety, it is strongly recommended that two people install the lighting fixture.
- 7. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- Save these instructions.

warnings:

- Do not remove the fixture from the packaging by pulling on the power cord as a bad connection or damage may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off the fixture and allow it to cool prior to replacing the light bulbs.
- 3. Do not touch the bulb when the fixture is turned on. Do not look directly at lit bulb.
- 4. Keep flammable materials away from lit bulbs.

to assemble:

Remove all the parts and hardware from the box along with any plastic protective packaging. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 2. Attach the Mounting Bracket (B) onto the Ceiling Outlet Box using Mounting Screws (C). Tighten the screws with a screwdriver until secure.
- 3. Attach one Hex Nut (F) to the top, and the other Hex Nut (F) to the bottom of the Nipple (G). Put the Lock Washer (H) in before attaching the Screw Collar Loop (I) to the bottom end of the Nipple (G).
- 4. Thread the Nipple (G) to the Mounting Bracket (B) and secure it with the Hex Nut (F), exposing approximately 2" of its thread.
- 5. Pull out the fixtures wire power cord and the bare copper ground wire woven through the Chain (K).
- 6. Slide the Canopy (E) and the Threaded Ring (J) up the Chain (K).

Paloma Large Chandelier 66594H622



your home

- 7. Connect Chain (K) to the Fixture Loop (L) and hang to the Screw Collar Loop (I) by using the Quick Link (M). Close the opening of the Quick Link (M) by screwing the nut clockwise.
- 8. Gently pull existing ground, hot, and neutral junction box wires down from the ceiling junction box and allow these to hang.
- Carefully inspect the fixture wires on the chandelier.
 The neutral fixture wire is ribbed. The hot fixture wire is smooth, and the ground fixture wire is bare copper.
- 10. Attach the ground wire from the fixture to the ground junction box wire. It usually has green insulation around it or is bare. Fasten these together with a Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. If the ceiling outlet junction box does not have a ground junction box wire, insert the Ground Screw (D) into the Mounting Bracket (B) where it is marked "Ground" facing down, and wrap the ground wire from the fixture around the Ground Screw (D). Tighten the Ground Screw (D) to clamp the ground fixture wire between the head of Ground Screw (D) and Mounting Bracket (B). IT IS IMPERATIVE THAT THE CEILING OUTLET JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED!
- 11. Connect the neutral fixture wire to the neutral junction box wire. It usually has white insulation around it. Fasten these together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed.
- 12. Connect the hot fixture wire to the hot junction box wire. It usually has black insulation around it. Fasten these together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. Do not reverse the hot and neutral connections or safety will be compromised.
- 13. Gently tuck the wire connections neatly into the ceiling outlet junction box.
- 14. Place the Canopy (E) over the ceiling outlet junction box and secure it in place by screwing the Threaded Ring (J) onto the Screw Collar Loop (I).
- 15. Insert Three (3) 60-Watt maximum Type A incandescent light bulbs (not included), or Three (3) 13-watt maximum compact fluorescent light bulbs (not included), or Three (3) 9-watt maximum LED light bulbs (not included) into the socket. DO NOT EXCEED SPECIFIED WATTAGE.
- 16. Restore power to junction box and test the fixture.
- 17. Installation is now completed.

- 1. Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the chandelier finish



PARTS ENCLOSED ITEMS DIAGRAM DESCRIPTION QTY. (A) Junction Box(Not 1 included) (B) **Mounting Screws** 8 (C) **Ceiling Plate** 1 (D1) 1 Canopy (D2)Hang straight 1 **Bolts** 2 (D3) 1 (E1)**Quick Link** 1 (E2)Chain **Quick Link** 1 (E3)1 (F) **Body** (F4) B **Glass Drop Spares 10** (G) **Bulbs+Spares** 5+2 Wire Nuts (H) 3 E1 F2 E3 -F1 G

IMPORTANT SAFETY INSTRUCTIONS:

PROFESSIONAL INSTALLATION RECOMMENDED

- 1. Use an authorized and certified electrician for consultation and installation.
- 2. This fixture has been rated for five (5) 25watt maximum E12 Incandescent bulbs.
- 3. To avoid the risk of fire, do not exceed the recommended wattage.
- 4. The manufacturer and distributor accepts no liability for incorrect installation.
- 5. For indoor use only
- 6. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your lamp is fully assembled and installed.
- 2. All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

Height: 72.5 cm (28.54in) Diameter: 45.0 cm (17.7in) Weight: 15.20 kg (33.51lbS) Grounded / Hardwired

TO ASSEMBLE:

- 1. Carefully remove all parts from the box and remove all plastic covering.
- 2. Turn OFF power to junction box where the ceiling light will be installed.
- 3. Attach the ceiling plate (C) to the ceiling with mounting screws (B). Please reinforce your ceiling as necessary.

 4. Wind the main wire along with the chain (E2), come out from the canopy (D1).
- 5. Connect the ground wire from the fixture to the ground junction box wire (usually the green or bare wire) with a plastic nut (H) and wrap the connection with electrical tape. Connect the hot wire to the junction box wire (usually black or smooth) with a plastic wire nut (H) and wrap the connection with electrical tape. connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a plastic wire nut (H) and wrap the connection with electrical tape.
- 6. Loosen the bolts (F2) from the body (F) and remove the cover frame (F3) from the
- Fasten lightbulb (D) to lampholder.
- 8. Attach the cover frame (F3) back to the body (F) with bolts (F2).
- Attach the body to the ceiling plate (C) with quick link (E1 & E3) and chain (E2).
 Move the canopy (D1) up to the ceiling plate, then fasten the bolts (D3)
 Restore power to the junction box and test the ceiling light fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth solution. Do not use corrosive cleaners.



PARTS ENCLOSED ITEMS DIAGRAM DESCRIPTION QTY. (A) **Body** 1 (A1) **Glass Drop Spare** 5 (B) **Bulbs+Spare** 3+1В Α

IMPORTANT SAFETY INSTRUCTIONS:

- 1. This fixture has been rated for three (3) 25watt maximum E12 Incandescent bulbs.
- 2. To avoid the risk of fire, do not exceed the recommended wattage.
- 3. The manufacturer and distributor accepts no liability for incorrect installation.
- 4. For indoor use only.
- 5. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your lamp is fully assembled and installed.
- 2. All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Glass & Iron Height: 165.0 cm (65.0in) Diameter: 32.0 cm (12.6in) Weight: 18.7 kg (41.22lbs) Grounded / Hardwired


TO ASSEMBLE:

- Carefully remove all parts from the box and remove all plastic covering.
 Fasten lightbulb (B) to lamp holder.
 Insert plug into socket and test floor lamp fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth. Do not use corrosive cleaners.




PARTS ENCLOSED ITEMS DIAGRAM DESCRIPTION QTY.









IMPORTANT SAFETY INSTRUCTIONS:

- 1. This fixture has been rated for one (1) 25watt maximum E12 Incandescent bulb.
- 2. To avoid the risk of fire, do not exceed the recommended wattage.
- 3. The manufacturer and distributor accepts no liability for incorrect installation.
- 4. For indoor use only.
- 5. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your table lamp is fully assembled and installed.
- 2. All wires are connected. Do not remove the table lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the table lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when $\,$ fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:


General material: Glass & Iron Height: 65.0 cm (25.6in) Diameter: 21.0 cm (8.27in) Weight: 7.45kg (16.42lbs) Grounded / Hardwired

TO ASSEMBLE:

- 1. Carefully remove all parts from the box and remove all plastic covering.
- Fasten lightbulb (B) to lampholder.
 Insert plug into socket and test floor lamp fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth. Do not use corrosive cleaners.

PARTS ENCLOSED ITEMS DIAGRAM DESCRIPTION QTY. Junction Box(Not (A) 1 included) Mounting **(B)** 5 Screws (Not included) **Body** 1 (C)(C3)Glass Drop Spares 2 (D) **Bulb+Spare** 1 + 1**(E)** 3 Wire Nuts



IMPORTANT SAFETY INSTRUCTIONS:

PROFESSIONAL INSTALLATION RECOMMENDED

- 1. Use an authorized and certified electrician for consultation and installation.
- 2. This fixture has been rated for one (1) 25watt maximum E12 Incandescent bulb.
- 3. To avoid the risk of fire, do not exceed the recommended wattage
- The manufacturer and distributor accepts no liability for incorrect installation.
- 5. For indoor use only.
- 6. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your lamp is fully assembled and installed.
- 2. All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Glass & Iron Height: 27.0 cm (10.63in) Lenght: 20.0 cm (7.87in) Width: 10.5 cm (4.13in) Weight: 1.97 kg (4.34lbs) Grounded / Hardwired

TO ASSEMBLE:

- 1. Carefully remove all parts from the box and remove all plastic covering.
- 2. Turn OFF power to junction box where the light will be installed.
- 3. Loosen the bolts (C1) from the body (C) and remove the glass drops (C3) from the bracket (C2).
- 4. Connect the ground wire from the fixture to the ground junction box wire (usually the green or bare wire) with a plastic nut (E) and wrap the connection with electrical tape. Connect the hot wire to the junction box wire (usually black or smooth) with a plastic wire nut (E) and wrap the connection with electrical tape. connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a plastic wire nut (E) and wrap the connection with electrical tape. Attach the wall bracket (C2) to wall with mounting screws (B).
- 5. Attach the wall bracket (C2) to wall with mounting screws (B). Please reinforce your wall as necessary.
- 5.1. There are 2 elongated holes in bracket for mounting light fixture onto the junction box with screws (B1).
- 5.2. There are 3 round holes in brakcet (2 holes in the top and 1 hole in the bottom) for mounting light fixture onto the wall with screws (B2).
- 6. Fasten lightbulb (D) to lampholder.
- 7. Attach the glass drops (C3) to the bracket (C2) with bolts (C1).
- 8. Restore power to the junction box and test the light fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth. Do not use corrosive cleaners.

PARTS ENCLOSED ITEMS DIAGRAM DESCRIPTION QTY. (A) Junction Box(Not 1 included) (B) **Mounting Screws** 8 (C) **Ceiling Plate** 1 (D1) 1 Canopy (D2)Hang straight 1 2 **Bolts** (D3) 1 (E1)**Quick Link** 1 (E2)Chain **Quick Link** 1 (E3)1 **Body** (F) (F4) B **Glass Drop Spares 10** (G) **Bulbs+Spares** 5+2 Wire Nuts (H) 3 omm)±N E1 F2 E3 -F1 G

IMPORTANT SAFETY INSTRUCTIONS:

PROFESSIONAL INSTALLATION RECOMMENDED

- 1. Use an authorized and certified electrician for consultation and installation.
- 2. This fixture has been rated for five (5) 25watt maximum E12 Incandescent bulbs.
- 3. To avoid the risk of fire, do not exceed the recommended wattage
- 4. The ceiling must have at least the capacity of 5 times the weight of the ceiling light. For this light at least a ceiling capacity of 76.0kg (167.55lbs) is required.
- 5. The manufacturer and distributor accepts no liability for incorrect installation.
- 6. For indoor use only
- 7. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your lamp is fully assembled and installed.
- 2. All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:


Height: 72.5 cm (28.54in) Diameter: 45.0 cm (17.7in) Weight: 15.20 kg (33.51lbS) Grounded / Hardwired

TO ASSEMBLE:

- 1. Carefully remove all parts from box. Carefully remove all plastic coverings from glass drops gently to avoid damaging the finish.
- Turn OFF power to junction box where the ceiling light will be installed.
- 3. Attach the ceiling plate (C) to the ceiling with mounting screws (B). Please reinforce your ceiling as necessary.
- . Wind the main wire along with the chain (E2), come out from the canopy (D1).
- 5. Connect the ground wire from the fixture to the ground junction box wire (usually the green or bare wire) with a plastic nut (H) and wrap the connection with electrical tape. Connect the hot wire to the junction box wire (usually black or smooth) with a plastic wire nut (H) and wrap the connection with electrical tape. connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a plastic wire nut (H) and wrap the connection with electrical tape.
- 6. Loosen the bolts (F2) from the body (F) and remove the cover frame (F3) from the body (F)
- Fasten lightbulb (D) to lampholder.
- 8. Attach the cover frame (F3) back to the body (F) with bolts (F2).
 9. Attach the body to the ceiling plate (C) with quick link (E1 & E3) and chain (E2).
- 10. Move the canopy (D1) up to the ceiling plate, then fasten the bolts (D3) 11. Restore power to the junction box and test the ceiling light fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth solution. Do not use corrosive cleaners.





IMPORTANT SAFETY INSTRUCTIONS:

- 1. This fixture has been rated for three (3) 25watt maximum E12 Incandescent bulbs.
- 2. To avoid the risk of fire, do not exceed the recommended wattage.
- 3. The manufacturer and distributor accepts no liability for incorrect installation.
- 4. For indoor use only.
- 5. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your lamp is fully assembled and installed.
- 2. All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Glass & Iron Height: 165.0 cm (65.0in) Diameter: 32.0 cm (12.6in) Weight: 18.7 kg (41.22lbs) Grounded / Hardwired

TO ASSEMBLE:


- 1. Carefully remove all parts from box. Carefully remove all plastic coverings from glass drops gently to avoid damaging the finish.

 2. Fasten lightbulb (B) to lamp holder.
- 3. Insert plug into socket and test floor lamp fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth. Do not use corrosive cleaners.




PARTS ENCLOSED ITEMS DIAGRAM DESCRIPTION QTY.









IMPORTANT SAFETY INSTRUCTIONS:

- 1. This fixture has been rated for one (1) 25watt maximum E12 Incandescent bulb.
- 2. To avoid the risk of fire, do not exceed the recommended wattage.
- 3. The manufacturer and distributor accepts no liability for incorrect installation.
- 4. For indoor use only.
- 5. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your table lamp is fully assembled and installed.
- 2. All wires are connected. Do not remove the table lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the table lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Glass & Iron Height: 65.0 cm (25.6in) Diameter: 21.0 cm (8.27in) Weight: 7.45kg (16.42lbs)

Grounded / Hardwired


TO ASSEMBLE:

- 1. Carefully remove all parts from box. Carefully remove all plastic coverings from glass drops gently to avoid damaging the finish.
- Fasten lightbulb (B) to lampholder.
 Insert plug into socket and test floor lamp fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth. Do not use corrosive cleaners.



PARTS ENCLOSED ITEMS DIAGRAM DESCRIPTION QTY. Junction Box(Not (A) 1 included) Mounting **(B)** 5 Screws (Not included) **Body** 1 (C)(C3)Glass Drop Spares 2 (D) **Bulb+Spare** 1 + 1**(E)** 3 Wire Nuts



IMPORTANT SAFETY INSTRUCTIONS:

PROFESSIONAL INSTALLATION RECOMMENDED

- 1. Use an authorized and certified electrician for consultation and installation.
- 2. This fixture has been rated for one (1) 25watt maximum E12 Incandescent bulb.
- 3. To avoid the risk of fire, do not exceed the recommended wattage
- 4. The manufacturer and distributor accepts no liability for incorrect installation.
- 5. For indoor use only.
- 6. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your lamp is fully assembled and installed.
- All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Glass & Iron Height: 27.0 cm (10.63in) Lenght: 20.0 cm (7.87in) Width: 10.5 cm (4.13in) Weight: 1.97 kg (4.34lbs) Grounded / Hardwired

TO ASSEMBLE:

- Carefully remove all parts from box. Carefully remove all plastic coverings from glass drops gently to avoid damaging the finish.
- 2. Turn OFF power to junction box where the light will be installed.
- Loosen the bolts (C1) from the body (C) and remove the glass drops (C3) from the bracket (C2).
- 4. Connect the ground wire from the fixture to the ground junction box wire (usually the green or bare wire) with a plastic nut (E) and wrap the connection with electrical tape. Connect the hot wire to the junction box wire (usually black or smooth) with a plastic wire nut (E) and wrap the connection with electrical tape. connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a plastic wire nut (E) and wrap the connection with electrical tape. Attach the wall bracket (C2) to wall with mounting screws (B).
- Attach the wall bracket (C2) to wall with mounting screws (B). Please reinforce your wall as necessary.
- 5.1. There are 2 elongated holes in bracket for mounting light fixture onto the junction box with screws (B1).
- 5.2. There are 3 round holes in brakcet (2 holes in the top and 1 hole in the bottom) for mounting light fixture onto the wall with screws (B2).
- 6. Fasten lightbulb (D) to lampholder.
- 7. Attach the glass drops (C3) to the bracket (C2) with bolts (C1).
- 8. Restore power to the junction box and test the light fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth. Do not use corrosive cleaners.

PARTS ENCLOSED ITEMS DIAGRAM DESCRIPTION QTY. (A) Junction Box(Not 1 included) (B) **Mounting Screws** 8 (C) **Ceiling Plate** 1 (D1) 1 Canopy (D2)Hang straight 1 2 **Bolts** (D3) 1 (E1)**Quick Link** 1 (E2)Chain **Quick Link** 1 (E3)1 **Body** (F) (F4) B **Glass Drop Spares 10** (G) **Bulbs+Spares** 5+2 Wire Nuts (H) 3 omm)±N E1 F2 E3 -F1 G

IMPORTANT SAFETY INSTRUCTIONS:

PROFESSIONAL INSTALLATION RECOMMENDED

- 1. Use an authorized and certified electrician for consultation and installation.
- 2. This fixture has been rated for five (5) 25watt maximum E12 Incandescent bulbs.
- 3. To avoid the risk of fire, do not exceed the recommended wattage
- 4. The ceiling must have at least the capacity of 5 times the weight of the ceiling light. For this light at least a ceiling capacity of 76.0kg (167.55lbs) is required.
- 5. The manufacturer and distributor accepts no liability for incorrect installation.
- 6. For indoor use only
- 7. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your lamp is fully assembled and installed.
- 2. All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:


Height: 72.5 cm (28.54in) Diameter: 45.0 cm (17.7in) Weight: 15.20 kg (33.51lbS) Grounded / Hardwired

TO ASSEMBLE:

- 1. Carefully remove all parts from box. Carefully remove all plastic coverings from glass drops gently to avoid damaging the finish.
- Turn OFF power to junction box where the ceiling light will be installed.
- 3. Attach the ceiling plate (C) to the ceiling with mounting screws (B). Please reinforce your ceiling as necessary.
- . Wind the main wire along with the chain (E2), come out from the canopy (D1).
- 5. Connect the ground wire from the fixture to the ground junction box wire (usually the green or bare wire) with a plastic nut (H) and wrap the connection with electrical tape. Connect the hot wire to the junction box wire (usually black or smooth) with a plastic wire nut (H) and wrap the connection with electrical tape. connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a plastic wire nut (H) and wrap the connection with electrical tape.
- 6. Loosen the bolts (F2) from the body (F) and remove the cover frame (F3) from the body (F)
- Fasten lightbulb (D) to lampholder.
- 8. Attach the cover frame (F3) back to the body (F) with bolts (F2).
 9. Attach the body to the ceiling plate (C) with quick link (E1 & E3) and chain (E2).
- 10. Move the canopy (D1) up to the ceiling plate, then fasten the bolts (D3) 11. Restore power to the junction box and test the ceiling light fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth solution. Do not use corrosive cleaners.





IMPORTANT SAFETY INSTRUCTIONS:

- 1. This fixture has been rated for three (3) 25watt maximum E12 Incandescent bulbs.
- 2. To avoid the risk of fire, do not exceed the recommended wattage.
- 3. The manufacturer and distributor accepts no liability for incorrect installation.
- 4. For indoor use only.
- 5. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your lamp is fully assembled and installed.
- 2. All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Glass & Iron Height: 165.0 cm (65.0in) Diameter: 32.0 cm (12.6in) Weight: 18.7 kg (41.22lbs) Grounded / Hardwired

TO ASSEMBLE:


- 1. Carefully remove all parts from box. Carefully remove all plastic coverings from glass drops gently to avoid damaging the finish.

 2. Fasten lightbulb (B) to lamp holder.
- 3. Insert plug into socket and test floor lamp fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth. Do not use corrosive cleaners.




PARTS ENCLOSED ITEMS DIAGRAM DESCRIPTION QTY.









IMPORTANT SAFETY INSTRUCTIONS:

- 1. This fixture has been rated for one (1) 25watt maximum E12 Incandescent bulb.
- 2. To avoid the risk of fire, do not exceed the recommended wattage.
- 3. The manufacturer and distributor accepts no liability for incorrect installation.
- 4. For indoor use only.
- 5. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your table lamp is fully assembled and installed.
- 2. All wires are connected. Do not remove the table lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the table lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Glass & Iron Height: 65.0 cm (25.6in) Diameter: 21.0 cm (8.27in) Weight: 7.45kg (16.42lbs)

Grounded / Hardwired


TO ASSEMBLE:

- 1. Carefully remove all parts from box. Carefully remove all plastic coverings from glass drops gently to avoid damaging the finish.
- Fasten lightbulb (B) to lampholder.
 Insert plug into socket and test floor lamp fixture.

- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth. Do not use corrosive cleaners.



PARTS ENCLOSED ITEMS DIAGRAM DESCRIPTION QTY. Junction Box(Not (A) 1 included) Mounting **(B)** 5 Screws (Not included) **Body** 1 (C)(C3)Glass Drop Spares 2 (D) **Bulb+Spare** 1 + 1**(E)** 3 Wire Nuts



IMPORTANT SAFETY INSTRUCTIONS:

PROFESSIONAL INSTALLATION RECOMMENDED

- 1. Use an authorized and certified electrician for consultation and installation.
- 2. This fixture has been rated for one (1) 25watt maximum E12 Incandescent bulb.
- 3. To avoid the risk of fire, do not exceed the recommended wattage
- 4. The manufacturer and distributor accepts no liability for incorrect installation.
- 5. For indoor use only.
- 6. Keep away from children.

Warnings:

- 1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your lamp is fully assembled and installed.
- All wires are connected. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the lamp and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
- 4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Glass & Iron Height: 27.0 cm (10.63in) Lenght: 20.0 cm (7.87in) Width: 10.5 cm (4.13in) Weight: 1.97 kg (4.34lbs) Grounded / Hardwired

TO ASSEMBLE:

- Carefully remove all parts from box. Carefully remove all plastic coverings from glass drops gently to avoid damaging the finish.
- 2. Turn OFF power to junction box where the light will be installed.
- Loosen the bolts (C1) from the body (C) and remove the glass drops (C3) from the bracket (C2).
- 4. Connect the ground wire from the fixture to the ground junction box wire (usually the green or bare wire) with a plastic nut (E) and wrap the connection with electrical tape. Connect the hot wire to the junction box wire (usually black or smooth) with a plastic wire nut (E) and wrap the connection with electrical tape. connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a plastic wire nut (E) and wrap the connection with electrical tape. Attach the wall bracket (C2) to wall with mounting screws (B).
- Attach the wall bracket (C2) to wall with mounting screws (B). Please reinforce your wall as necessary.
- 5.1. There are 2 elongated holes in bracket for mounting light fixture onto the junction box with screws (B1).
- 5.2. There are 3 round holes in brakcet (2 holes in the top and 1 hole in the bottom) for mounting light fixture onto the wall with screws (B2).
- 6. Fasten lightbulb (D) to lampholder.
- 7. Attach the glass drops (C3) to the bracket (C2) with bolts (C1).
- 8. Restore power to the junction box and test the light fixture.


- 1. Make sure that the power is turned off and bulb has cooled before handling.
- 2. Wipe clean with a dry cloth. Do not use corrosive cleaners.

PETRA SHORT TABLE LAMP BASE 662065L613B



parts enclosed:

- (A) Finial (1)
- (B) Harp Top (1)
- (C) Harp (1)
- (D) Harp Caps (2)
- (E) Socket (1)
- (F) Saddle (1)
- (G) Lamp Base (1)
- (H) Shade
- (I) Bulb (not included)



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. This fixture has been rated for up to one (1) 150-Watt max

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Raise the Harp Caps (D) and insert the bottom ends of the Harp (C) into the Saddle (F).
- 2. Lower the Harp Caps (D) until they cover the two-pronged Saddle (F).
- 3. Unscrew the Finial (A) from the Harp Top (B)
- 4. Place the Shade (H) over the Harp (C) making sure the Harp Top (B) extends through the top ring of the Shade (H).
- 5. Secure the Shade (H) by turning the Finial (A) onto the Harp Top (B).
- 6. Insert the specified light bulb into the socket (E). DO NOT EXCEED THE SPECIFIED WATTAGE.


- 1. Wipe clean with a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

PETRA TALL TABLE LAMP BASE 662065L614B



parts enclosed:

- (A) Finial (1)
- (B) Harp Top (1)
- (C) Harp (1)
- (D) Harp Caps (2)
- (E) Socket (1)
- (F) Saddle (1)
- (G) Lamp Base (1)
- (H) Shade
- (I) Bulb (not included)



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. This fixture has been rated for up to one (1) 150-Watt max

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Raise the Harp Caps (D) and insert the bottom ends of the Harp (C) into the Saddle (F).
- 2. Lower the the Harp Caps (D) until they cover the two-pronged Saddle (F).
- 3. Unscrew the Finial (A) from the Harp Top (B)
- 4. Place the Shade (H) over the Harp (C) making sure the Harp Top (B) extends through the top ring of the Shade (H).
- 5. Secure the Shade (H) by turning the Finial (A) onto the Harp Top (B).
- 6. Insert the specified light bulb into the socket (E). DO NOT EXCEED THE SPECIFIED WATTAGE.


- 1. Wipe clean with a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

PETRA X TABLE LAMP BASE 662065L615B



parts enclosed:

- (A) Finial (1)
- (B) Harp Top (1)
- (C) Harp (1)
- (D) Harp Caps (2)
- (E) Socket (1)
- (F) Saddle (1)
- (G) Lamp Base (1)
- (H) Shade
- (I) Bulb (not included)



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. This fixture has been rated for up to one (1) 150-Watt max

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Raise the Harp Caps (D) and insert the bottom ends of the Harp (C) into the Saddle (F).
- 2. Lower the the Harp Caps (D) until they cover the two-pronged Saddle (F).
- 3. Unscrew the Finial (A) from the Harp Top (B)
- 4. Place the Shade (H) over the Harp (C) making sure the Harp Top (B) extends through the top ring of the Shade (H).
- 5. Secure the Shade (H) by turning the Finial (A) onto the Harp Top (B).
- 6. Insert the specified light bulb into the socket (E). DO NOT EXCEED THE SPECIFIED WATTAGE.

- 1. Wipe clean with a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.


Pierce Floor Lamp

ARHAUS

your home

parts enclosed:

Α	Finial	•
В	Lamp Shade	•
С	Harp	•
Е	Washer	•



important safety instructions:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

warnings:

- To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the lamp and allow it to cool prior to replacing bulbs.
- Do not touch the bulbs when the lamp is turned on. Do not look directly at lit bulbs.
- 3. Keep flammable materials away from lit bulbs.
- 4. Remove clear shade cover prior to use.
- This portable lamp is meant for indoor use, dry locations only.
- 6. This lamp has been rated for up to ONE (1) 100-Watt maximum Type A standard medium base incandescent light bulb (not included) or ONE (1) 23-watt compact fluorescent light bulb (not included) or ONE (1) 20-Watt LED light bulb (not included). To avoid the risk of fire, do not exceed the recommended wattage.
- 7. Save these instructions.

to assemble:

- 1. Unpack all parts from carton carefully.
- 2. Insert the Harp (C) into the Saddle (D) and lower the harp caps until they cover the two-pronged Saddle (D).
- 3. Unscrew the Finial (A) from the harp top. Place the Shade (B) over the assembled Harp (C), making sure the harp top extends through the hole at the top of the Lamp Shade.
- 4. Attach the Finial (A) and Washer (E) onto the harp top and tighten to secure the Lamp Shade (B).
- Insert ONE (1) 100-watt maximum TYPE A standard medium base incandescent light bulb (not included), or ONE (1) 23-watt maximum compact fluorescent light bulb (not included), or ONE (1) 20-watt maximum LED light bulb (not included) into the socket.
- 6. Remove Protective Plastic from Electrical Plug.
- 7. Plug the lamp into proper electrical outlet and test this lamp.

- 1. Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the lamp's finish.


PARTS INVENTORY

Super	Product ID	Description	Stat	Collection	Route
Category					
LIGHTING	91594L69F	PIERCE FLOOR LAMP FINIAL IRON FINIAL	А	PT-PIERCE	PART
LIGHTING	91594L69H	PIERCE FLOOR LAMP HARP IRON HARP	A	PT-PIERCE	PART
LIGHTING	91594L69SH	PIERCE FLOOR LAMP SHADE FAUX SILK REPLACEMENT SHADE	A	PT-PIERCE	
LIGHTING	91594L68F	PIERCE TABLE LAMP FINIAL IRON FINIAL	A	PT-PIERCE	PART
LIGHTING	91594L68H	PIERCE TABLE LAMP HARP IRON HARP	А	PT-PIERCE	PART
LIGHTING	91594L68SH	PIERCE TABLE LAMP SHADE FAUX SILK REPLACEMENT SHADE	А	PT-PIERCE	



parts enclosed:

Part	Description	Qty.	Part	Description	Qty.
Α	lock collar	1	Н	cable	1
В	mounting bracket	1	1	naked earth cable	1
C	nipples	3	J	ceiling loop	1
D	canopy	1	K	round plate	1
E	chain	1	L	cover	1
F	open ring	1	M	pinecone knob	1
G	loop	1	N	screws	2



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:


- 1. Carefully remove all parts from the box.
- 2. Remove the mounting bracket (B) from the canopy (D) by loosening the lock collar (A).
- 3. Taking off the open ring (F) and use the dimensions of the fixture as a guide, shorten the chain as needed using a pair of chain pliers.
- 4. Use the open ring (F) to link the chain (E) and the loop (G), then put the cable (H) and naked earth cable (I) through the chain (E) in every 3-4 rings until through the ceiling loop (J).
- 5. Use a screw driver to take down the screw (N) and loosen the other screw, then move the round iron plate (K) aside, then install the bulb on the socket. Then secure the round plate (K) with the screw (N) again. Then install the cover (L) & pinecone knob (M) at the bottom as well.
- 6. INSURE THE ELECTRICITY SUPPLY IS TURNED OFF.
- 7. Affix the mounting bracket (B) on the outlet box.
- 8. Wrap both safety cable with nipples (C), push the cable into the outlet box.
- 9. Attach the canopy (D) to the mounting bracket (B) and secure with lock collar (A).
- 10. Installation is complete, turn on power at fuse or circuit breaker.

care instructions:



parts enclosed:

Part	Description	Qty.	Part	Description	Qty.
Α	lock collar	1	Н	cable	1
В	mounting bracket	1	1	naked earth cable	1
C	nipples	3	J	ceiling loop	1
D	canopy	1	K	round plate	1
E	chain	1	L	cover	1
F	open ring	1	M	pinecone knob	1
G	loop	1	N	screws	2



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box.
- 2. Remove the mounting bracket (B) from the canopy (D) by loosening the lock collar (A).
- 3. Taking off the open ring (F) and use the dimensions of the fixture as a guide, shorten the chain as needed using a pair of chain pliers.
- 4. Use the open ring (F) to link the chain (E) and the loop (G), then put the cable (H) and naked earth cable (I) through the chain (E) in every 3-4 rings until through the ceiling loop (J).
- 5. Use a screw driver to take down the screw (N) and loosen the other screw, then move the round iron plate (K) aside, then install the bulb on the socket. Then secure the round plate (K) with the screw (N) again. Then install the cover (L) & pinecone knob (M) at the bottom as well.
- 6. INSURE THE ELECTRICITY SUPPLY IS TURNED OFF.
- 7. Affix the mounting bracket (B) on the outlet box.
- 8. Wrap both safety cable with nipples (C), push the cable into the outlet box.
- 9. Attach the canopy (D) to the mounting bracket (B) and secure with lock collar (A).
- 10. Installation is complete, turn on power at fuse or circuit breaker.

care instructions:


PARTS INVENTORY

Super	Product ID	Description	Stat	Collection	Route
Category LIGHTING	912036B4PCH	POPPY GOLD 4MM 12 FT CHAIN	A	PT-POPPY	PART
LIGHTING	912030B4PCH	.16" X 12 FT GOLD CHAIN	A	PI-POPPI	PARI
LIGHTING	912036B4PCH6	POPPY GOLD 4MM 6 FT CHAIN	Α	PT-POPPY	PART
LIGITING	312030D II CI 10	.16" X 6 FT GOLD CHAIN	^	1110111	IAKI
LIGHTING	912036B6PCH	POPPY GOLD 6MM 12 FT CHAIN	Α	PT-POPPY	PART
		.24" X 12 FT GOLD CHAIN			
LIGHTING	912036B6PCH6	POPPY GOLD 6MM 6 FT CHAIN	A	PT-POPPY	PART
		.24" X 6 FT GOLD CHAIN			
LIGHTING	912036BPCN	POPPY GOLD CANOPY	Α	PT-POPPY	PART
		4.75" DIAM CANOPY W/ HRDWR			
LIGHTING	912036BPFL	POPPY GOLD LARGE FINIAL	Α	PT-POPPY	PART
		LG BOTTOM PLATE W/ FINIAL			
LIGHTING	912036BPFS	POPPY GOLD SMALL FINIAL	Α	PT-POPPY	PART
		SM BOTTOM PLATE W/ FINIAL			
LIGHTING	912036BPFINT	POPPY TOP DECORATIVE FINIAL	Α	PT-POPPY	PART
		GOLD DECORATIVE TOP FINIAL			



parts enclosed:

Part	Description	Qty.
Α	screw#A	2
В	mounting bracket	1
С	screw#C	2
D	nipples	3



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box.
- 2. Install the bulbs on the sockets.
- 3. Loosen the side screws (C) and take the mounting bracket (B) from the base. Then fix the bracket (B) with screws (A) to the wall.
- 4. INSURE THE ELECTRICITY SUPPLY IS TURNED OFF.
- 5. Connect the 2 power wires (black and white color) with nipples (D) and earth wire according to their colors.
- 6. Attach the base to the bracket (B) and secure with side screws (C) again.
- 7. Installation is complete, turn on power at fuse or circuit breaker.

care instructions:




PORTOBELLO BASE ONLY

your home

parts enclosed:

A. Finial (1)

B. Harp (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Attach harp (B) to the saddle (C).
- 4. Unscrew finial (A) place shade on harp (B) and tighten finial (A) to harp (B).
- 5. Restore power to the circuit breaker and test lamp fixture.


care instructions:

Do not use polishes or cleaners on your lamp. Just wipe with soft, lint free cloth.



PARTS ENCLOSED:

- (A)Mounting Plate (1)
- (B)Canopy (1)
- (C)Ring (1)
- (D)Sleeve (3)
- (E)Safety Cable (3)
- (F)Plastic Wire Connector (3)
- (G)Green Ground Screw (1)
- (H)Mounting Screw (2)
- (I)Knob (16)
- (J)Shade (16)



IMPORTANT SAFETY INSTRUCTIONS:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

WARNINGS:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

TO ASSEMBLE:

- 1. Shut off the main electrical supply from the main fuse box/circuit breaker.
- 2. Carefully unpack all fixture parts and hardware. Lay items out on a clear workspace.
- 3. Determine the desired hanging height of lighting fixture from ceiling. Unscrew the sleeves (D) and retie the Safety Cable (E) with double loop on the desired length. Cut the excessive Safety Cable (E) if no room to store in the Canopy (B). Ensure to cut three Safety Cable (E) the same length otherwise the fixture might not be level.
- 4. Attach the ground wire from the fixture to the ground junction box wire from the outlet box (Usually green or bare wire). Or wrap the fixture's ground wire around Green ground screw (G), and then fix the green ground screw into the Mounting plate (A).
- 5. Connect the hot wire to the hot junction box wire (usually black or smooth) with a plastic wire connector (F) and wrap the connection with electrical tape. Connect the neutral wire to the neutral junction box wire (usually white or ribbed) with a Plastic wire connector (F) and wrap the connection with electrical tape.
- 6. Attach the Mounting plate (A) to the outlet box using the Mounting screws (H). Tighten with a screwdriver.
- 7. Attach the Canopy (B) to the Mounting plate (A) using the Ring (C) and tighten it.
- 8. Insert the 25-watt bulbs (not included) into the sockets.
- 9. Insert the Shade (J) and turn clockwise the Knob (I) until tight.
- 10. Restore power to the junction box and test lamp fixture.
- 11. Installation is complete.


- 1. Wipe clean using a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals and abrasives to clean light fixture as they may damage the finish.

RAMSEY 3-LT CHANDELIER 6610182H623

ARHAUS

parts enclosed:

part	description	QTY
Α	Mounting Bracket	1
В	Compact Splicing Connector	3
С	Canopy	1
Ε	Lampshade	3
F	Threated Collar	3
D	Hanging Rod 18" (450 mm)	1
M	Hanging Rod 12" (300 mm)	3
N	Hanging Rod 6" (150 mm)	1
Q	Allen Key	1
R	Allen Screw	3
S	Serrated Washer	3



important safety instruction:

- **1.** We recommend installation by a licensed electrician.
- **2.** To avoid the risk of fire, do not exceed the recommended Wattage for this fixture.

UL CLASSIFICATION: DRY

BULB WATTAGE MAX 28 WATTS INCANDESCENT/ 6 WATTS LED (BULB NOT INCLUDED)

warnings:

- **1.** Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- **2.** To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it cool prior to replacing light bulb.
- **3.** Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from the lit bulb.

to assemble:

- **1.** SHUT OF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 2. Carefully remove all parts from the box.
- **3.** Assemble the arms using Allen Key (Q), Screws (R) and Serrated Washer (S). (See STEP 1)
- **4.** Determine the desired hanging height of lighting fixture from ceiling and thread the Hanging Rod(s)
- (D, M, and/or N) to light fixture body accordingly. Guide wiring carefully through the Hanging Rod(s) before threading these together. (See STEP 2)
- **5.** Affix the Mounting Bracket (A) onto the Outlet Box. (See STEP 3)
- **6.** Connect the wires using the Compact Splicing Connector. Pull the lever up, insert a conductor (wire) and push the lever back down.
- **7.** Place the Canopy (C) over the ceiling outlet junction box and secure it in place by tightening the 3 Canopy screws.
- **8.** Fix the Lampshades (E) with the appropriate Threaded Collar (F). See STEP 5,6)
- **9.** Install the bulbs (not included) on the socket.


care instructions:

RAMSEY 5-LT CHANDELIER 6610182H624

ARHAUS

parts enclosed:

part	description	QTY
Α	Mounting Bracket	1
В	Compact Splicing Connector	3
С	Canopy	1
E	Lampshade	5
F	Threated Collar	5
D	Hanging Rod 18" (450 mm)	1
М	Hanging Rod 12" (300 mm)	3
N	Hanging Rod 6" (150 mm)	1
Q	Allen Key	1
R	Allen Screw	5
S	Serrated Washer	5



important safety instruction:

- **1.** We recommend installation by a licensed electrician.
- **2.** To avoid the risk of fire, do not exceed the recommended Wattage for this fixture.

UL CLASSIFICATION: DRY

BULB WATTAGE MAX 28 WATTS INCANDESCENT/ 6 WATTS LED (BULB NOT INCLUDED)

warnings:

- **1.** Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- **2.** To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it cool prior to replacing light bulb.
- **3.** Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from the lit bulb.

to assemble:

- 1. SHUT OF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 2. Carefully remove all parts from the box.
- **3.** Assemble the arms using Allen Key (Q), Screws (R) and Serrated Washer (S). (See STEP 1)
- **4.** Determine the desired hanging height of lighting fixture from ceiling and thread the Hanging Rod(s)
- (D, M, and/or N) to light fixture body accordingly. Guide wiring carefully through the Hanging Rod(s) before threading these together. (See STEP 2)
- **5.** Affix the Mounting Bracket (A) onto the Outlet Box. (See STEP 3)
- **6.** Connect the wires using the Compact Splicing Connector. Pull the lever up, insert a conductor (wire) and push the lever back down.
- **7.** Place the Canopy (C) over the ceiling outlet junction box and secure it in place by tightening the 3 Canopy screws.
- **8.** Fix the Lampshades (E) with the appropriate Threaded Collar (F). See STEP 5,6)
- 9. Install the bulbs (not included) on the socket.


care instructions:

RAMSEY 6-LT CHANDELIER 6610182H625

ARHAUS

parts enclosed:

part	description	QTY
Α	Mounting Bracket	1
В	Compact Splicing Connector	3
С	Canopy	1
E	Lampshade	6
F	Threated Collar	6
D	Hanging Rod 18" (450 mm)	1
M	Hanging Rod 12" (300 mm)	3
N	Hanging Rod 6" (150 mm)	1
Q	Allen Key	1
R	Allen Screw	6
S	Serrated Washer	6



Dx1

Mx3

Nx1

important safety instruction:

- **1.** We recommend installation by a licensed electrician.
- **2.** To avoid the risk of fire, do not exceed the recommended Wattage for this fixture.

UL CLASSIFICATION: DRY

BULB WATTAGE MAX 28 WATTS INCANDESCENT/ 6 WATTS LED (BULB NOT INCLUDED)

warnings:

- **1.** Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- **2.** To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it cool prior to replacing light bulb.
- **3.** Do not touch bulb when fixture is turned on or look directly at lit bulb.
- **4.** Keep flammable materials away from the lit bulb.

to assemble:

- **1.** SHUT OF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 2. Carefully remove all parts from the box.
- **3.** Assemble the arms using Allen Key (Q), Screws (R) and Serrated Washer (S). (See STEP 1)
- **4.** Determine the desired hanging height of lighting fixture from ceiling and thread the Hanging Rod(s)
- (D, M, and/or N) to light fixture body accordingly. Guide wiring carefully through the Hanging Rod(s) before threading these together. (See STEP 2)
- **5.** Affix the Mounting Bracket (A) onto the Outlet Box. (See STEP 3)
- **6.** Connect the wires using the Compact Splicing Connector. Pull the lever up, insert a conductor (wire) and push the lever back down.
- **7.** Place the Canopy (C) over the ceiling outlet junction box and secure it in place by tightening the 3 Canopy screws.
- **8.** Fix the Lampshades (E) with the appropriate Threaded Collar (F). See STEP 5,6)
- **9.** Install the bulbs (not included) on the socket.


care instructions:


RAMSEY FLOOR LAMP 6610182H626



parts enclosed:

part	description	qty
Α	Floor Lamp	1
Е	Lampshade	1
F	Threaded Collar	1





important safety instructions:

- 1. We recommend installation by a licensed electrician.
- **2.** To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. UL CLASSIFICATION: DRY BULB WATTAGE MAX 28 WATTS INCANDESCENT/ 6 WATTS LED (BULB NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- **2.** To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- **3.** Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- **1.** Carefully remove all the parts from the box.
- **2.** Unscrew Threaded Collar (F) from the socket of the floor lamp.
- **3.** Fix the Lampshade (E) with the appropriate Threaded Collar (F).
- **4.** Insert one (1) 6-watt maximum LED light bulb (not included) into the socket. Plug the lamp into the proper electrical outlet and test this lamp.


care instructions:

RAMSEY SWING ARM SCONCE 6610182H629



parts enclosed:

part	description	qty		
Α	Mounting Bracket	1		
В	Compact Splicing Connector	3		
С	Back Plate	1		
D	Threaded Cap without hole	1		
Е	Lampshade	1		
F	Threaded Collar	1		
G	Threaded Cap with hole	1		
Н	Additional Cable with Plug	1		



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- **2.** To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. UL CLASSIFICATION: DRY BULB WATTAGE MAX 28 WATTS INCANDESCENT/ 6 WATTS LED (BULB NOT INCLUDED)

warnings:

- **1.** Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- **2.** To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- **3.** Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.
- 5. SHUT OF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER

to assemble:

- **1. To plug-in**. Choose a place nearby a socket.
- 2. Affix the Mounting Bracket (A) onto the Outlet Box.
- **3.** Place the Backplate (C) over the Mounting Bracket and secure it in place by tightening the four Canopy screws.
- **4.To Hardwire:** to transform your wall sconce from plugin to hardwired, loose the connections of the cable on the Compact Splicing Connectors (B).
- **5**. Remove the cable with the socket.
- **6.** Pass the cable through the cap with hole (G).
- **7.** Unscrew the Threaded Cap with hole (G) and replace it with the one without hole. (D)
- **8.** Connect the hot wire on the fixture to the hot outlet box wire (usually black) using the Compact Splicing Connector (B). Pull the lever up, insert a conductor (wire) and push the lever back down.
- **9**. Connect the neutral wire on the fixture to the neutral outlet box wire (usually white) using the Compact Splicing Connector (B). Pull the lever up, insert a conductor (wire) and push the lever back down.
- **10.** Attach the ground wire (silver) from the fixture to the ground junction box wire from the outlet box (usually green) using the Compact Splicing Connector (B). Pull the lever up, insert a conductor (wire) and push the lever back down.
- **11.** Fix the Lampshades (E) with the appropriate Threaded Collar (F).
- **12.** Restore power to the junction box and test the fixture.


care instructions:

RAMSEY TABLE LAMP 6610182H627



parts enclosed:

part	description	qty
Α	Table Lamp	1
Е	Lampshade	1
F	Threaded Collar	1



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- **2.** To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. UL CLASSIFICATION: DRY BULB WATTAGE MAX 28 WATTS INCANDESCENT/ 6 WATTS LED (BULB NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- **2.** To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- **3.** Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- **1.** Carefully remove all the parts from the box.
- **2.** Unscrew Threaded Collar (F) from the socket of the table lamp.
- **3.** Fix the Lampshade (E) with the appropriate Threaded Collar (F).
- **4.** Insert one (1) 6-watt maximum LED light bulb (not included) into the socket. Plug the lamp into the proper electrical outlet and test this lamp.


care instructions:

RAMSEY TABLE LAMP 6610182H627



parts enclosed:

part	description	qty
Α	Table Lamp	1
Е	Lampshade	1
F	Threaded Collar	1



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- **2.** To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. UL CLASSIFICATION: DRY BULB WATTAGE MAX 28 WATTS INCANDESCENT/ 6 WATTS LED (BULB NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- **2.** To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- **3.** Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- **1.** Carefully remove all the parts from the box.
- **2.** Unscrew Threaded Collar (F) from the socket of the table lamp.
- **3.** Fix the Lampshade (E) with the appropriate Threaded Collar (F).
- **4.** Insert one (1) 6-watt maximum LED light bulb (not included) into the socket. Plug the lamp into the proper electrical outlet and test this lamp.


care instructions:

RAMSEY WALL SCONCE 6610182H628



parts enclosed:

part	description	qty
Α	Mounting Bracket	1
В	Compact Splicing Connector	3
С	Backplate	1
Е	Lampshade	1
F	Threaded Collar	1



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- **2**. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. UL CLASSIFICATION: DRY BULB WATTAGE MAX 28 WATTS INCANDESCENT/ 6 WATTS LED (BULB NOT INCLUDED)

warnings:

- **1.** Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- **2.** To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- **3.** Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.
- 5. SHUT OF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER

to assemble:

- **1.** Affix the Mounting Bracket (A) onto the Outlet Box.
- **2.** Connect the hot wire on the fixture to the hot outlet box wire (usually black) using the Compact Splicing Connector (B). Pull the lever up, insert a conductor (wire) and push the lever back down.
- **3**. Connect the neutral wire on the fixture to the neutral outlet box wire (usually white) using the Compact Splicing Connector (B). Pull the lever up, insert a conductor (wire) and push the lever back down.
- **4.** Attach the ground wire (silver) from the fixture to the ground junction box wire from the outlet box (usually green) using the Compact Splicing Connector (B). Pull the lever up, insert a conductor (wire) and push the lever back down.
- **5.** Place the Backplate (C) over the Mounting Bracket and Outlet Box and secure it in place by tightening the three Canopy screws.
- **6.** Fix the Lampshade (E) with the appropriate Threaded Collar (F).
- **7.** Restore power to the junction box and test the fixture.

care instructions:

Currey & Company

WALL SCONCE (A) Assembly and Installation Instructions

CAUTION:

• BEFORE INSTALLING FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

Important Safety Instructions:

- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the installation of this lighting fixture.
- We strongly recommend that a professional electrician install all direct wire fixtures.
- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A
 PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS
 INVOLVED.
- The lighting fixture is meant for indoor use. It must be connected only to 3-wire, single-phase electrical supply systems (provided with Ground wire or equivalent protection system).
- For your safety, it is strongly recommended that two people install the lighting fixture.
- To avoid the risk of fire, do not exceed the recommended lamp wattage.
- The lighting fixture is meant for indoor use, DRY LOCATIONS ONLY.
- Save these instructions.

WARNING:

- To reduce the risk of fire, electrical shock or personal injury, always turn off light fixture and allow it to cool prior to replacing light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.
- This lighting fixture contains lead, a chemical known to the State of California to cause cancer, birth defects
 and other reproductive harm. Wash hands after installing, handling, cleaning or otherwise touching this light
 fixture.

Pre-assembly:

- Remove all parts and hardware from box along with any plastic protective packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.
- For your safety and convenience, assembly by two people is recommended.

Parts and Hardware Included:

- (3) PLASTIC WIRE CONNECTORS (A)
- (1) MOUNTING BRACKET (B)
- (1) GREEN GROUND SCREW (C)
- (2) J-BOX MOUNTING SCREWS (D)
- (2) MOUNTING STUDS (E)
- (1) BACKPLATE (F)
- (2) KNURLED BALL NUTS (G)


TOOLS REQUIRED (not included): Ladder, Phillips Head & Flat Blade Screwdrivers, Pliers, Wire Cutter/Stripper & Electrical Tape.

Assembly Instructions:

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER!
- 2. Carefully unpack all fixture parts and hardware and lay them out on a clear workspace.
- 3. Attach the MOUNTING BRACKET (B) to the ceiling outlet box using the J-BOX MOUNTING SCREWS (C). Align the slots of the MOUTNING BRACKET (B) with the two threaded holes located on the J-Box. Use a screwdriver to tighten each screw until the MOUNTING BRACKET (B) is firmly secured to the J-Box.
- 4. Carefully inspect the wall sconce fixture wires. The NEUTRAL FIXTURE WIRE has FINE LONGITUDINAL RIDGES running along its length. The HOT FIXTURE WIRE is SMOOTH and the bare copper wire is the GROUND WIRE. If you have any doubt and cannot identify the power-supply wires with confidence, then we recommend that you ask an electrician and that you not continue with the installation.
- 5. Gently pull existing wire from the junction box and allow wires to hang. The HOT or LIVE wire is usually black. The NEUTRAL wire is usually white. Check to see if there is a ground wire that is usually green or green with a yellow stripe or exposed copper metal wire. If needed, use a pair of wire strippers to remove about 1/2 inches of insulation from each wire.
- 6. Attach the GROUND WIRE from the fixture to the GROUND JUNCTION BOX WIRE from the outlet junction box (J-box) (usually green insulation or bare wire). Fasten each together with a PLASTIC WIRE CONNECTOR (E) by twisting the connector in a clockwise direction and wrap the connection with electrical tape. Be sure that no wire strands are exposed. If your outlet junction box DOES NOT have a GROUND WIRE, be sure to insert the GREEN GROUND SCREW (B) into the MOUNTING BRACKET (B), marked as "GND", facing downward and wrap the fixture's bare ground wire around the GREEN GROUND SCREW (C). Tighten screw to clamp ground wire between ground screw head and MOUNTING BRACKET (B). IT IS IMPERATIVE THAT THE JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED!
- 7. Connect the NEUTRAL FIXTURE WIRE to the NEUTRAL JUNCTION BOX WIRE (usually white insulation). Fasten each together with a PLASTIC WIRE CONNECTOR (A) by twisting the connector in a clockwise direction and wrap the connection with electrical tape. Be sure that no wire strands are exposed.
- 8. Connect the HOT FIXTURE WIRE to the HOT JUNCTION BOX WIRE (usually black insulation). Fasten each together with a PLASTIC WIRE CONNECTOR (A) by twisting the connector in a clockwise direction and wrap the connection with electrical tape. Be sure that no wire strands are exposed. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED**.
- 9. Check the wiring connections and if all looks good, gently tuck the wire connections neatly into the ceiling outlet junction box.
- 10. Screw the MOUNTING STUDS (E) onto the MOUNTING BRACKET (B).
- 11. Place the BACKPLATE (F) onto MOUNTING STUDS (E) and secure into place using the KNURLED BALL NUTS (G).
- 12. Screw light bulb into the threaded socket and make sure they do not exceed the maximum wattage specified on the fixture's wattage rating level.
- 13. Restore power to ceiling outlet junction box and test fixture.
- 14. Installation is complete.

Care Instructions:

- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.



Note: The drawing of the back plate is for reference only.

www.curreyandcompany.com


Reeded Glass Floor Lamp

ARHAUS

your home

parts enclosed:

Α	Finial	•
В	Lamp Shade	,
С	Harp	



important safety instructions:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

warnings:

- To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the lamp and allow it to cool prior to replacing bulbs.
- Do not touch the bulbs when the lamp is turned on. Do not look directly at lit bulbs.
- 3. Keep flammable materials away from lit bulbs.
- 4. Remove clear shade cover prior to use.
- 5. This portable lamp is meant for indoor use, dry locations only.
- 6. This lamp has been rated for up to one (1) 100-Watt maximum Type A standard medium base incandescent light bulb (not included) or one (1) 23-watt maximum compact fluorescent light bulb (not included) or one (1) 20-Watt maximum LED light bulb (not included). To avoid the risk of fire, do not exceed the recommended wattage.
- 7. Save these instructions.

to assemble:

- Unpack all parts from carton carefully.
- 2. Insert the Harp (C) into the Saddle (D) and lower the harp caps until they cover the two-pronged Saddle (D).
- Unscrew the Finial (A) from the harp top. Place the Lamp Shade (B) over the assembled Harp (C), making sure the harp top extends through the hole at the top of the Lamp Shade (B).
- 4. Attach the Finial (A) onto the harp top and tighten to secure the Lamp Shade (B).
- Insert ONE (1) 100-watt maximum TYPE A standard medium base incandescent light bulb (not included), or ONE (1) 23-watt maximum compact fluorescent light bulb (not included), or ONE (1) 20-watt maximum LED light bulb (not included) into the socket.
- Remove protective plastic from electrical plug (E).
- 7. Plug the lamp into proper electrical outlet and test this lamp.

care instructions:

- Wipe clean with a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the lamp's finish.

Made in China


Reeded Glass Table Lamp

ARHAUS

your home

parts enclosed:

Α	Finial	
В	Lamp Shade	
С	Harp	



important safety instructions:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

warnings:

- 1. To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the lamp and allow it to cool prior to replacing bulbs.
- 2. Do not touch the bulbs when the lamp is turned on. Do not look directly at lit bulbs.
- 3. Keep flammable materials away from lit bulbs.
- 4. Remove clear shade cover prior to use.
- 5. This portable lamp is meant for indoor use, dry locations only.
- 6. This lamp has been rated for up to one (1) 100-watt maximum Type A standard medium base incandescent light bulb (not included) or one (1) 23-watt maximum compact fluorescent light bulb (not included) or one (1) 20-watt maximum LED light bulb (not included). To avoid the risk of fire, do not exceed the recommended wattage.
- 7. Save these instructions.

to assemble:

- 1. Unpack all parts from carton carefully.
- 2. Insert the Harp (C) into the Saddle (D) and lower the harp caps until they cover the two-pronged Saddle (D).
- 3. Unscrew the Finial (A) from the harp top. Place the Lamp Shade (B) over the assembled Harp (C), making sure the harp top extends through the hole at the top of the Lamp Shade (B).
- 4. Attach the Finial (A) onto the harp top and tighten to secure the Lamp Shade (B).
- Insert ONE (1) 100-watt maximum TYPE A standard medium base incandescent light bulb (not included), or ONE (1) 23-watt maximum compact fluorescent light bulb (not included), or ONE (1) 20-watt maximum LED light bulb (not included) into the socket.
- 6. Remove protective plastic from electrical plug (E).
- 7. Plug the lamp into proper electrical outlet and test this lamp.

care instructions:

- 1. Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the lamp's finish.

PARTS INVENTORY

Super	Product ID	Description	Stat	Collection	Route
Category					
LIGHTING	91594L047F	REEDED FLOOR LAMP FINIAL PLATED ORB FINIAL	A	PT-REEDED	PART
LIGHTING	91594L047H	REEDED FLOOR LAMP HARP NICKEL HARP	A	PT-REEDED	PART
LIGHTING	91594L047SH	REEDED FLOOR LAMP SHADE LINEN REPLACEMENT SHADE	A	PT-REEDED	
LIGHTING	91594L048F	REEDED TABLE LAMP FINIAL PLATED ORB FINIAL	A	PT-REEDED	PART
LIGHTING	91594L048H	REEDED TABLE LAMP HARP NICKEL HARP	A	PT-REEDED	PART
LIGHTING	91594L048SH	REEDED TABLE LAMP SHADE LINEN REPLACEMENT SHADE	A	PT-REEDED	




RETRO TRIPOD LAMP

your home

parts enclosed:

- A. Shade (1)
- B. Knob (1)
- C. Lamp (1)
- D. Socket cover (1)
- E. Socket cover ring (1)
- F. Bulb cover (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W

BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Attach shade (A) to the lamp body (C) following the image and tighten knob (B).
- 3. Attach bulb cover (F) to socket cover (D) by following the thread of socket cover ring (E).
- 4. Install lightbulb to the lamp (not included).

care instructions:

Wipe with a soft, dry cloth. Do not use polishes or cleaners on your lamp.

LIGHTING PARTS SKUS

CATEGORY	SKU	DESCRIPTION	STATUS	COLLECTION	ROUTE
LIGHTING	913507L210AB	RETRO TRIPOD BULB COVER	Α	PT-RETRO	PART
		ANTO BRASS INSIDE SM SHADE			



your home

RETRO WHITE FLOOR LAMP

parts enclosed:

A. Shade (1)


B. Knob (1)

C. Lamp (1)

D. Socket cover (1)

E. Socket cover ring (1)

F. Bulb cover (1)



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W

BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Attach shade (A) to the lamp body (C) following the image and tighten knob (B).
- 3. Attach bulb cover (F) to socket cover (D) by following the thread of socket cover ring (E).
- 4. Install light bulb to the lamp (not included).

care instructions:

DO NOT use polishes or Cleaners on your lamp. Wipe with soft, lint free cloth.




RHYS BRASS TABLE LAMP

your home

parts enclosed:

A. Finial (1) B. Harp (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Attach harp (B) to the saddle (C).
- 4. Unscrew finial (A) place shade on harp (B) and tighten finial (A) to harp (B).
- 5. Restore power to the circuit breaker and test lamp fixture.

care instructions:




RHYS BRASS FLOOR LAMP

your home

parts enclosed:

A. Finial (1)B. Harp (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W

BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Attach harp (B) to the saddle (C).
- 4. Unscrew finial (A) place shade on harp (B) and tighten finial (A) to harp (B).
- 5. Restore power to the circuit breaker and test lamp fixture.

care instructions:




RHYS BRASS WALL SCONCE

your home

parts enclosed:

A. Finial (1)B. Harp (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E491659, UL RATING: DRY, MAX BULB WATTAGE: 40 W

CONVERSION TO MAX LED WATTAGE: 12 W

BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the wall sconce be installed.
- 3. Remove back plate from base & fix it onto wall with screws.
- 4. After fixing back plate onto outlet, fix the wall sconce through base & tighten the top nuts.
- 5. Attach harp (B) to the saddle (C).
- 6. Unscrew finial (A) place shade on harp (B) and tighten finial (A) to harp (B).
- 7. Restore power to the circuit breaker and test wall sconce.

care instructions:




RHYS BRONZE FLOOR LAMP

your home

parts enclosed:

A. Finial (1)B. Harp (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W

BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Attach harp (B) to the saddle (C).
- 4. Unscrew finial (A) place shade on harp (B) and tighten finial (A) to harp (B).
- 5. Restore power to the circuit breaker and test lamp fixture.

care instructions:




RHYS BRONZE WALL SCONCE

your home

parts enclosed:

A. Finial (1)B. Harp (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E491659, UL RATING: DRY, MAX BULB WATTAGE: 40 W

CONVERSION TO MAX LED WATTAGE: 12 W

BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the wall sconce be installed.
- 3. Remove back plate from base & fix it onto wall with screws.
- 4. After fixing back plate onto outlet, fix the wall sconce through base & tighten the top nuts.
- 5. Attach harp (B) to the saddle (C).
- 6. Unscrew finial (A) place shade on harp (B) and tighten finial (A) to harp (B).
- 7. Restore power to the circuit breaker and test wall sconce.

care instructions:




RHYS NICKEL FLOOR LAMP

your home

parts enclosed:

A. Finial (1)B. Harp (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Attach harp (B) to the saddle (C).
- 4. Unscrew finial (A) place shade on harp (B) and tighten finial (A) to harp (B).
- 5. Restore power to the circuit breaker and test lamp fixture.

care instructions:




RHYS NICKEL FLOOR LAMP

your home

parts enclosed:

A. Finial (1)B. Harp (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E310644, UL RATING: DRY, MAX BULB WATTAGE: 60 W CONVERSION TO MAX LED WATTAGE: 12 W BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the lamp will be installed.
- 3. Attach harp (B) to the saddle (C).
- 4. Unscrew finial (A) place shade on harp (B) and tighten finial (A) to harp (B).
- 5. Restore power to the circuit breaker and test lamp fixture.

care instructions:




RHYS NICKEL WALL SCONCE

your home

parts enclosed:

A. Finial (1)B. Harp (1)



important safety instructions:

1. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.

UL NO: E491659, UL RATING: DRY, MAX BULB WATTAGE: 40 W

CONVERSION TO MAX LED WATTAGE: 12 W

BULB: 1 X A-19 (NOT INCLUDED)

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box and remove all protective coverings.
- 2. Turn OFF power to the circuit breaker where the wall sconce be installed.
- 3. Remove back plate from base & fix it onto wall with screws.
- 4. After fixing back plate onto outlet, fix the wall sconce through base & tighten the top nuts.
- 5. Attach harp (B) to the saddle (C).
- 6. Unscrew finial (A) place shade on harp (B) and tighten finial (A) to harp (B).
- 7. Restore power to the circuit breaker and test wall sconce.

care instructions:


Rosalind Black Chandelier 66594H560

ARHAUS

your home

parts enclosed:

Α	Wire Connector	3
В	Mounting Bracket	1
С	Mounting Screw	2
D	Ground Screw	1
Ε	Canopy	1
F	Hex Nut	2
G	Nipple	1
Н	Lock Washer	1
I	Screw Collar Loop	1
J	Threaded Ring	1
K	Chain	1
L	Fixture Loop	1
М	Center Rod	1
N	Chandelier Body	1
0	Candle Sleeve	5
Р	Quick link	1



caution:

BEFORE INSTALLING THIS FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. This fixture is meant for indoor use, DRY LOCATIONS ONLY.
- 4. Do not use the electric cord to support the weight of the fixture.
- 5. These instructions are provided for your safety. It is important that they are read carefully and completely before beginning the installation of this lighting fixture.
- 6. For your safety, it is strongly recommended that two people install the lighting fixture.
- 7. Please save these instructions.

warnings:

- Do not remove the fixture from the packaging by pulling on the power cord as a bad connection or damage may result
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off the fixture and allow it to cool prior to replacing the light bulbs.
- 3. Do not touch the bulbs when the fixture is turned on. Do not look directly at lit bulbs.
- 4. Keep flammable materials away from lit bulbs.

to assemble:

Remove all the parts and hardware from the box along with any plastic protective packaging. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- Screw the Center Rod (M) in the bottom of the Chandelier Body (N) and turn clockwise until firmly tightened.
- 3. Attach the Mounting Bracket (B) onto the Ceiling Outlet Box using Mounting Screws (C). Tighten the screws with a screwdriver until secure.
- 4. Attach one Hex Nut (F) to the top, and the other Hex Nut (F) to the bottom of the Nipple (G). Put the Lock Washer (H) in before attaching the Screw Collar Loop (I) to the bottom end of the Nipple (G).
- 5. Thread the Nipple (G) to the Mounting Bracket (B) and secure it with the Hex Nut (F), exposing approximately 2" of its thread.
- 6. Pull out the fixtures wire power cord and the bare copper ground wire woven through the Chain (K).
- 7. Slide the Canopy (E) and the Threaded Ring (J) up the Chain (K).
- 8. Connect Chain (K) to the Screw Collar Loop (I) by using the Quick Link (P). Close the opening of the Quick Link (P) by screwing the nut clockwise.

Rosalind Black Chandelier 66594H560

ARHAUS

your home

- 9. Gently pull existing ground, hot, and neutral junction box wires down from the ceiling junction box and allow these to hang.
- 10. Carefully inspect the fixture wires on the chandelier. The neutral fixture wire is ribbed. The hot fixture wire is smooth, and the ground fixture wire is bare copper.
- 11. Attach the ground wire from the fixture to the ground junction box wire. It usually has green insulation around it or is bare. Fasten these together with a Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. If the ceiling outlet junction box does not have a ground junction box wire, insert the Ground Screw (D) into the Mounting Bracket (B) where it is marked "Ground" facing down, and wrap the ground wire from the fixture around the Ground Screw (D). Tighten the Ground Screw (D) to clamp the ground fixture wire between the head of Ground Screw (D) and Mounting Bracket (B). IT IS IMPERATIVE THAT THE CEILING OUTLET JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED!
- 12. Connect the neutral fixture wire to the neutral junction box wire. It usually has white insulation around it. Fasten these together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed.
- 13. Connect the hot fixture wire to the hot junction box wire. It usually has black insulation around it. Fasten these together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. Do not reverse the hot and neutral connections or safety will be compromised.
- 14. Gently tuck the wire connections neatly into the ceiling outlet junction box.
- 15. Place the Canopy (E) over the ceiling outlet junction box and secure it in place by screwing the Threaded Ring (J) onto the Screw Collar Loop (I).
- 16. Slide the Candle Sleeves (O) over the sockets.
- 17. Insert Five (5) 25-Watt maximum Type B incandescent light bulbs (not included), or Five (5) 6-watt maximum compact fluorescent light bulbs (not included), or Five (5) 4-watt maximum LED light bulbs (not included) into the socket. DO NOT EXCEED SPECIFIED WATTAGE.
- 18. Restore power to junction box and test the fixture.
- 19. Installation is now completed.

care instructions:

- 1. Wipe clean with a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the chandelier finish

Made in China


Rosalind Brass Chandelier 66594H559

ARHAUS

your home

parts enclosed:

Α	Wire Connector	3
В	Mounting Bracket	1
С	Mounting Screw	2
D	Ground Screw	1
Е	Canopy	1
F	Hex Nut	2
G	Nipple	1
Н	Lock Washer	1
I	Screw Collar Loop	1
J	Threaded Ring	1
K	Chain	1
L	Fixture Loop	1
М	Center Rod	1
Ν	Chandelier Body	1
Ο	Candle Sleeve	5
Р	Quick link	1



caution:

BEFORE INSTALLING THIS FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. This fixture is meant for indoor use, DRY LOCATIONS ONLY.
- 4. Do not use the electric cord to support the weight of the fixture.
- 5. These instructions are provided for your safety. It is important that they are read carefully and completely before beginning the installation of this lighting fixture.
- 6. For your safety, it is strongly recommended that two people install the lighting fixture.
- 7. Please save these instructions.

warnings:

- Do not remove the fixture from the packaging by pulling on the power cord as a bad connection or damage may result
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off the fixture and allow it to cool prior to replacing the light bulbs.
- 3. Do not touch the bulbs when the fixture is turned on. Do not look directly at lit bulbs.
- 4. Keep flammable materials away from lit bulbs.

to assemble:

Remove all the parts and hardware from the box along with any plastic protective packaging. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

- 1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- Screw the Center Rod (M) in the bottom of the Chandelier Body (N) and turn clockwise until firmly tightened.
- 3. Attach the Mounting Bracket (B) onto the Ceiling Outlet Box using Mounting Screws (C). Tighten the screws with a screwdriver until secure.
- 4. Attach one Hex Nut (F) to the top, and the other Hex Nut (F) to the bottom of the Nipple (G). Put the Lock Washer (H) in before attaching the Screw Collar Loop (I) to the bottom end of the Nipple (G).
- 5. Thread the Nipple (G) to the Mounting Bracket (B) and secure it with the Hex Nut (F), exposing approximately 2" of its thread.
- 6. Pull out the fixtures wire power cord and the bare copper ground wire woven through the Chain (K).
- 7. Slide the Canopy (E) and the Threaded Ring (J) up the Chain (K).
- 8. Connect Chain (K) to the Screw Collar Loop (I) by using the Quick Link (P). Close the opening of the Quick Link (P) by screwing the nut clockwise.

Rosalind Brass Chandelier 66594H559

ARHAUS

your home

- Gently pull existing ground, hot, and neutral junction box wires down from the ceiling junction box and allow these to hang.
- 10. Carefully inspect the fixture wires on the chandelier. The neutral fixture wire is ribbed. The hot fixture wire is smooth, and the ground fixture wire is bare copper.
- 11. Attach the ground wire from the fixture to the ground junction box wire. It usually has green insulation around it or is bare. Fasten these together with a Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. If the ceiling outlet junction box does not have a ground junction box wire, insert the Ground Screw (D) into the Mounting Bracket (B) where it is marked "Ground" facing down, and wrap the ground wire from the fixture around the Ground Screw (D). Tighten the Ground Screw (D) to clamp the ground fixture wire between the head of Ground Screw (D) and Mounting Bracket (B). IT IS IMPERATIVE THAT THE CEILING OUTLET JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED!
- 12. Connect the neutral fixture wire to the neutral junction box wire. It usually has white insulation around it. Fasten these together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed.
- 13. Connect the hot fixture wire to the hot junction box wire. It usually has black insulation around it. Fasten these together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. Do not reverse the hot and neutral connections or safety will be compromised.
- 14. Gently tuck the wire connections neatly into the ceiling outlet junction box.
- 15. Place the Canopy (E) over the ceiling outlet junction box and secure it in place by screwing the Threaded Ring (J) onto the Screw Collar Loop (I).
- 16. Slide the Candle Sleeves (O) over the sockets.
- 17. Insert Five (5) 25-Watt maximum Type B incandescent light bulbs (not included), or Five (5) 6-watt maximum compact fluorescent light bulbs (not included), or Five (5) 4-watt maximum LED light bulbs (not included) into the socket. DO NOT EXCEED SPECIFIED WATTAGE.
- 18. Restore power to junction box and test the fixture.
- 19. Installation is now completed.

care instructions:

- 1. Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the chandelier finish


Made in China

Rosalind Rattan Black Chandelier 66594H558 ARHAUS

your home

parts enclosed:

Α	Wire Connector	3
В	Mounting Bracket	1
С	Mounting Screw	2
D	Ground Screw	1
E	Canopy	1
F	Hex Nut	2
G	Nipple	1
Н	Lock Washer	1
I	Screw Collar Loop	1
J	Threaded Ring	1
K	Chain	1
L	Fixture Loop	1
M	Center Rod	1
Ν	Chandelier Body	1
0	Candle Sleeve	5
Р	Quick link	1



caution:

BEFORE INSTALLING THIS FIXTURE, MAKE SURE THE POWER TO THE CIRCUIT IS TURNED OFF AT THE MAIN FUSE BOX / CIRCUIT BREAKER UTILITY BOX.

important safety instructions:

- We recommend installation by a licensed electrician.
- To avoid the risk of fire, do not exceed the recommended wattage for this fixture.
- 3. This fixture is meant for indoor use, DRY LOCATIONS ONLY.
- Do not use the electric cord to support the weight of the fixture.
- 5. These instructions are provided for your safety. It is important that they are read carefully and completely before beginning the installation of this lighting fixture.
- For your safety, it is strongly recommended that two 6. people install the lighting fixture.
- 7. Please save these instructions.

warnings:

- Do not remove the fixture from the packaging by pulling on the power cord as a bad connection or damage may
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off the fixture and allow it to cool prior to replacing the light bulbs.
- Do not touch the bulbs when the fixture is turned on. 3. Do not look directly at lit bulbs.
- Keep flammable materials away from lit bulbs. 4.

to assemble:

Remove all the parts and hardware from the box along with any plastic protective packaging. Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.

- SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.
- 2. Screw the Center Rod (M) in the bottom of Chandelier Body (N) and turn clockwise until firmly tightened.
- 3. Attach the Mounting Bracket (B) onto the Ceiling Outlet Box using Mounting Screws (C). Tighten the screws with a screwdriver until secure.
- Attach one Hex Nut (F) to the top, and the other Hex Nut (F) to the bottom of the Nipple (G). Put the Lock Washer (H) in before attaching the Screw Collar Loop (I) to the bottom end of the Nipple (G).
- 5. Thread the Nipple (G) to the Mounting Bracket (B) and secure it with the Hex Nut (F), exposing approximately 2" of its thread.
- 6. Pull out the fixtures wire power cord and the bare copper ground wire woven through the Chain (K).
- 7. Slide the Canopy (E) and the Threaded Ring (J) up the Chain (K).
- 8. Connect Chain (K) to the Screw Collar Loop (I) by using the Quick Link (P). Close the opening of the Quick Link (P) by screwing the nut clockwise.

Rosalind Rattan Black Chandelier 66594H558



your home

- Gently pull existing ground, hot, and neutral junction box wires down from the ceiling junction box and allow these to hang.
- 10. Carefully inspect the fixture wires on the chandelier. The neutral fixture wire is ribbed. The hot fixture wire is smooth, and the ground fixture wire is bare copper.
- 11. Attach the ground wire from the fixture to the ground junction box wire. It usually has green insulation around it or is bare. Fasten these together with a Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. If the ceiling outlet junction box does not have a ground junction box wire, insert the Ground Screw (D) into the Mounting Bracket (B) where it is marked "Ground" facing down, and wrap the ground wire from the fixture around the Ground Screw (D). Tighten the Ground Screw (D) to clamp the ground fixture wire between the head of Ground Screw (D) and Mounting Bracket (B). IT IS IMPERATIVE THAT THE CEILING OUTLET JUNCTION BOX IN YOUR HOME BE PROPERLY GROUNDED!
- 12. Connect the neutral fixture wire to the neutral junction box wire. It usually has white insulation around it. Fasten these together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed.
- 13. Connect the hot fixture wire to the hot junction box wire. It usually has black insulation around it. Fasten these together with a plastic Wire Connector (A) and wrap the connection with electrical tape. Make sure that no wire strands are exposed. Do not reverse the hot and neutral connections or safety will be compromised.
- 14. Gently tuck the wire connections neatly into the ceiling outlet junction box.
- 15. Place the Canopy (E) over the ceiling outlet junction box and secure it in place by screwing the Threaded Ring (J) onto the Screw Collar Loop (I).
- 16. Slide the Candle Sleeves (O) over the sockets.
- 17. Insert Five (5) 25-Watt maximum Type B incandescent light bulbs (not included), or Five (5) 6-watt maximum compact fluorescent light bulbs (not included), or Five (5) 4-watt maximum LED light bulbs (not included) into the socket. DO NOT EXCEED SPECIFIED WATTAGE.
- 18. Restore power to junction box and test the fixture.
- 19. Installation is now completed.

care instructions:

- 1. Wipe clean with a soft, dry cloth or static duster.
- 2. Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the chandelier finish


Made in China


ROSCOE GLOBE CHANDELIER 662036H177



parts enclosed:

Part	Description	Qty.	Part	Description	Qty.
Α	canopy	1	K	tube #K	4
В	mounting bracket	1	G	screw nipple #G	1
C	nipples	3	Н	glass shades	6
D	screws #D	2	1	wrench	1
E	tube #E	4	J	screw#J	1
F	tube #F	4			





important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:


- 1. Carefully remove all parts from the box.
- 2. Remove the mounting bracket (B) from the canopy (A) by loosening the side screws (D).
- 3. Feed the cord through tubes (E) (F) (K) and assemble tubes together according to the desired height. Thread the linked tubes onto the fixture body screw nipple (G). Feed cord through canopy (A) and mounting bracket (B) and thread canopy onto assembled tubes.
- 4. INSURE THE ELECTRICITY SUPPLY IS TURNED OFF.
- 5. Affix the mounting bracket (B) on the outlet box.
- 6. Wrap both safety cables with nipples (C). Push the cables into the outlet box.
- 7. Attach the canopy (A) to the mounting bracket (B) and secure with screws (D).
- 8. Adjust the arms in the orientation of the drawing according to the arrow stickers located on the chandelier arms. Fix arms in place by tightening the screws (J) with small wrench (I).
- 9. Install the bulbs (included) on the sockets and then thread the glass globe shades (H) on the sockets.
- 10. Installation is complete, turn on power at fuse or circuit breaker.


care instructions:



Part	Description	Qty.
Α	canopy	1
В	mounting bracket	1
С	nipples	3
D	screws # D	2
Е	tube #E	4
F	tubes #F	4

Part	Description	Qty.
K	tubes #K	4
G	screw nipple #G	1
Н	glass shades	6
1	wrench	1
J	screws #J	12
spare parts screws #J		5





important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.


to assemble:

- 1. Carefully remove all parts from the box.
- 2. Remove the mounting bracket (B) from the canopy (A) by loosening the side screws (D).
- 3. Feed the cord through tubes (E) (F) (K) and assemble tubes together according to the desired height. Thread the linked tubes onto the fixture body screw nipple (G). Feed cord through canopy (A) and mounting bracket (B) and thread canopy onto assembled tubes.
- 4. INSURE THE ELECTRICITY SUPPLY IS TURNED OFF.
- 5. Affix the mounting bracket (B) on the outlet box.
- 6. Wrap both safety cables with nipples (C). Push the cables into the outlet box.
- 7. Attach the canopy (A) to the mounting bracket (B) and secure with screws (D).
- 8. Loosen each set screw (J) using the allen wrench (I) provided. Carefully adjust the arms in the orientation of your preference. Fix arms in place by tightening the screws (J) with the allen wrench (I).
- 9. Install the bulbs (included) on the sockets and then thread the glass globe shades (H) on the sockets.
- 10. Installation is complete, turn on power at fuse or circuit breaker.

care instructions:



Part	Description	Qty.
Α	glass ball	1
В	lamp arm	1
С	iron pipe	1
D	rod # D	1
E	rod # E	1
F	rod joint	1
G	internal hexagonal	1



important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.


to assemble:


- 1. Carefully remove all parts from the box.
- 2. Connect the rods (D) (E) together according to the illustration.
- 3. Install the connected lamp body on the rod joint (F) in the marble base firmly.
- 4. Install the bulb on the socket and then install the glass ball (A) on the socket too.
- 5. According to the drawing, install iron pipe (C) on the lamp arm (B).
- 6. Adjust the orientation of the arm with provided internal hexagonal (G) wrench according to the illustration.
- 7. Installation is completed. Plug the lamp into wall outlet

care instructions:



Part	Description	Qty.
Α	glass ball	1
В	lamp arm	1
C	iron pipe	1
D	centre rod	1
E	rod joint	1
F	internal hexagonal	1





important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.


to assemble:


- 1. Carefully remove all parts from the box.
- 2. Install the centre rod (D) on the rod joint (E) firmly.
- 3. Install the bulbs on the socket and then install the glass ball (A) on the socket too..
- 4. According to the drawing, install iron pipe (C) on the lamp arm (B).
- 5. Adjust the orientation of the arm with provided internal hexagonal (F) wrench according to the illustration.
- 6. Installation is completed. Plug the lamp into wall outlet.

care instructions:



Part	Description	Qty.
Α	screw#A	2
В	bracket	1
С	screw#C	2
D	connectors	3
F	glass ball	1
G	lamp arm	1
Н	iron pipe	1







important safety instructions:

- 1. We recommend installation by a licensed electrician.
- 2. To avoid the risk of fire, do not exceed the recommeded wattage for this fixture.

warnings:

- 1. Do not remove the lamp from its packaging by pulling on the power cord, as a bad connection may result.
- 2. To avoid the risk of fire, electrical shock, or personal injury, turn off lamp and allow it to cool prior to replacing light bulb.
- 3. Do not touch bulb when fixture is turned on or look directly at lit bulb.
- 4. Keep flammable materials away from lit bulb.

to assemble:

- 1. Carefully remove all parts from the box.
- 2. Loosen the side screws (C) and take the mounting bracket (B) from the base. Then fix the bracket (B) with screws (A) to the wall.
- 3. INSURE THE ELECTRICITY SUPPLY IS TURNED OFF.
- 4. Connect the 2 power wires (black and white color) with connectors (D) and earth wire according to their colors.
- 5. Attach the base to the bracket (B) and secure with side screws (C) again.
- 6. Install the bulbs on the socket and then install the glass ball (F) on the socket too.
- 7. According to the drawing, install iron pipe (H) on the lamp arm (G).
- 8. Installation is complete, turn on power at fuse or circuit breaker.

care instructions:


ARHAUS

RYLAND=q^_ib=i^jm=_^pb

your home

parts enclosed:

^K=cáåá~ä=ENF K=e~êé=ENF



important safety instructions::

NK=É=êÉÅçããÉåÇ=áåëí~ää~íáçå=Äó=~=äáÅÉåëÉÇ=ÉäÉÅ OKœ=~îçáÇ=íÜÉ=êáëå=çÑ=ÑáêÉI=Çç=åçí=ÉñÅÉÉÇ=íÜÉ= êÉÅçããÉåÇÉÇ=ï~íí~ÖÉ=Ñçê=íÜáë=ÑáñíìêÉK

ri =kIW=bPNRRMPI=roi^qfkd=W=aorI=
j^u=_ri_=t^ qq^dbW=SM=t
`lksbopflk=q l=j^u=iba=t^ qq^dbW=NO=t==
ri W=N=u^=J=NV=EkIq=fk`irabaF

Warnings:

NK=aç=åçí=êÉãçîÉ=íÜÉ=a~ãé=Ñêçã=áíë=é~Åâ~ÖáåÖ=Äó=éìíÜÉ=éçïÉê=ÅçêÇI=~ë=~=Ä~Ç=ÅçååÉÅíáçå=ã~ó=êÉëìäíK
OKţ=~îçáÇ=íÜÉ=êáëâ=çÑ=ÑáêÉI=ÉäÉÅíêáÅ~ä=ëÜçÅâI=ḍê=iîêå=çÑ=ä~ãé=~åÇ=~ääçï=áí=íç=Åççä=éêáçê=íç=êÉéa~ÅáåÖ
PK=aç=åçí=íçlÅÜ=ÄìäÄ=ïÜÉå=ÑáñíìêÉ=áë=íìêåÉÇ=çå=çê=äçi~í=äáí=ÄìäÄK
QK=hÉÉe=Ñä~ãã~ÄäÉ=ã~íÉêá~äë=~ï~ó=Ñêçã=äáí=ÄìäÄK

To assemble:

NK=`~êÉÑìääó=êÉãçîÉ=~ää=é~êíë=Ñêçã=íÜÉ=Äçñ=~åÇ=
====êÉãçîÉ=~äa=éêçíÉÅíáîÉ=ÅçîÉêáåÖëK
OKţìêå=lcc=éçïÉê=íç=íÜÉ=ÅáêÅìáí=ÄêÉ~âÉê=ïÜÉêÉ=
====íÜÉ=ä~ãé=ïäää=ÄÉ=áåëí~ääÉÇ
PK¹i~ÅÜ=e~êé=E_F=íç=íÜÉ=p~ÇÇäÉ=E`FK
QK=råëÅêÉï=cáåá~ä=E^F=éä~ÅÉ=pÜ~ÇÉ=çå=e~êé=E_F=~
====íáÖÜíÉå=cáåá~ä=E^F=íç=e~êé=E_FK
RK=oÉĕíçêÉ=éçïÉê=íç=íÜÉ=ÅáêÅìáí=ÄêÉ~âÉê=~åÇ=íÉĕí======ä~ãé=ÑáñíìêÉK

Care instructions:

aç=åç(=ìëÉ=éçäáëÜÉë=çê=ÅäÉ~åÉêë=çå=óçìê=ä~ãéK táéÉ=ïá(Ü=ëçÑ(I=äáå(=ÑêÉÉ=Åäç(ÜK