





TRIPLE PLAY



Assembly Guide

ITEM	PART NO	DESCRIPTION	QTY
1	5462301	WLDMT, TP LEFT	1
2	2007801	WASHER, 1/2 X 1-3/4 X 4.5†	8
3	2005816	BOLT, 1/2-13 X 4-1/4" (108mm) SOCKET HEAD	4
4	2001401	NUT, 1/2-13 LK ST ZN	4
5	5462401	WLDMT, TP RIGHT	1




SECURELY tighten all bolt connections.







1/2 X 4-1/4" (108mm) (3)


SECURELY tighten all bolt connections.






SECURELY tighten all bolt connections.





3 1/2 X 4-1/4" (108mm)



SECURELY tighten all bolt connections.

