



MB12 Double Stroller

- GB Instruction Manual
- FR Manuel d'utilisateur



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

Welcome to the familiie

Your trust in our product means the world to us, and we're thrilled to be a part of your parenting journey. Our team has worked tirelessly to ensure that this product provides comfort, safety, and style for you and your little one. We're confident it will exceed your expectations. Should you have any questions or require assistance in the future, please don't hesitate to reach out. Thank you for choosing My Babiie; we wish you and your family countless wonderful times ahead.

Get to know your stroller

Scan the QR code below on your camera app to be linked off to our page to get all the information you need for using your stroller. From setting it up to how to fold it down, it's all there!



Warranty

We provide a 1 year warranty against manufacturing or material defects.

The warranty period is effective from the day of purchase and applicable to the UK and Ireland. If you made your purchase from an authorised retailer, please return your product to them.

If you bought your product via our website; mybabiie.com, please contact our Customer Service team via email (info@mybabiie.com). We are happy to refund any product if you change your mind about your purchase (if purchased from our website, mybabiie.com.) As long as you tell us within 30 days of receiving your goods. They must be returned in an unused condition, in the original, undamaged packaging and complete with all original parts and accessories. Proof of purchase is required.

What is not covered by the Guarantee?

- Failure to follow My Babiie user guide and maintenance instructions.
- Damage caused by non domestic use
- General wear and tear, for example: worn wheels, damaged rain covers, worn/torn fabric.
- Deliberate damage, misuse or neglect.
- Product which has been modified, undergone an unauthorised repair or used a non approved spare part.
- Cosmetic damage.
- Parts subject to normal wear and tear, foam handles, rubber elements of wheels, signs of fabric wear.
- Loss incurred as a result of not being able to use a product whilst waiting for a spare part or repair.

A repair service is available for any item that sustains accidental damage at any point during its lifespan. If the damages are not covered by our guarantee, we will provide a quote for the repair costs on an individual basis. If you find yourself in need of spare parts that are not covered by the warranty, you can purchase each spare part on our website (subject to availability).

To read more about your guarantee, please visit mybabiie.com/guarantee.

Our guarantee is provided by My Babiie Retail Ltd, Suite 188, Stockiie Business Centre, Unit A, St. James Business Park, Henwood Ind. Estate, Henwood, Ashford TN24 8DH.

Your statutory rights are not affected by the guarantee.

Registering your Warranty

To register your warranty please visit www.mybabiie.com/warranties

Registering for your product warranty allows you to claim repairs or replacements if your product develops a fault. It will also help us contact you in the event of a product issue that you may need to be made aware of.

Problems or Questions

If you have any questions about your product then please drop us an email at info@mybabiie.com and we will get back to to you as soon as possible. Alternatively, you can chat to us on our Live Support Chat on our website mybabiie.com or contact us via our social media channels.

Stroller Warnings

IMPORTANT - READ CAREFULLY AND KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE

Remove all packaging and non-permanent labels and dispose of safely before using this product.

The safety of your child could be put at risk if you do not follow these instructions.

This stroller is designed for 2 children from 0 months up to a weight of 15 kg (each seat).

WARNING: Never leave the child unattended.

WARNING: Uneven or excessive loading of items on or in the stroller may cause the product to tip and may cause injury.

WARNING: Maximum intended weight within the shopping basket is 3kg (each basket).

WARNING: Ensure that all the locking devices are engaged before use.

WARNING: To avoid injury ensure that the child is kept away when unfolding and folding this stroller.

WARNING: Do not let the child play with this product.

WARNING: Always use the restraint system.

WARNING: Check that the stroller body is correctly engaged before use.

WARNING: Do not put hot drinks or liquids in the cup holder.

WARNING: This product is not suitable for running or skating.

WARNING: Do not insert any additional mattresses into the stroller.

WARNING: Accessories which are not approved by the manufacturer shall not be used.

WARNING: This pushchair has been designed for one or two children and shall be used for the transport for only up to two children!

WARNING: Always use the crotch strap in combination with the waist belt.

WARNING: This stroller does not replace a cot or a bed. Should your child need to sleep, then it should be placed in a suitable cot or bed.

WARNING: Only replacement parts supplied or recommended by My Babiie shall be used.

WARNING: Any load attached to the handle and on the back of the backrest and on the sides of the stroller will affect the stability of the stroller.


WARNING: The parking device shall be engaged when placing and removing the children.

EN 1888-1:2018+A1:2022 and EN 1888-2:2018+A1:2022 approved


Care and Maintenance

- Please check on a regular basis that the brakes, wheels, latches, connecting elements, belt systems and seams are properly functional.
- Do not expose the stroller to strong sunshine.
- Sponge clean only.
- After use in rain or snow, the wheels should be lubricated and the stroller dried to prevent rust.
- Care for, clean and check this stroller regularly.


Components



What's in the box




2 x canopies




Frame



3 x front wheels



Rear wheel set



Rain cover




2 x cup holders

Assembly instructions

1 Unfold Frame


Locate the locking catch on the side of the stroller and lift to release from the locking stud.

Unfold the pushchair using both hands. Press the locking bar "clicks" into place.



2 Unfold Frame


Unfold the pushchair using both hands. Press the locking bars (1 & 2) until it "clicks" into place.



3 Assemble the front wheels


Assemble the front wheels by pressing down the lock pin on the front tube.

Insert the front tube into the adaptor on the front wheel until the lock pin is fully engaged in the plastic hole.





4 Assemble the rear wheels

Assemble the rear wheels by aligning them with the frame and inserting the rear tube into the adaptor on the rear wheels until the lock pin is fully engaged in the plastic hole.



5 To lock swivel wheels

Your pushchair has front locking swivel wheels. To lock, rotate the wheel so that the pedal is facing forward. Press the pedal down with your foot and you should hear a “click”. Further minor rotation may be required. To release the locked swivel wheels simply lift the pedal with your foot.




6 To operate brakes

Your stroller has a linked parking brake. To engage brakes simply press down with your foot on the pedal located on the rear wheels.

To release brakes simply lift the pedal located on the rear wheels with your foot.


WARNING: Do not step on the steel bar to apply the brakes.

WARNING: Roll back and forth to make sure the brakes are engaged before letting go.



7 Fit the canopy



Slide the plastic component of the canopy onto the corresponding part on the frame. Attach Velcro to both sides of the seat fabric and the rear of the backrest.



8 Adjust the canopy

Pull the canopy away from the backrest to open (Arrow 1).

Push the canopy towards the backrest to close (Arrow 2).



9 Harness & Buckle

Note: Thread the shoulder straps through the loops to reduce the shoulder strap height if required.

To fasten the waist harness:


Insert both buckle clips into each side of the buckle until a “click” is audible

To release the harness:

Squeeze the buckles and pull apart.

To adjust the buckle:

Adjust the shoulder straps by moving the slides as shown.




10 To recline backrest

Each backrest has 3 positions, upright, semi-reclined and fully reclined.


Squeeze and hold the seat backrest adjustment lever and move the seat unit upwards or downwards. Release the lever once the desired position has been achieved and a “click” noise is heard.

Check the backrest is secure before placing the child into the pushchair.




11 Attach cup holders

Slide the cupholders down onto the attachments on the sides of the frame.




12 Legrest adjustment

Pull the levers on either side of the underneath of the leg rest then adjust the leg rest to the desired position.



13 Folding the stroller

Lift the rear locking catches upwards with your foot (1), push the second locking clip down with your foot (2). The pushchair will begin to fold at this point. Push the handles over and the pushchair will naturally catch on the locking catch located on the side of the stroller (3).



IMPORTANTE: LEA DETENIDAMENTE Y CONSERVE ESTAS INSTRUCCIONES PARA FUTURAS CONSULTAS

Retire todos los embalajes y etiquetas no permanentes y deséchelos de forma segura antes de usar este producto. La seguridad de su hijo podría correr riesgo si no sigue estas instrucciones. Este cochecito está diseñado para 2 niños desde 0 meses hasta un peso de 15 kg (cada asiento).

ADVERTENCIA: Nunca deje al niño desatendido.

ADVERTENCIA: La carga desigual o excesiva de artículos sobre o dentro del cochecito puede hacer que el producto se incline y cause lesiones.

ADVERTENCIA: El peso máximo previsto dentro de la cesta de la compra es de 3 kg (cada cesta).

ADVERTENCIA: Asegúrese de que todos los dispositivos de bloqueo estén activados antes de su uso.

ADVERTENCIA: Para evitar lesiones, asegúrese de mantener alejado al niño al desplegar y plegar este cochecito.

ADVERTENCIA: No deje que el niño juegue con este producto.

ADVERTENCIA: Utilice siempre el sistema de retención.

ADVERTENCIA: Compruebe que el cuerpo del cochecito esté correctamente acoplado antes de su uso.

ADVERTENCIA: No coloque bebidas ni líquidos calientes en el portavasos.

ADVERTENCIA: Este producto no es apto para correr o patinar.

ADVERTENCIA: No inserte ningún colchón adicional en el cochecito.

ADVERTENCIA: No se utilizarán accesorios que no estén aprobados por el fabricante.

ADVERTENCIA: ¡Este cochecito ha sido diseñado para uno o dos niños y solo se utilizará para el transporte de hasta dos niños!

ADVERTENCIA: Utilice siempre la correa de la entrepierna en combinación con el cinturón.

ADVERTENCIA: Este cochecito no sustituye a una cuna ni a una cama. Si su hijo necesita dormir, deberá colocarlo en una cuna o cama adecuada.


ADVERTENCIA: Sólo se utilizarán piezas de repuesto suministradas o recomendadas por My Babiie. **ADVERTENCIA:** Cualquier carga sujeta al asa y en la parte posterior del respaldo y en los lados del cochecito afectará la estabilidad del cochecito.

ADVERTENCIA: El dispositivo de estacionamiento deberá estar activado al colocar y retirar a los niños.


Aprobado EN 1888-1:2018+A1:2022 y EN 1888-2:2018+A1:2022

Cuidado y mantenimiento


- Compruebe periódicamente que los frenos, ruedas, pestillos, elementos de conexión, correas los sistemas y las costuras funcionan correctamente.
- No exponga el cochecito a la luz solar intensa.
- Limpiar únicamente con esponja.
- Después de su uso bajo la lluvia o la nieve, se deben lubricar las ruedas y secar el cochecito para evitar óxido.
- Cuide, limpie y revise este cochecito con regularidad.



Qué hay en la caja




2 x toldos




Marco




3 x ruedas delanteras



Juego de ruedas traseras



Cubierta de lluvia



2 x portavasos


Instrucciones de montaje

1 Marco desplegable

Ubique el pestillo de bloqueo en el costado del cochecito y levántelo para liberarlo del perno de bloqueo.


Despliegue el cochecito con ambas manos.

Presione la barra de bloqueo hasta que encaje en su lugar con un "clíc".



2 Marco desplegable


Despliegue el cochecito con ambas manos. Presione las barras de bloqueo (1 y 2) hasta que encajen en su lugar.



3 Montar las ruedas delanteras.


Ensamble las ruedas delanteras presionando hacia abajo el pasador de bloqueo en el tubo delantero.

Inserte el tubo delantero en el adaptador de la rueda delantera hasta que el pasador de bloqueo esté completamente enganchado en el orificio de plástico.





4 Montar las ruedas traseras.

Ensamble las ruedas traseras alineándolas con el marco e insertando el tubo trasero en el adaptador de las ruedas traseras hasta que el pasador de bloqueo esté completamente enganchado en el orificio de plástico.



5 Para bloquear las ruedas giratorias

Su cochecito tiene ruedas giratorias con bloqueo delantero. Para bloquear, gire la rueda de modo que el pedal mire hacia adelante. Presione el pedal con el pie y debería escuchar un "clik". Es posible que se requiera una rotación menor adicional. Para liberar las ruedas giratorias bloqueadas, simplemente levante el pedal con el pie.




6 Para operar los frenos

Su cochecito tiene un freno de mano vinculado. Para accionar los frenos, simplemente presione con el pie el pedal ubicado en las ruedas traseras.

Para soltar los frenos simplemente levante con el pie el pedal ubicado en las ruedas traseras.



ADVERTENCIA: No pise la barra de acero para aplicar los frenos.

ADVERTENCIA: Ruede hacia adelante y hacia atrás para asegurarse de que los frenos estén activados antes de soltarse.



7 Colocar el dosel



Deslice el componente de plástico de la marquesina sobre la parte correspondiente del marco. Coloque velcro en ambos lados de la tela del asiento y en la parte trasera del respaldo.



8 Ajustar el dosel

Retire la capota del respaldo para abrirla (Flecha 1).

Empuje la capota hacia el respaldo para cerrar (Flecha 2).



9 Arnés y hebilla

Nota: Pase las correas de los hombros a través de los bucles para reducir la altura de las correas de los hombros si es necesario.

Para sujetar el arnés de cintura:


Inserte ambos clips de la hebilla en cada lado de la hebilla hasta que se escuche un "clic"

Para soltar el arnés:

Apriete las hebillas y sepárelas.

Para ajustar la hebilla:

Ajuste las correas de los hombros moviendo las correderas como se muestra.




10 To recline backrest

Each backrest has 3 positions, upright, semi-reclined and fully reclined.


Squeeze and hold the seat backrest adjustment lever and move the seat unit upwards or downwards. Release the lever once the desired position has been achieved and a "click" noise is heard.

Check the backrest is secure before placing the child into the pushchair.




11 Coloque los portavasos

Deslice los portavasos hacia abajo sobre los accesorios a los lados del marco.




12 Ajuste del reposapiernas

Tire de las palancas a cada lado de la parte inferior del reposapiernas y luego ajuste el reposapiernas a la posición deseada.



13 Plegar el cochecito

Levante los pestillos de bloqueo traseros hacia arriba con el pie (1), empuje el segundo clip de bloqueo hacia abajo con el pie (2). En este punto, el cochecito comenzará a plegarse. Empuje las manijas y el cochecito se enganchará naturalmente en el pestillo de bloqueo ubicado en el costado del cochecito (3).




Stroller do's & don'ts



Do use your brakes!

Ensure the parking brake is engaged during the loading and unloading of children & when the pushchair is stationary.




Do always use the restraint system!

Ensure that the child restraint system is correctly fitted at all times.



Do keep your pushchair clean and dirt free.

Use a clean white cloth, warm water and a mild detergent to keep your pushchair clean.



Do always keep two hands on the handles when pushing.

You could lose control of your pushchair if not steering with both hands.



Do follow manufacturers instructions when assembling and using your pushchair.

For safety, please refer to our instruction manuals or contact customer support if you're unsure.



Don't use your pushchair up and down stairs!

Don't use your pushchair up or down stairs or to bump kerbs.



Don't hang bags off the handles!

Bags and other items should not be hung from the handles as this can affect the stability of the pushchair.



Don't run or skate with your pushchair!

Our products are not suitable for running or skating.



Don't carry the stroller with baby inside!

Our pushchairs are not designed to be carried with your baby inside them.



Don't put hot drinks in the cup holder.

Hot drinks burn and can easily spill from the bottle holder.



Don't jetwash your pushchair.

Some jet washers are very powerful and could damage parts of your pushchair!



Don't leave your child un-attended in their pushchair.

Always keep your child and pushchair in view to avoid accidents.



Don't treat your pushchair like a trolley.

Don't load your pushchair up with all your shopping as they are not built for this purpose and could cause damage.



Don't use your pushchair as a bumper cart!

Damage can easily occur if your pushchair is knocked into other things.



Don't smoke around your pushchair.

We wouldn't want your pushchair or little one getting hurt or damaged!



Don't leave your pushchair unattended on extreme gradients.

Even with your brakes on your pushchair is at risk from tipping or sliding on extreme gradients!




Don't sit in the pushchair unless the user is under the guideline weight.

Our pushchairs are designed to hold a maximum weight. If exceeded this will cause damage!



Do enjoy your My Babiie product!

Go out and have fun adventures with your little one!



Register your product



www.mybabiie.com/warranties



www.mybabiie.com/registro

In the first instance of needing assistance please
contact your original place of purchase.

This product qualifies for 12 month warranty
when registered through our website

mybabiie.com



My Babiie



@MyBabiieOfficial



My Babiie



@mybabiie_official