

Tighten the bolts on both sides (9 bolts per side).



Insert all parts



The arrow on the lock should be pointing to the direction of the bolt when squeezing




Tighten the lock clock-wise till the arrow will point oposite direction of the bolt. Do not overtighten or the lock can be damaged! Do it for all of the locks on both sides.



Place second side on top, make sure all screws went into the holes.



Make sure this part are well inserted into cut-out on both sides before locking



Insert removable step into one of the 3 available positions IMPORTANT!
Removable safety plank should be used only with highest removable step position.



Usage of removable safety plank:
A. Insert one side of the plank into cut-out.



Squeeze all locks into holes



B. Make sure the lock is UNLOCKED before inserting and push the plank till the end of cut-out. Use the key after locking it. to do so.

IMPORTANT! Kee



C. Lock it and check that you cannot remove the plank after locking it.

IMPORTANT! Keep it locked at all times when safety plank is used! Remove the key.

WARNING!!!

- The tower can only be used with adult supervision!
- To insure your child's safety and for your own peace of mind, be sure to follow instructions properly. Failure to follow these warnings and assembly instructions could result in serious injury.
- Before each usage or assembly, inspect the tower for damaged hardware, loose joints, missing parts.
- Before using the tower make sure that child can stand stable in it.
- Additional front protection is designed for use with the highest position of standing step.
- Do not leave key in the lock, child can put it in the mouth!

FOR NO COATED ITEMS:

• Uncoated wood quickly loses its aesthetic appearance, so we recommend coating the product with oil, varnish, paint, etc. to protect the wood from external influences.

FOR OILED ITEMS:

- Our items are made to order, so a new item can have an oil smell that will disappear over 1-2 weeks. The oil is organic, 0% VOC, so it is completely safe to use for children from dispatching time.
- We recommend cleaning with a dry cloth for the first 2 weeks without intensive rubbing and without using cleaners.
- After 2 weeks stains can be cleaned with a cloth moistened with water or a non-alcoholic cleaner.
- It is advisable to remove stains immediately and protect them from splashing with intense colors.
- The item can be refinished if necessary.



Thank you for purchasing from us.

This item is made for you with love.