





3-IN-1 KITCHEN HELPER TOWER




**FOLLOW THIS CODE
TO SEE VIDEO GUIDE
FOR ASSEMBLING**

FOLLOW STEPS BELOW TO ASSEMBLE FURNITURE

30 x  (For fixing parts together) 18 x  (For attaching latches)



CORRECT USE OF HELPER, SLIDE AND DESK



Adult supervision is required at all times; we cannot be held responsible for accidents. Do not leave child unattended with stool or desk; keep children and stool away from hazardous objects. Adult assistance is required to unlatch and fold the stool into a desk or attach a slide.