# **Getting Started with your Kestrel Drop**





Figure 1: Overview

# **Changing Settings**



Device Info

Please go to <u>http://www.nkhome.com/kestrel/DROPs</u> for more information.

### **Battery Life**

- The battery life will vary based on usage.
- For baseline conditions and settings\*, the battery will last approximately 6 months.
  \*Temp = 75°F, Logging Rate = 10 Minutes, Update Rate = 30 seconds.
- Battery life will be reduced by:
  - Colder conditions
  - More frequent logging or update rates
- Downloads of large data logs (or firmware updates) are best completed with a fresh battery and in temperatures above 10°C / 50°F.

## **Battery Replacement**



Figure 2: Battery Replacement

	Unit is on. (Only powers off if battery is removed)	
If Battery is Inserted	Bluetooth is on.	
	Drop is logging data.	

#### **LED Indicators**


LED Condition	Status Button	Possible Conditions
Blinking Green Light	Pressed	Unit is functioning normally.
	Not Pressed	Battery was inserted.
		Bluetooth has connected successfully.
		Bluetooth has disconnected successfully.

Note: Status button can be used to immediately send a connection signal to your iOS device.

Please go to <u>http://www.nkhome.com/kestrel/DROPs</u> for more information.

### **Connecting to an iOS Device**

- Please see: http://www.nkhome.com/pdfs/Kestrel Connect Instructions.pdf
- All data logged by the Drop since your last connection will automatically download to your iOS device upon your next connection.



Please go to <u>http://www.nkhome.com/kestrel/DROPs</u> for more information.