



**AUTOMATIC GRINDER & AUTO DISPENSER** 

**QUICK START GUIDE** 









Video Instruction & Warranty Regristration

# UNLOCK 6

- **> TASTES**
- **>** AROMAS
- > & POTENCY


The key to unlocking your herb's flavours, aromas, and potency is in the grind: consistently fluffy, smooth, and perfect - all at the push of a button.



CLOUDIOUS 9°

## **Contents**

Parts & Operation	2
Cleaning & Maintenance	5
mportant Safeguards	6
Warranty Information	7



#### USB Charging (V3)

Plug the supplied USB cord/lead into the USB-C port at the base of the Auto9 Grinder and into a suitable USB Type-A power output or a mobile cell phone charger or laptop port (typically with a 5V 2.1A output).

A full charge takes 2-3 hours. The charging LED changes from Red to Green when complete.



# Step 1

Place the Auto9 Grinder on a flat surface, remove the top grinder head.



### Step 2


For optimal results, divide your herb between the two cavities in the bottom grinder. Then firmly close the grinder sections together. The upper and lower grinder heads should meet completely flat.





## Step 3

Point your Auto9 Grinder in a downward direction and press the grind switch. For best result, regularly alternate between directions by pressing and releasing the switch until you have a smooth grinding rotation.



# **Cleaning & Maintenance**

Use the cleaning accessories after each use for a jam and blockage free grind.

Carefully separate the spout from the top grinder for easier cleaning



x 2

Optimal ginding requires optimal cleaning

Grinding head and spout disassembles

Clean-thru for a jam free grind







### IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

- Read all instructions.
- 2. Portable To protect against risk of electrical shock do not put appliance in water or other liquid.
- 3. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they are closely supervised and instructed concerning use of the appliance by a person responsible for their safety. Close supervision is necessary when any appliance is used by or near children.

Children should be supervised to ensure that they do not play with the appliance.

- Do not press any button when not in use, before assembling or disassembling parts and before cleaning.
- 5. Avoid contacting moving parts.
- 6. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
- 7. Do not use outdoors.
- 8. Do not incinerate this appliance even if it is severely damaged any enclosed batteries can explode in a fire.
- 9. For use with legal material in your local jurisdiction only.

# **SAVE THESE INSTRUCTIONS**

# **Warranty Information**

Find full details of warranty registration at www.cloudious9.com



Auto9 Grinders offers a statutory warranty on all of its products against defective workmanship and faulty materials and undertakes, at its option, to repair or replace, free of charge, each product thereof from the date of purchase, on condition, together with a valid purchase order identification number or valid proof of purchase:

- The product has not been subjected to unauthorised repairs, improper maintenance, misuse, neglect, or been involved in an accident.
- 2. The repairs are not required as a result of normal wear and tear, abuse, or complete burnout due to overloading of the tool's capacity or use beyond the manufacturer's recommendations and in unsuitable environments.

#### Questions? Product Issues? Contact us now:

WWW.CLOUDIOUS9.COM

