



SEQ	PART NO.	QTY in Product	DESCRIPTION
1.00	30300400447	1	HOB PANEL
2.00	30306700005	2	PANEL LIMIT BLOCK
3.00	30302900184	1	OVEN FIXING PLATE
4.00	30302900185	1	OVEN FIXING PLATE
5.00	30102700006	2	HOTPLATE-1000W
5.10	30102700011	2	HOTPLATE-1500W
6.00	30300300001	2	HOTPLATE FIXING PLATE
6.10	30300300002	2	HOTPLATE FIXING PLATE
7.00	30315000243	1	CAVITY PANEL
8.00	2030300006	1	CAVITY COMPONENT
9.00	2030400003	1	DOOR SEAL
10.00	30305900281	1	CONTROL PANEL
11.00	30100100001	1	MECHANICAL TIMER
12.00	30301400063	1	CONTROL PANEL FIXING PLATE
13.00	30301400064	1	CONTROL PANEL FIXING PLATE
14.00	30302300084	2	SIDE PANEL
15.00	30302700135	2	CONNECTION PLATE
16.00	30313200063	2	BRACKET
17.00	30301500016	1	BACK GUIDE BRACKET OF CAVITY
18.00	30302600029	1	HINGE FIXING PLATE
19.00	30302600030	1	HINGE FIXING PLATE
20.00	30302600031	2	HINGE FIXING PLATE
21.00	30100500018	1	FUNCTION SWITCH.4FUNCTION
22.00	30100900001	1	THERMOSTAT SWITCH
23.00	30301800026	1	BOTTOM COVER FOR SMOKE VENT
24.00	30312600011	1	COVER BOARD FOR SMOKE VENT
25.00	30312700003	1	BAFFLE FOR SMOKE VENT
26.00	30401100002	1	EXHAUST PIPE
27.00	30302900172	1	OVEN FIXING PLATE
28.00	30302900173	1	OVEN FIXING PLATE
29.00	30302900171	1	OVEN FIXING PLATE
30.00	30100400018	1	COOLING FAN ASSEMBLY
31.00	30100800003	1	THERMOSTAT
32.00	30100700008	1	LIMITER TEMP CUTOUT
33.00	30101200136	1	TOP ELEMENT
34.00	30101200020	1	BOTTOM ELEMENT
35.00	30301200006	1	FIXED BOARD FOR BOTTOM ELEMENT

SEQ	PART NO.	QTY in Product	DESCRIPTION
36.00	30304100001	2	TEMPERATURE CONTROL PROBE FIXING CLAMP
37.00	30101000001	1	BULB SUB ASSEMBLY
38.00	30102500003	2	INDICATOR LIGHT
39.00	30302200106	1	BACK COVER FOR SHELL
40.00	30400200002	1	GUIDE BRACKET FIXED SHAFT-LEFT
41.00	30400200003	1	GUIDE BRACKET FIXED SHAFT-RIGHT
42.00	30400300003	4	GUIDE BRACKET FIXED SHAFT.
43.00	30102600021	1	JUNCTION BOX
44.00	30313200060	1	BRACKET
45.00	30400700189	1	HANDLE
46.00	30303600001	1	HANDLE FIXING PLATE
47.00	30201300001	2	HANDLE FIXING RUBBER
48.00	30201400003	2	HANDLE GASKET
49.00	30500400124	1	INNER GLASS
50.00	30500300010	1	MIDDEL GLASS
51.00	30500200929	1	OUTER GLASS
52.00	30303500061	1	DOOR BRACKET
53.00	30303400126	1	RIGHT SUPPORT BRACKET FOR DOOR FRAME
54.00	30303400127	1	RIGHT SUPPORT BRACKET FOR DOOR FRAME
55.00	30400600044	2	HINGE
56.00	30200900018	1	INNER GLASS FIXING BLOCK
57.00	30200900019	1	INNER GLASS FIXING BLOCK
58.00	30200900016	4	INNER GLASS FIXING BLOCK
59.00	30201000006	2	MIDDEL GLASS FIXING BLOCK
60.00	30307100117	1	DRAWER PANEL
61.00	30403900006	2	GUIDE RAIL
62.00	30307800014	1	BAFFLE
63.00	30307200021	2	COAMING
64.00	30302900193	2	OVEN FIXING PLATE
65.00	30302900194	2	OVEN FIXING PLATE
66.00	30307100127	1	WARMING DRAWER BOTTOM BOARD
67.00	30402500030	7	KNOB
68.00	30400100011	1	RACK
69.00	30304200002	1	GUILD PILLAR FOR GRILL TRAY
70.00	30201600007	4	ANTI SLIP FEET
71.00	30401600005	2	SPRING
72.00	30100500048	4	ELEMENT SWITCH / REGULATOR