

Thank you for choosing RK products. In order to quickly understand and use this product, please read this operation guide carefully. If you have any other questions, please click www.rkgaming.com for more help.

Thank you for choosing RK products. In order to quickly understand and use this product, please read this operation guide carefully. If you have any other questions, please click www.rkgaming.com for more help.

Model	Rk61	Specification
Size	289(L)x103(W)x39(H)±2	1xKeyboard
Layoyt	61Key	1xUser's manual
Backlight	Led	1xQuality certificate
Switch	Mechanical switch	system support
Version	①USB ②BT+USB	windows/xp/vista/7/8/9/10
Warranty	12-month warrany (non human damage)	ios/macOS/linux/android

Backlight Mode Introduction:

FN+ [V] Switch Backlight Mode

Switch cycle of 17 kinds of backlight modes (The number and effect of the backlight mode will vary depending on the version. Please refer to the actual product.)

Backlight mode introduction:

Fn+ [V] Switch Backlight Mode

Switch cycle of 17 kinds of backlight modes (The number and effect of the backlight mode will depend on the version. Please refer to the actual product.)

FN+ [F]/ [D] Control the brightness of backlight

Press to increase the brightness of backlight. Press to reduce the brightness of backlight to off. There are four grades of backlight brightness and 1 grade to turn it off.

FN+ [;] ['] Control the speed of backlight

Press FN+ [;] to increase the speed of backlight. Press FN+ ['] to reduce the speed of backlight to off. There are four grades of backlight speed.

Fn+ { / } Control the brightness of backlight

Press to increase the brightness of backlight. Press to reduce the brightness of backlight to off. There are four levels of backlight's brightness and one level to turn it off.

Fn+ ; / ' Control the speed of backlight

Press Fn+ ; to increase the speed of backlight. Press Fn+ ' to reduce the speed of backlight to off. There are four levels of backlight speed.

Multifunctional Key Description



Keys	Second function (Fn+Key)	Keys	Second function (Fn+Key)	Keys	Second function (Fn+Key)
ESC	~	8	F8	I	Pause
1	F1	9	F9	H	Insert
2	F2	0	F10	J	Home
3	F3	-_	F11	K	Pgup
4	F4	=+	F12	N	Del
5	F5	backspace	Del	M	End
6	F6	Y	Prtsc	,<	Pgdn
7	F7	U	ScrLk		

E.g. + = F1 + = F1 + = !

Press FN+Shift(Shift on the right side of the keyboard), Arrow keys turn into the second FN function. Press FN+Shift again, arrow keys function recovery.

FN+ --- Win Key Locking Control

Press FN+ to lock the function of WIN key. Press FN+ again to unlock the function of WIN key.

+ Switching to Windows System Mode + Switching to Mac System Mode

Keys	Second function (Fn+Key)	keys	Second function (Fn+Key)	keys	Second function (Fn+Key)
ESC	~	8	F8	I	Pause
1	F1	9	F9	H	Insert
2	F2	0	F10	J	Home
3	F3	-	F11	K	Pgup
4	F4	=	F12	N	Del
5	F5	backspace	Del	M	End
6	F6	Y	Prtsc	,	Pgdn
7	F7	U	ScrLk		

E.g

Press Fn+Shift(Shift on the right side of the keyboard), Arrow Keys turns into the second function. Press Fn+Shift again, Arrow Keys Function recovery.

Fn+win Win key locking control

Press Fn+Win to lock the function of Win key. Press Fn+Win again to unlock the function of WIN key.

Fn+A switch to windows system mode Fn+S swithing to Mac system mode

Combination keys' function switching and locking

Press FN+Ctrl(Ctrl on the left side of the keyboard) to switch to activating the second function of combination keys (except the arrow keys). Press FN+Ctrl again, to restore the 9 keys main function Y/U/I/H/J/K/N/M/, < , but the other combination keys still in the second function. Press FN+Ctrl third times, all the combination keys' main function recovery

Combination Keys' function Swith and lock.

Press Fn+Ctrl (Ctrl on the left side of the keyboard) to switch to activating the second function of combiantion keys(expect the arrow keys). Press Fn+Ctrl again, to restore the 9 Keys main function Y/U/I/H/J/K/N/M/, , but the other combination keys still in the second function. Press Fn+Ctrl third times, all the combination keys' main function recovery.

Wired/ BT Mode Introduction: BT keyboard only

FN + TAB Switch Wired/ BT Mode

When the keyboard connected to the data cable, you can press the FN + Tab to switch the BT to use the wired mode, and press FN + Tab again to switch to BT mode.

FN + P Enter the pairing mode

Firstly, ensure that the switch on the back of the keyboard is in "ON" state. Secondly, press FN + TAB to switch to BT mode. Thirdly, press FN + P (long press for 3 seconds) to enter the pairing status. The P key backlight will continue to flicker, until the BT device finishes pairing successfully(This product is displayed as MantisTek Keyboard on the device). When finishing pairing, the P key backlight will turn off.

Wire/BT Mode introduction: BT keyboard only

Fn+TAB Switch Wired/BT Mode

When the keyboard connected to the data cable, you can press the Fn+Tab to Switch the BT to use the wired mode, and press Fn+Tab again to switch to BT mode.

Fn+P Enter the pairing Mode

1. Power on. The power switch is on the back of the keyboard.
2. Press Fn+TAB to switch to BT Mode
3. Long Pres Fn+P to entry Pairing status. The P key's backlight will continue blink in white light, until the BT device pairing complete. Than P key's backlight will not blink in white light.

FN+Q W E Switch BT Device

This keyboard can save three BT devices at the same time. You can switch among 3 BT devices which has been matched successfully by pressing FN+Q, W, E. When switching among the BT devices, the backlight will flicker continuously at a certain frequency and turns off after switching successfully. If the wireless device is not saved, please press

Charging Introduction: ⚠ BT keyboard only

When charging with a charger, please ensure voltage 5V and current 1A. You can also charge it by plugging it directly into the computer. During charging, the key Space will be on and it will be off when finishing. Full charge needs about 3 hour

Energy-saving: ⚠ BT keyboard only

Without operation for 1 minutes, the keyboard backlight will automatically turn off.
Without operation for 5 minutes, the keyboard will turn into standby mode.
Without operation for 10 minutes, it will turn into Deep Sleep mode. You can tap an key to wake the keyboard.

Fn+Q/W/E Switch BT Device

This keyboard can save three BT device in the same time. You can switch among 3 BT devices which has been match successfully by pressing Fn+Q, W, E. When switching among the BT devices, the backlight will blink twice.

Charging Introduction:

When charging with a charger, please ensure voltage 5V and current 1A. You can also charge it via USB cable to computer. During charging, the spacebar Key will be on the red light. After finish charge the red light will turn off.

Energy-saving:

In BT mode:

Without operation for 1 minutes, the keyboard backlight will turn off.

Without operation for 5 minutes, the Keyboard will be into standby mode.

Without operation for 10 minutes, the keyboard will be into deep sleep mode and disconnect to BT device. You can tap any key on the keyboard, and wait for a second will reconnect to BT device.