




USER MANUAL



Mechanical Wireless Keyboard

English
Deutsch
日本語

PRODUCT BASIC




Keyboard



Size	310(L)×101(W)×38(H)±2mm
Layoyt	68 Key
Backlight	Led
Switch	Mechanical switch



system support
windows/xp/vista/7/8/9/10
ios/macOS/android

WIRED MODE




WIRELESS MODES & CHARGING

BT Connection (BT function keyboard only)



For a better experience, please fully charge the keyboard before first use.

BACKLIGHT CONTROL



- Fn + \ | : Switch Backlight Mode
- Fn + > : Monochromatic conditioning cycle (The same applies to RGB)
- Fn + → : Backlight Speed +
- Fn + ↵ : Backlight Brightness +
- Fn + ↓ : Backlight Brightness -
- Fn + ← : Backlight Speed -

SPECAIAL FUNCTION KEYS

- Fn + PrtSc
- Fn + Del
- Fn + PgUp
- Fn + Spacebar
- Fn + [[
- Fn +]]
- Fn + PgDn
- Fn + ScrLK

SPECAIAL FUNCTION KEYS

- Fn + 1 F1
- Fn + 2 F2
- Fn + 3 F3
- Fn + 4 F4
- Fn + 5 F5
- Fn + 6 F6
- Fn + 7 F7
- Fn + 8 F8
- Fn + 9 F9
- Fn + 0 F10
- Fn + - F11
- Fn + = F12

MULTIMEDIA KEY FOR WINDOWS

Windows System FN + A: switch to Windows system
FN + Left Ctrl (The primary key function and the second function of the composite key are interchanged)

- Fn + F1 Computer
- Fn + F2 Browser
- Fn + F3 Mailbox
- Fn + F4 Calculator
- Fn + F5 Player
- Fn + F6 Stop
- Fn + F7 Last song
- Fn + F8 Play / pause
- Fn + F9 Next song
- Fn + F10 Mute
- Fn + F11 Volume-
- Fn + F12 Volume+

MULTIMEDIA KEY FOR MAC

MAC System FN + S: switch to MAC system
FN + Left Ctrl (The primary key function and the second function of the composite key are interchanged)

- Fn + F7 Last song
- Fn + F8 Play / pause
- Fn + F9 Next song
- Fn + F10 Mute
- Fn + F11 Volume-
- Fn + F12 Volume+

Have an issue with one of our RK products?

Feel free to contact us with any product issues or questions. We will reply as quickly as possible to ensure all your needs are handled. Please contact the seller

