计

POP

USER MANUAL



POWER ON

Take the earphones out of the charging case and it will automatically turn on

POWER OFF

Touch and hold both the earbuds for 8 secs to turn off



FIRST TIME PAIRING

- Take out the earbuds from the charging case
- The earbuds will auto power ON
- Search for 'CB-Airpop' in your phone's BT list
- Click to connect



MONO PAIRING

- For mono mode, take out either of the earbuds when already paired
- The music will automatically play in that particular earbud

RESET

If the earbuds are paired individually,

- Press and hold both the earbuds for 3 secs, the earbuds will enter matching mode.
 - The earbuds have been reset to normal mode and paired between each other.

Search for 'CB-Airpop' in the phone's BT list. Click and connect.

NOTE: Remove/Delete any existing 'CB-Airpop' BT profile from your phone before performing this reset.

CONTROLS

- Volume increase Tap on right earbud once
- Volume decrease Tap on left earbud once
- · Previous tracks Tap on left earbud thrice
- · Next tracks Tap on right earbud thrice
- Play/Pause Tap on either of the earbuds twice
- Answer/Hang up calls Tap on either of the earbuds twice
- Reject incoming call Touch and hold on either of the earbuds for 2 secs
- Voice Assistants Touch and hold on either of the earbuds for 2 secs

NOTE: Available only on devices that have Voice Assistant enabled

CHARGING

- Connect and use the Type-C cable provided in the box for charging.
- Full charge in less than 1.5 hours.

LED INDICATORS ON CASE

When charging -

- Flashing every second While charging
- Solid white Fully charged

When not charging -

Flashing every second – Low battery

LED INDICATORS ON EARBUDS

- White light flashes for a second Turn on
- · Orange light flashes for a second Turn off
- Solid white Pairing
 Solid Orange Earbuds charging
- Off Earbuds fully charged
- Orange light flashes every 0.2 secs Earbuds low battery

www.crossbeats.com

- © +91 96112 93293
- +91 96112 93293