




edgepe

QUICK START GUIDE



1

FUNCTION KEY

TOUCH SENSOR

2

AVAILABLE LED

WHITE AND BLUE LIGHTS



POWER ON

Take earphones out of the charging case and it will automatically turn on.

POWER OFF

Touch hold both the earbuds for 8 secs to turn off.

PAIRING

For first time pairing, take out both earbuds from the case and search for 'CB-EDGE' in phone Bluetooth, just click and connect.

In normal mode if Bluetooth not used for more than 2 mins then it will automatically go to standby or turn off.

To disconnect, just replace the earbuds in the charging case.

CLEAR PHONE PAIRING

In power-off state, touch hold for 15secs to clear earphone pairing information to the cellphone.

AUTO POWER OFF

If the earbuds are disconnected and no function, they will auto turn off in 2 mins.

RESET

If earbuds have paired individually, then long touch both the left and right earbuds at the same time for about 3 secs to enter TWS matching mode. Now the earbuds have been reset to normal mode and paired between each other.

Now turn on Bluetooth in phone, search for 'CB-EDGE'. Click and connect.

Remove/Delete any existing 'CB-EDGE' Bluetooth profile from your phone before performing this reset.

CHARGING THE EARBUDS

Place the earbuds in the charging case and they will automatically charge, No need to press/touch any buttons

SIRI/OK GOOGLE ACTIVATION

While connected, quick touch 3 times on left or right earbuds to activate Siri/Ok Google.



RECEIVE/DISCONNECT CALL

When receiving a call, short touch any earbud to answer the call.

When receiving a call, double touch any earbud to decline the call.

When the call is finished, touch any earbud to end the call.

POWER & BATTERY

For Battery Display - The battery level display for main earphones can be seen on the mobile phone after being connected.*

Low Battery Indication - When the battery power is below 3.5v, the Red-light flashes once every 5 secs and the low battery reminder will be shown every 2 minutes.

Low Battery Power Off – The earbuds will turn off automatically if Battery is below 3.0v.

Charging – Place the earbuds in the charging case to charge them. Maximum charging current is about 55mA for each earbud.

*Conditions Apply.



SMART LED INDICATORS

Power On – White light is on for 1sec

Power Off – Blue light is on for 1 sec and then off

Low Battery – Blue light flashes every 5 secs

In the Charging – White light is always on

Charge Complete – Blue light is on

Not Charging – No LED



LED INDICATORS FOR CHARGING CASE

If the Battery level is

25%, the white light flashes only once

50%, the white light flashes 2 times

75%, then the white light flashes 3 times

100%, then white light is on always

Note: Red light is always on while charging.



LED INDICATORS FOR CHARGING CASE

If the Battery level is

25%, the white light flashes only once


50%, the white light flashes 2 times

75%, then the white light flashes 3 times

100%, then white light is on always

Note: Red light is always on while charging.

www.crossbeats.com

 +91 96112 93293

 +91 96112 93293

 support@crossbeats.com