P

I G N I T E

MANUAL

- 1) Rotating crown key
- 2) Premium metal casing
- 3) Multi-motion sensors

- 4) Microphone
- 5) Speaker

Large 1.7" HD IPS screen Bluetooth calling on watch Health monitors 10 sports modes Dual theme Multiple watch faces (on app) IP67 rated



Scan the QR code to download the smartwatch app Or, Download 'CB-ACTIV' App from the Playstore or iOS app store



- To attach the straps, slide the pin (the side opposite to quick-release lever) into the notch on the watch. Attach the strap with the clasp to the top of the watch.
- While pressing the quick-release lever inward, slide the other end of the strap into place.
- When both ends of the pin are inserted, release the quick-release lever.



- To remove the straps, turn over the watch and find the quick-release lever.
- While pressing the quick-release lever inward, gently pull the strap away from the watch to release it.

- Charge the smart watch before using it.
- Full charge in less than 2 hours.
- Connect the back of the watch to the magnetic charging pin available in the box.
- Please use a 5V charging adapter or connect USB with the laptop.

NOTE: Do not use any fast/dash charging adapters.





Bluetooth 5.0 & Bluetooth 3.0

Note:

- All notifications, alerts, reminders and data received from phone to watch or vice versa will be connected over Bluetooth 5.0.
- For calls, Bluetooth 3.0 needs to be connected.





- Turn on the Bluetooth on your mobile phone.
- Download and install the CB-ACTIV app
- Create an account and login to the app
 - Open APP > device > add new device > choose IGNITE-S3
- When pairing smart watch with mobile phone please ensure the watch and mobile phone are in sync.

NOTE: Upon successful pairing of BT 5.0, android users will get a pop-up dialogue box requesting to pair 'Bluetooth 3.0'. Click yes to pair. Now you can make calls via the smartwatch and will also receive all the notifications.







- Turn on the Bluetooth on your mobile phone.
- Download and install the CB-ACTIV app
- Create an account and login to the app
- Open APP>device>add new device>choose IGNITE-S3
 - When pairing smart watch with mobile phone please ensure the watch and mobile phone are in sync.

Pair from phone Bluetooth for BT3.0 connectivity

- Open the phone settings>Bluetooth, click and connect to 'BT 3.0' in searching list.
- Upon successful connection you will see a dual-coloured BT icon on the home screen.

NOTE: You can answer voice calls on the watch itself. You also have access to the address book and can answer, reject or mute calls on the watch.







BUILT IN WATCH FACES

- Touch and hold the home screen / Rotate the crown key
- You will enter the 'watch face' menu
- Scroll & select your favourite screen

CUSTOMIZE WATCH FACES IN APP

- Go to CB-ACTIV app, select the device tab
- Now click on watch faces
- Pick your choice of dial





PEDOMETER/DISTANCE/CALORIES BURNT

- Swipe right to left thrice on the main screen
 - Swipe bottom to top on the pedometer menu
- You can see all the tracked data of steps, distance, and calories burnt





SLEEP MONITOR

- Swipe right to left 4 times on the main screen
 - Swipe bottom to top on the sleep tab
- You will be able to see the number of hours slept and also the light and deep sleep analysis
- On the CB-ACTIV app, go to device tab & click on the sleep function to see a detailed analysis of your sleeping pattern





HEART RATE

- Swipe right to left once on the main interface
 - You will be able to measure your Heart Rate.

Automatic tracking on App

- Open the CB-ACTIV App and go to device
- Open automatic heart rate detection
 - Set up the monitoring intervals manually
- You can also see the HR variation by clicking on HR from the status tab





SPORTS MODE

- Swipe bottom to top once on the main interface
- Scroll & click on the 'Sports' to explore 10 different activities





BLOOD PRESSURE

- Swipe bottom to top once on the main interface
- Scroll & click on the 'Blood Pressure' to activate
- Wait for 10-15secs for the reading to complete
- You can see more details your CB-ACTIV app under the status tab



WEATHER UPDATES

- Swipe from right to left 5 times from the main interface
- Check the weather forecast update



WOMEN'S HEALTH

- Activate Menstrual feature from the CB ACTIV app
 - On the watch, you will be able to monitor the same
- Swipe bottom to top once on the main interface
- Scroll & click on Menstrual to view the period details



MUSIC CONTROL

- Swipe bottom to top once on the main interface
 - Scroll & click on 'Music' to expand the music control
- Control or change tracks & volume levels





HOW TO ACCESS

 Swipe top to bottom once to enter the apps menu

RDICHTNES

- Swipe from top to bottom once
 - Click on the brightness icon
- Adjust the brightness as required



DUAL THEME

- Swipe top to bottom once
- Click on the 'theme' icon
- Select 'Theme 1' or 'Theme 2' to change the user interface



FACTORY RESET

- Swipe top to bottom once on the main interface
- Click on the settings icon
- Now scroll to 'Factory mode' and click on it to reset the watch



POWER OFF

- Swipe from top to bottom once
- Click on 'Settings'
- Now scroll and click on 'Power Off' to turn the smartwatch off



CAMERA CONTROL

- Open the CB-ACTIV app and go to device tab
- Scroll down to 'Camera' and allow App to access camera
- On the watch, swipe bottom to top once on the main interface
 - Click on the 'camera' icon to activate
- On the watch screen, you will see 'Click'. Tap on it to take a picture



SMART ALERTS

- Swipe bottom to top once
- Scroll and select notifications to view your latest notifications



STOPWATCH

- Swipe from bottom to top once on the main interface
- Click on the 'stopwatch' icon to activate
- You also have pause and restart option



STRESS MANAGEMENT

 Swipe right to left twice on the main interface to view your stress level graph





138 7522 6533 💌		
1	2	3
4	5	6
7	8	9
*.	0	•

CALL REMINDER

- Go to the CB-ACTIV app and select the 'device tab'
- Click on the 'Message Push' icon
- Enable 'Incoming call' and 'SMS' alerts

NOTE - You can speak on the watch as it has in-built speaker and mic



SEDENTARY REMINDER

- Go to the CB-ACTIV app
- Under the 'device tab', turn on the 'Sedentary reminder'
- You can set the timing for idle alert via the App



ALARM CLOCK

- Go to the CB-ACTIV app and select the 'Device tab'
- Click on the 'Alarm Clock' to add a new alarm or enable an existing alarm



FIND MY PHONE

- Swipe from top to bottom once on the main interface
- Click on the 'find phone' icon
- Your phone will ring to alert

HCROSSBEATS