

melomane

MELOPODS

RHYTHM




Quick User Guide



**EXPERIENCE
THE LIMITLESS**

1. Product Labeling


- 1) Right Earphone Power Button
- 2) Right Earphone Indicator/Call Microphone
- 3) Left Earphone Power Button
- 4) Left Earphone Indicator/Call Microphone
- 5) Charging Case Indicator
- 6) Type-C Charging Port



2. Function Introduction

1) Power ON/OFF

- Turn On : In Power-ON state, long press earphone power button for 3 seconds to enter reconnect state. Take it out of melopod case and it will automatically connect back.
- Turn Off : Long press earphone power button for 3 seconds to power off. Put the earphone into the melopod case, the earphone will Power-OFF automatically.



2) Pair your phone or other device

- Use for both your ears : Take both the left and right earphones out of the melopod case at the same time, the auxiliary earphone automatically pairs the host earphone. The red and blue indicators of the host flash alternately to enter the state of waiting for connection.
- Use of single ear : Take one earphone out of the melopod case. The red and blue indicators of the earphone flash alternately to enter the state of waiting for connection.
- Turn on the bluetooth switch of your phone or other device.
- Search the bluetooth device and select the device name "Melopod : RHYTHM".
- If the pairing is successful, the blue indicator will start to flash.
- On the second use, the earphone automatically connects to the last connected device (make sure that the device's bluetooth function is turned on)

- If the pairing is unsuccessful, turn off the earphone and then pair again.

3) Operations of basic functions

- Music Pause/Play : Click power button
- The previous song : Double click the power button (on the right earphone) for the previous song.
- The next song : Double click the power button (on the left earphone) for the next song.
- Cancelling callback : Click power button
- Answering call : Click power button
- Rejecting call : Long press the power button 1 second
- Redialing last number : Triple click the power button
- Ending the current call : Click power button
- Start Siri or Google Assistant : Long press the power button 1 second to start siri or google assistant.

4) Charging


- Charging of the melopod case : When the red indicator in the melopod case flashes to indicate the low battery of the current melopod case, please use the Type-C charging cable and plug it into the USB port supporting 5V power (such as AC/DC USB adapter or PC USB port). Connect the USB charger cable to the charged port of the melopod case when the red light flashes, the melopod case is charging. When the blue light is constantly on, the melopod case is charging the earphone. When the melopod case is charged for the first time, please make sure that the melopod case is used after fully charged.
- Earphone charging : When there is a voice prompt 'Low Battery', it needs to be charged as soon as possible. Put the earphone into the charging case to automatically charge it.

3. Attention

- Put 2 earbuds into the melopod case, if the earbuds light is

red, it means it is on charging, if the earbuds light isn't red (red and blue light flashing or no light on), please shake the earbud to make sure the light is indicating red in the melopod case.

- When people can only connect one earbud with their mobile phone (only can hear 1 earbuds sound), maybe because of mis-operation, please restart the melopod earbuds.
- Reset operation : Keep the mobile phones bluetooth off, then take 2 earbuds from the melopod case, if you can see the left and right earbud red and blue light flashing, then press the right earbuds button twice quickly and put two earbuds together, 2-3 seconds later, the left and right earbuds would connect automatically.







8 906131 80064