

## SPECTRUM Series Headlights Installation Instructions

**Product Specifications** 

Input Voltage 12-24 vdc

**Max output** 

Low Beam 2400 lumens High Beam 3600 lumens

## !!! Disconnect battery before attempting any electrical work or installation!!!

## **Installation Guide:**

- 1. Disconnect battery.
- 2. Remove Grille to access headlight retainer rings.
- 3. Remove headlight retainer rings using T15 Torx screwdriver.
- 4. Remove old headlights and inspect vehicle wiring harness and connectors for any damage. Repair if needed.
- 5. Plug in the anti flicker harness, if present, to the vehicle headlight plug then connect the headlight main connector to the anti flicker harness.
- 6. For Halo Models only- connect Red wire to running light or a switch. This wire activates the white halo. Connect the green wire to the turn signal if desired. This will activate the amber halo function of the light.
- 7. Reconnect battery and test each function for correct operation.
- 8. Zip tie or tuck away your wiring to prevent pinching.
- 9. Reinstall headlight retainer rings Be careful to not pinch any wires
- 10.Reinstall Grill and your ready to enjoy your new SPECTRUM Series headlights!



Red wire - white halo

Green wire -amber halo(Turn signal)

## Anti-Flicker Harness (purchased separately)



Load Resistors for Turn Signals (purchased separately)

