

- 3 Cannot pair or connect with Alexa or Google Assistant. Please contact the Govee support team for rapid product replacement.
 - a. Ensure the stability of the Wi-Fi connection.
 - b. Go to the app Settings page and follow the instructions under "User Guide" to pair the device again.
- 4 One or more fixture lights fail to light up.
 - a. Check that the connecting wires, control box, and power adapter are all properly connected.
- 5 Only one user can control the device.
 - a. Each device can only be controlled by one account.
 - b. If multiple users wish to control the same device, ensure they are using the same account.



Govee Home App

For FAQs and more information, please visit: www.govee.com

Customer Service

- Warranty: 12-Month Limited Warranty
- Support: Lifetime Technical Support
- Email: support@govee.com
- Official Website: www.govee.com
- @Govee @govee_official @govee.official
- @Goveeofficial @Govee.smarthome

FCC and ISED Canada Statement

This device complies with Part 15 of the FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil n' doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-005. Cet appareil numérique de la classe B est conforme à la norme NMB-005 du Canada.

Govee is a trademark of Shenzhen Intellirocks Tech Co.,Ltd. Copyright ©2021 Shenzhen Intellirocks Tech Co.,Ltd. All Rights Reserved.

FCC and IC Radiation Exposure Statement

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

La distance entre l'utilisation et l'appareil ne doit pas être inférieure à 20 cm.

This device uses a non-replaceable light source. When the light source reaches the end of its life cycle, this device should be replaced. Not intended for illumination. Only used for creating ambiance.

1. Do not connect the rope light to the supply while it is in the packing or wound onto a reel;
2. Do not use the rope light when covered or recessed into a surface;
3. Do not open or cut the rope light;

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Intellirocks Tech. Co., Ltd. is under license.

Responsible party :

Name: GOVEE MOMENTS(US) TRADING LIMITED
Address: 13013 WESTERN AVE STE 5 BLUE ISLAND IL 60406-2448
Email: support@govee.com
Contact information: <https://www.govee.com/support>

CAUTION:

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

ATTENTION :

RISQUE D'EXPLOSION SI LA BATTERIE EST REMPLACÉE PAR UN TYPE INCORRECT. ÉLIMINER LES BATTERIES USÉES CONFORMÉMENT AUX INSTRUCTIONS.



FOR INDOOR USE ONLY
POUR UNE UTILISATION EN INTÉRIEUR UNIQUEMENT



User Manual

Model: H6087

Fixture Lights

READ AND SAVE THESE INSTRUCTIONS

Safety Instructions

Read and follow all the safety instructions:

- This product is not waterproof. Avoid exposing its components to splashes, water drops, or every high-humidity environments.
- The working temperature should be between 14°F to 104°F (-10°C to 40°C).
- The internal light sources of this product cannot be replaced. If the light sources sustain damage, the product should be replaced.
- Do not allow children to assemble and install this product without adult supervision.
- Avoid installing this product near major heat sources.
- External dimmers cannot be used with this product.
- Avoid installing this product near potentially dangerous sources (e.g., candles, liquid-filled objects.)

Introduction



Thanks for choosing Govee Fixture Lights. This product is composed of 4 connected fixtures that can be easily installed on the walls of a corridor, living room, bedroom, and more, bringing another level of colorfulness to daily life.

Download Govee Home App to adjust colors, color segmentation, brightness, effects, and mode, and also connect with third-party voice assistants such as Alexa and Google Assistant for hands-free control.

What You Get

Fixture Lights	4
Control Box	1
Power Adapter	1
Mounting Brackets	4
Power Cable	3
User Manual	1
Service Card	1

At a Glance



Power Button	Press to turn on/off
Function Button	Press to cycle through 9 colors; Long press to cycle through 6 brightness levels.
Music Mode Button	Press to enter Music Mode

Pairing Your Device with Govee Home App

What You Need

- A Wi-Fi router that supports 2.4GHz and 802.11 b/g/n bands (5GHz is not supported).
- A smartphone or tablet running iOS or Android.

Pairing Instructions

- Download the Govee Home app from the App Store (iOS devices) or Google Play (Android devices).
- Turn on Bluetooth on your smartphone.
- Open the app, tap the "+" icon in the top right corner and search for "H6087".
- Tap the device icon and follow the on-screen instructions to complete pairing.



Controlling the Device with Your Voice

- 1 Open the app, then tap the device icon to enter detail page.
- 2 Tap the setting icon in the top right corner.
- 3 Select Using Guidance and follow on-screen instructions to control the device using your voice.

Specifications

Adapter Input	AC100-240V
Light Input	12V/2A
Lumens	150lm/Pcs
Color	RGBWW
Color Temperature	2200K-6500K
Control Method	App, Voice, On-Device Buttons
Working Temperature	14°F to 104°F (-10°C to 40°C)

Troubleshooting

- 1 Cannot connect to Govee Home App.
 - a. Check if the fixture light is powered on.
 - b. Check if your smartphone's Bluetooth is enabled, or try connecting with another smartphone.
 - c. When connecting for the first time, ensure the smartphone is near the fixture light.
 - d. If the connection error still exists, please delete the connected fixture light from "My Device" on the app.
 - e. Reconnect to Govee Home App by following the instructions provided previously.
- 2 Wi-Fi disconnected or failed to connect.
 - a. Check if the fixture light is powered on.
 - b. Do not skip connecting to Wi-Fi during the pairing process.
 - c. Ensure your Wi-Fi router is 2.4GHz capable (5GHz is not supported).
 - d. Ensure you entered the correct Wi-Fi password during the Wi-Fi connection process.
 - e. Try connecting the fixture light with a smartphone hotspot to check if your home network is working properly.
 - f. Shorten the distance between the fixture light and the Wi-Fi router to less than 50ft, then try reconnecting.