


## FC-625 Plug n' Power

### Front



**POWER (Constant)**  
**TO: Laptop**  
 (For computer equipment only)

**LED Light**  
**Green** - Grounded  
**Orange** - Power ON  
**Red** - Protected  
 (All Lit when power button is pressed & power cord is properly grounded)

**OUTPUT**  
**RJ11 Phone Jack TO:**  
**Computer or Fax**

**OUTPUT**  
**RJ45 High Speed DSL or Ethernet Connection**  
 Provides access to a cable modem, network, or internet router  
**TO: Laptop Computer**


**OUTPUT**  
**2-USB A Downstream**  
 The front USB port #1 is a direct connection to USB port #1 located on the back of the unit (only one USB port may be used at a time)

**INPUT**  
**1-USB B Upstream**  
 The front USB port #2 powers the back USB port #2.  
**FROM: Computer**

### Back

**RJ45 High Speed DSL or Ethernet Connection**  
**TO: Network, Router, or Cable Modem**

**TO: Palm Pilot, Printer, Digital Camera or to a Laptop Computer**



**OUTPUT**  
**2-USB A Downstream**  
 The front USB port #2 is a direct connection USB port #2 located on the back of the unit. (only one USB port may be used at a time)  
**To: Palm Pilot, Printer, Digital Camera or to a Laptop Computer**

**RJ11 Phone Jack TO:**  
**Wall Phone Jack**  
**INPUT**  
**1-USB B Upstream**  
 The back USB port powers the front USB port.  
**FROM: Desktop or Laptop Computer**

**RJ11 Phone Jack TO:**  
**Modem**

**Constant Power**

**Power Outlets (with child safety locks)**

**Input connections made from the back via USB, RJ45, or RJ11 powers the front connections**

