



BAGOROLL –
PRODUCT MANUAL



產品說明書

製品説明書



Made in Taiwan
Design By **FLYTTA**

GO
BAGOROLL



ENGLISH —————

P.2 – 8

日本語 —————

P.9 – 15

中文 —————

P.16 – 22



The product can be used in three styles





STYLE.1

Lightweight Handbag

STYLE.2

Classic Handbag



STYLE.3

Unique Hand-Roll Bag

Usage of the Table Mat





STEP.1

Pull out the slap bracelet.

STEP.2

Flatten the bag on both the left and right sides.




STEP.3

Use the mobile table mat to picnic everywhere.

Usage of the Cutlery

STEP.1

Pull out the cutlery.



STEP.2

All three kinds of cutlery are ready for use.



STEP.3

Keep the cutlery handy, and the cutlery won't stick to the table.



Usage of the Slap Bracelet





STEP.1

Pull out the slap bracelet.

STEP.2


Roll it into a heat-insulating cup cover, so that hot drinks won't burn your hands.



STEP.3

After use, put the slap bracelet back face up on the front of the bag.

Usage of the Rollable Bag




STEP.1

Set the protruding side of the flap bracelet towards the cutlery pocket of the bag body.

STEP.2


Press the bottom side of the bag inward to quickly roll up the bag body.



STEP.3

You can smoothly roll up the bag this way.

Usage of the Salad Clip




STEP.1

Overlap the spoon and fork and open the salad clip.


STEP.2

Put the salad clip into the pen-clip structure to fix them.




STEP.3

You can easily pick up light food such as bread, salad, etc.




STEP.4

Put it at the rear end of the cutlery for storage, and you can take it with you at any time.



Usage of the Cup Holder




STEP.1

Flatten the product to save space during storage.

STEP.2

Press both sides with your hands, squeeze inward to arch the cup holder body, fold the 4 sides of the cup holder inward, and place the notched side on the inside.



STEP.3

Put the drink on the cup holder, or put it in the bag. The bottom plate can prevent the cup from shaking and tipping.

バッグが3種類に変化





STYLE.1

軽くて持ちやすい手提げバッグ

STYLE.2

オーソドックスなハンドバッグ



STYLE.3

バッグを巻いて収納

ランチョンマット使用方法





STEP.1

カップベルトを取り出します。

STEP.2

バッグの左右を
引っ張って平ら
にします。




STEP.3

携帯用ランチョンマッ
トでどこでもピクニッ
クできます。

STEP.1

各食器を取り出します。



STEP.2

3種類の食器で美味しくお召し上がりになれます。



STEP.3

テーブル上に置いても汚しません。



カップベルト使用方法





STEP.1

カップベルトを取り出します。

STEP.2


あつあつのカップの周りに巻けば手を火傷しません。



STEP.3

カップベルトの表面を叩いて平らにしてからそのままバッグに収納します。

エコバッグの巻き方




STEP.1

カップベルトの凸面を食器用ポケット側に向けま

STEP.2


バッグの下側を内側に押すとバッグがあっという間に巻きま



STEP.3

エコバッグを巻いて収納
できます。

サラダ tong 使用方法




STEP.1

スプーンとフォークを重ねてから外に開きます。

STEP.2

内側にクリップを入れてサラダ tong を固定します。




STEP.3

パンやサラダなどを簡単に掴むことができます。




STEP.4

収納時はバッグの後ろ側に入れていつでも簡単に持ち運べます。



カップホルダー使用方法




STEP.1

収納時は平らで場所をと
りません。

STEP.2

長い辺を指で内側に押すと、ホルダーがアーチ状に膨らみます。ホルダー端の4つの耳を内側に折ります。口が欠けている耳が内側です。



STEP.3

ドリンクをホルダーに載せて一緒にバッグの中に入れることができます。底板のおかげでカップが揺れません。

三款包的變化




STYLE.1

-輕巧手提包-


STYLE.2

-經典手拿包-



STYLE.3

-獨特手捲包-



餐墊使用方法





STEP.1

將拍拍尺抽出。

STEP.2

將袋子左右壓平。




STEP.3

行動餐墊，隨處野餐。

STEP.1

將餐具抽出。



STEP.2

三種餐具使用都好食。



STEP.3

隨手放置，餐具不沾桌。



拍拍尺使用方法





STEP.1

將拍拍尺抽出。

STEP.2


捲成隔熱杯套，
熱飲不燙手。



STEP.3

使用完後將拍拍尺正面
與袋體正面放回。

捲收的使用方式




STEP.1

將拍拍尺凸面對向袋體之餐具口袋面。

STEP.2


將袋子底側做內壓可快速捲收起袋體。



STEP.3

順利捲收成為捲收袋體。

沙拉夾使用方式




STEP.1

將湯匙與叉子相向交疊後撐開。


STEP.2

將沙拉夾套入筆夾式結構中固定。




STEP.3

即可輕鬆夾取麵包、沙拉等輕食。




STEP.4

收納時將之套入餐具後方，即可輕鬆隨時帶。



置杯架使用方式




STEP.1

收納時攤平以節省空間。

STEP.2

用手按壓兩側長邊，向內擠壓讓杯架體拱起，將置杯架4片側耳向內凹折，有缺口之側耳置於內側。



STEP.3

將飲料置於杯架上，亦可一起置於袋體內，底板可防止杯身搖晃傾倒。