

Upgrade your Aquor Hydrant with customizable debris covers to match your home's style. Protect your hydrant from dirt and debris when not in use. Available in stainless steel or weatherproof thermoplastic, in multiple colors and finishes. Simple, quick installation.

- Quickly and easily customize appearance
- Protects hydrant from dirt and debris
- Corrosion resistant stainless steel
- 1-minute install: simply undo hydrant screws to replace, no need to shut off water
- 95° angle rubber gasket for proper drainage



Compatibility	Hydrant V1/V1+, RV City Water Inlet, Ground Hydrant				
Install Required	Yes	Yes	Yes	Yes	Yes
Finish	Brushed Stainless	Matte Black	Matte White	Aquor Blue	Slate Gray
Cover Material	Brushed Stainless	Coated Stainless	Coated Stainless	Delrin® Acetal Polymer	Delrin® Acetal Polymer
Gasket Material	EDPM	EDPM	EDPM	EDPM	EDPM
Warranty	10 Years	10 Years	10 Years	5 Years	5 Years
SKU	MC-V1	MC-V1-TI	MC-V1-WHT	C-V1-B	C-V1-G

Installation




1) Remove existing cover by releasing hydrant mounting screws. There is no need to shut off the water supply. Do not disconnect from plumbing.



2) Slide the existing cover up to remove. New cover must be installed BEHIND the hydrant faceplate.

Note the 5° wedge will angle the hydrant downward for drainage.



3) Replace mounting screws to secure assembly to wall.



4) Check cover alignment and operation. Adjust friction hinge if needed.

Care & Maintenance

BRUSHED STAINLESS

Gently clean with warm water and a mild liquid detergent to remove any dirt or debris.

Stainless steel is highly-resistant to corrosion, the surface can be susceptible to cosmetic spots by saltwater and airborne chemicals. Simple cleaning should restore the stainless steel to its original appearance. Use a Scotchbrite pad in the same direction of the existing brushed surface.

DO NOT use steel wool to clean stainless steel, as the carbon steel will contaminate the stainless steel, causing rust.

COATED STAINLESS & POLYMER

This coated finish is extremely durable and resistant to scratches, but can still chip if the cover is hit or knocked against with sharp objects. Gently clean with warm water and a mild liquid detergent to remove any dirt or debris.

DO NOT use bleach, caustic, acid-based cleaning materials or detergents, or abrasive materials (such as Scotchbrite) or other hard objects against the coated finish.