

ENVIROSOLV®

WATER-BASED CLEANER

Quick Tip:

To cut down on

the number of rags

it takes to clean a

screen, use a non absorbent scrub pad to liquify the

GENERAL DESCRIPTION

ENVIROSOLV® is a water-based ink cleaner designed for the removal of water-based and plastisol inks. This product works especially well at opening up dried-in waster-base ink in the image area. This product will protect the fabric from deep stains or ghosting from the image print.

ADVANTAGES

- Water Based
- No Residue
- Pleasant Odor

ADVAITIAGEO

all the ink to one

ink and a

end of the screen and wipe up with

one or two rags.

APPLICATIONS

Always card excessive ink from screen. Use one of the following applications.

"PRESS WASH/SCREEN OPENER"

Apply product on both sides of screen and then wipe or squeegee off until all residue is gone. ENVIROSOLV® works extremely well when cataloging the screen.

"SCREEN WASH"

Apply to the ink side of the screen. Use a brush or pad to agitate both sides of the screen. High pressure water rinse until all residue is gone.

E-44PL EconoBooth

Click here for more details.



Look For More Information on all the Products in the ENVIROLINE® of "Green" Chemistry.













