

USER GUIDE

# AIRWALKS

True Wireless Earbuds



[WWW.TRNDLABS.COM](http://WWW.TRNDLABS.COM)

**Thank you for purchasing AIRWALKS  
True Wireless Earbuds and welcome to  
the world of TRNDlabs products.**

AIRWALKS is a pair of Bluetooth-connected Earbuds with its own charging case, giving you the freedom to take your music anywhere in an elegant design.

# Table of Contents

Parts Identification	5
Functions	6
Setup and Charging	8
Turning AIRWALKS ON & OFF	14
Connecting	15
Specifications	17
Troubleshooting	18
Safety Information	20

# Parts Identification




USB to Micro USB Charging Cable

AIRWALKS True Wireless Earbuds

AIRWALKS Charging Case




Ear Hooks



# Functions

Play/Pause a track - *Single Press*  
Redial - *Double Press*  
Take/End call - *Single Press*  
Power OFF - *Hold for 5 seconds*



Earbud LED Light

Charging Docks

LED Lights




USB Charging  
Port

# Setup and Charging

## BEFORE YOU USE AIRWALKS FOR THE FIRST TIME

- 1 Place your AIRWALKS True Wireless Earbuds into the Charging Case and make sure they sit comfortably in the magnetic Charging Dock.
- 2 Connect the Charging Case to a computer or a power source via the Micro-USB Cable.
- 3 The LEDs on the Charging Case will flash blue to indicate that the Charging Case is charging. It is fully charged when all 4 LEDs on the Charging Case are lit.
- 4 To charge the Earbuds, disconnect the Charging Case from the power source. The LEDs will turn red indicating that your Earbuds are charging. When the batteries are fully charged the red LED indicators will turn off.





## **CHARGING AIRWALKS TRUE WIRELESS EARBUDS**

- 1** Place your Earbuds into the Charging Case and make sure they sit comfortably in the magnetic Charging Docks.
- 2** A red LED light will light up on each Earbud to indicate that the Earbuds are charging.


The red LED light will turn off once the Earbuds are fully charged.



## CHARGING YOUR AIRWALKS CHARGING CASE

- 1 Connect the Charging Case to a computer or power source via the Micro-USB Cable.
- 2 The LEDs on the Charging Case will flash blue to indicate that the Charging Case is charging. It is fully charged when all 4 LEDs on the Charging Case are lit.

*Note: You can charge your Charging Case with or without the Earbuds inserted.*



## Turning AIRWALKS ON & OFF

The left and right Earbud are paired with each other by default. You can trigger this connection by removing both Earbuds from the Charging Case. Both the blue and red LEDs on the Earbuds will start to flash. After 1-8 seconds the Earbuds will establish a connection with each other.

Next, the LEDs of the Master Earbud will flash blue and red, this means AIRWALKS is attempting to establish a connection with your Bluetooth device. The LED on the Second Earbud will turn off.

Inserting the Earbuds into the Charging Case switches them off and allows them to recharge.

# Connecting

## SETUP THE EARBUDS CONNECTION

You have to reset the connection between the Earbuds if they fail to pair. In this case, simply follow these steps:

- 1 Make sure both Earbuds are switched off.
- 2 Press and hold both Earbuds control button for 5 seconds until the Earbuds LEDs flash in red and blue.
- 3 After 3-8 seconds the Earbuds will establish a connection with each other; the LEDs of the Master Earbud will flash blue and red, while the LED on the Second Earbud will turn off.

## **BLUETOOTH PAIRING**

Your AIRWALKS True Wireless Earbuds use Bluetooth to connect to your device.

After turning on both Earbuds (as explained in the chapter ‘Turning AIRWALKS On and Off’ on page 14), pair your device with “AIRWALKS” via your device’s Bluetooth settings page. The LED on the Master Earbud will stop flashing, and your AIRWALKS True Wireless Earbuds are now ready to use.

When previously paired with a device, AIRWALKS will automatically attempt to reconnect to this device after being switched off and on.



# Specifications

**Bluetooth version:** Bluetooth 5.0

**Operating distance:** Up to 33 feet (10 meters)

**Frequency:** 20Hz – 20kHz

**Music playtime:** Up to 4 hours

**Talk time:** Up to 4 hours

**Maximum playtime with Charging Case:** Additional 10 hours

**Battery capacity:** 50 mAh (Earbuds), 200 mAh (Charging Case)

**Dimensions:** 15.4 x 14.5 x 15.0 mm (Earbud)

**Weight:** 4.2 grams (Earbud), 65 grams (Charging Case)

# Troubleshooting

**Problem:**

No connection between AIRWALKS and your Bluetooth device.

*Solution:*


- Make sure AIRWALKS is fully charged and switched ON.
- Check that your device is available and supports the A2DP Bluetooth Profile.
- Move AIRWALKS closer to your device.

**Problem:**

Devices paired successfully, but still no sound.

*Solution:*

- Increase the volume of your device to its maximum level.
- Disconnect and reconnect your device with AIRWALKS.



*Note: to avoid damage to your ears, do not wear the Earbuds during this process.*

**Problem:**

When turning both Earbuds on, one (or both of the Earbuds) does not work.

*Solution:*

- Reset the Earbuds connection as explained in the chapter “Connecting” on page 16.

# Safety information

- Do not attempt to charge AIRWALKS by any means other than a USB charger, power bank or computer.
- Do not modify or disassemble the battery.
- Do not dismantle or modify AIRWALKS in any way.
- Do not expose AIRWALKS to moisture or immerse it in liquid.
- Do not keep AIRWALKS in an environment of excessively high temperatures, including intense sunshine. Only use the product within the following temperatures: 0° - 40°.
- Do not place AIRWALKS on flammable materials, such as bedding or carpets during charging.
- Do not touch AIRWALKS with wet hands.
- Disconnect the USB connector from the AIRWALKS Charging Case once fully charged.
- Do not connect input and output in reverse.
- Do not charge AIRWALKS in excess of the rating suggested.

- In the unlikely event that any liquid from the inside of this product gets into your eyes, do not rub your eyes. Wash your eyes immediately with clean water and consult a physician.
- All of TRNDlabs' products have been tested comprehensively. If you encounter any unusual heat, discoloration or product distortion during charging or storage, please stop using it immediately and contact the dealer. These issues may cause leakage, heat, smoke or ignition of AIRWALKS.
- AIRWALKS is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities (or lack of experience and knowledge) unless they have been given supervision or instructions concerning the use of AIRWALKS by a person responsible for their safety.





The contents of this document are subject to change.  
Download the latest version from  
[www.trndlabs.com](http://www.trndlabs.com).

If you have any questions about this document, please  
contact TRNDlabs by sending a message  
to [hello@trndlabs.com](mailto:hello@trndlabs.com).

© 2020 TRNDlabs. All rights reserved.



3031/2/EN