


CONTROLS



VOL

TONE

CONTOUR

DRIVE



COMMUNORE
OVERDRIVE

WHAT IS THE COMMODORE OVERDRIVE?

Welcome aficionados of drive! Inspired by another one of our all-time favorites, the classic Marshall BluesBreaker and crossbred with our beloved Imperial MKII, we are excited to present you with our retro themed, extra special Commodore Overdrive.

The Commodore offers a fresh spin on an old-school heavyweight by mating a specially tuned, low to mid-gain BB style drive circuit with the super sculpting output section of the Imperial. Carefully selected component values and asymmetric clipping offer an organic and natural sounding drive ranging from sweet and mellow to hot and spicy, while the Tone and Contour sliders allow you to dial in anything from black panel spank to Vox-ey chime and British growl.

With that said, go ahead - plug in, crank it up and let loose! We want you to have fun and enjoy!

WHAT DOES THIS DO?

Vol: Allows you to boost or cut your volume level.

Tone: Allows you to set darker tones as you lower the slider or brighter tones as you raise it.

Contour: This controls the midrange content of the tone stack by changing the frequency of the high pass filter. The effect of the contour slider becomes more apparent when the Tone is set to brighter positions. Raising the Contour slider increases mids while lowering the slider scoops mids.

Drive: Allows you to increase or decrease the amount of distortion and gain. The overall sound of the pedal will get warmer as you decrease the drive and provide more cut and bite as you increase the drive.


True Bypass Switch: Allows you to engage or bypass the effect.

9V DC Input: This pedal uses a negative ground, 9-18VDC power supply with a 2.1mm barrel plug and negative center. Current draw is less than 10mA.

IMPORTANT: USE OF AN IMPROPER POWER SUPPLY WILL VOID WARRANTY


TRY OUR SETTINGS

CONTROLS




FULLERTON

CONTROLS




DIRTY BOOSTER

CONTROLS




LIVERPOOL

CONTROLS




THE OL' EVERYTHING AT NOON

CONTROLS



BLETCHLEY

CONTROLS



CLASSIC OVERDRIVE

WARRANTY INFORMATION

All SolidGoldFX products purchased through the solidgoldfx.com website or our authorized dealers come with a three-year warranty against failure resulting from defective parts and/or faulty workmanship. Cosmetic flaws or issues related to wear and tear are not covered.

The warranty applies only to the original owner of the product and is not transferable. Warranty coverage terminates three years after the owner receives the product. While a product is under warranty, the product will be repaired free of charge. The owner of the product will be responsible for both shipping to and from SolidGoldFX. Warranty coverage will be automatically cancelled should the product be tampered with, modified, abused, damaged through misuse, repaired by an unauthorized third party, or damaged through failure to follow the operating instructions. Use of an improper power supply will void warranty.



MONTREAL, CANADA

WWW.SOLIDGOLDFX.COM

INFO@SOLIDGOLDFX.COM

SOCIAL @SOLIDGOLDFX