

# Vantage PRO2™ INSTALLATION DIAGRAM

## Wireless Repeater Network with Multiple Stations

This diagram shows a Wireless Repeater network, comprised of a Vantage Pro2™ sensor suite, a Temperature/Humidity sensor in a Sensor Transmitter, and a Leaf and Soil Moisture Station, all transmitting to a Wireless Repeater. The Wireless Repeater is relaying the data from each of the three stations to a WeatherLink® console or a WeatherLink Live™.

