

Vantage PRO2™ INSTALLATION DIAGRAM

Wireless Repeater Daisy Chain (One Station, Multiple Repeaters)

This diagram shows a Wireless Repeater network, comprised of a Vantage Pro2™ sensor suite transmitting to a Wireless Repeater. The initial Wireless Repeater is relaying the sensor suite data to two additional Wireless Repeaters, and the data is then relayed to a WeatherLink® console or WeatherLink Live™. An installation with these instruments can transmit the sensor suite data up to 4000' (1200 m) outdoors,

