## Vantage PRO2 INSTALLATION DIAGRAM

## **Wireless Repeater Combination Network (Multiple Stations & Repeaters)**

This diagram illustrates how a WeatherLink® Console can receive data from up to eight different transmitting stations. In this arrangement, a Vantage Pro2 sensor suite is transmitting data to a WeatherLink Console via a daisy chain of three Wireless Repeaters. At the same time, the Wireless Repeaters are receiving and relaying data to the console from a collection of wireless instruments including a Leaf and Soil Moisture Station, the Anemometer in a Sensor Transmitter, a Temperature/Humidity Sensor in a Sensor Transmitter, and a Stainless Steel Temperature Probe in a Sensor Transmitter.

