

# LYCAN<sup>®</sup>

GAMING


# NEMESIS

## MULTIMEDIA

## GAMING KEYBOARD

Model: LGKBMEMM

## USER MANUAL



## FEATURES


- 117 Keys Total
- 104 Standard Keys including 12 Function Keys
- 7 Multimedia Buttons
- 6 Macro Keys
- 26 Anti-Ghosting Keys
- RGB Lighting
- Palm Rest
- 1.8m USB Braided Cable
- Plug & Play

## SPECIFICATIONS

- Current max: 200mA
- Compatible with Windows 2000, XP, Vista or Windows 7, Windows 8, Windows 10
- Compatible with Mac OS X v10.0 or later. Note this may exclude Function Keys (F1 to F12).



## CONNECTION

- ① Connect USB plug of keyboard to USB port on your desktop computer or laptop.




- ② LED on keyboard will illuminate once it is connected and ready to use.

## MULTIMEDIA KEYS



## FUNCTION KEYS



## RGB BACKLIGHT CONTROLS



Seven colours steady stream



Seven colours chasing



Seven colours breathing



Three colours sequential flashing



Eight colours switch: Red (default), green, blue, yellow, light blue, purple, white, multicolour



Seven colours wave pattern



Customised zones: Press FN+7 twice in 2 seconds to enter study mode, all the lights will flash twice. Press FN + ↑←↓→ to choose the zone, FN + ↑/↓ to change the colour of the zone



Seven colours by key stroke




Adjust the direction of lights






Increase / Decrease RGB Backlight Brightness

## MACRO KEYS



A macro key can be used to create a shortcut of key sequences. A sequence can be recorded with a single key or a combination of keys. G1-G5 keys can be manually recorded, and each macro can be recorded at 15 bytes maximum.

- ① Press Rec key to start recording and press the valid macro key (G1-G5) you want to record your sequence to after the  LED light above the number keypad illuminates.
- ② Press one of the G1-G5 macro keys to stop recording. Once  LED light stops flashing and returns to current state, the recorded content will be stored in the applicable macro key.
- ③ Press the Rec key to exit recording. Alternatively, if there is no action for 30 seconds, the recording will automatically exit. The  LED light will then return to current state after exiting.
- ④ Press FN+Esc keys for 3 seconds to clear the macro recording information. The default setting will be restored after the middle of the keyboard illuminates sequential flashing of red, green and blue colours.

## WARNING

- Keep keyboard away from water and moisture to avoid any damage to hardware.
- Keep keyboard away from direct sunlight to avoid colour fading.
- Regularly wipe dust from keyboard with dry cloth to extend keystroke lifespan.

Windows is a registered trademark of Microsoft Corporation in the United States and/or other countries.

Mac is a trademark of Apple Inc., registered in the U.S. and other countries.



v2

**BRED FOR GAMING**

[www.lycangamer.com](http://www.lycangamer.com)