

S5000

User's Manual


取扱説明書

使用说明书



Manufacturer / 製造 / 製造商
final Inc.

Product Overview




List of Items in Package

Main unit, Carrying case, Ear tips, Ear hooks TYPE A

How to Mount the Ear Hooks


After attaching the ear hooks to the cables, insert the housings into each ear, hook the ear hooks over the ears and adjust the fit.

* Using the ear hooks makes for an even more stable fit, and also makes for a reduction in touch noise.



Note on Use of the Detachable Cable

- The connection terminals are not designed for frequent attachment and detachment. Repeatedly connecting and disconnecting the terminals may lead to wear, damage, and contact issues. Please avoid detaching the cables except when replacing damaged cables or when switching to a separately sold cable by our company.
- To prevent damage to the connecting terminal, please ensure that all parts are held straight when connecting or disconnecting them.
- When disconnecting them, do not pull on the cable; ensure that you hold the plug (metal section).
- In the event that evidence of excess wear or damage to the connecting terminal is recognized, the product will not be covered by the warranty, even during the warranty period.



Regarding Ear Tips

- Use the ear tips in their original shape. Please do not compress them.
- The foam material used in the ear tips will deteriorate more quickly if it comes into contact with alcohol or other liquids, so please avoid contact with liquids.
- Do not use the ear tip if it becomes wet, remove the moisture and ensure it is thoroughly dry before use or storage.
- If the ear tip becomes dirty, avoid washing it with water or using wet wipes. Gently wipe it with a clean, dry cloth.
- The ear tips use foam material. It may get scratched or deformed, so please be careful not to rub it or let sharp objects or adhesive tape touch it. Handle the product with care to avoid damage. Do not pull or squeeze it forcefully. Do not leave this product under pressure for an extended period, as it may become deformed and difficult to return to its original shape.
- The ear tips naturally deteriorate over time and may no longer perform as intended. In such case please replace the ear tips. The recommended replacement interval is every 3 months.
- If you wish to purchase additional ear tips, please consult your local distributor or dealer.



Regarding the Carrying Case

Pull the lid out to open the case; store the earphones inside, then close the lid, ensuring that all three tabs are securely fastened. The lid may open if the case is exposed to inordinate force.

Please scan the QR code or access the link below to view a how to video.

<https://youtu.be/Tb0mNscs6s>



Notes on Use

| | | |
|--|-------------------|---|
| | WARNING | Ignoring the content of this indication could result in death or serious injury. |
| | PROHIBITED | Do not use the earphones while driving a bicycle, car or motorcycle. Doing so could cause a traffic accident and/or serious injury. |
| | PROHIBITED | Do not use the product while walking in dangerous environments such as near a railroad crossing or intersection where you cannot hear sounds from the outside. |
| | CAUTION | Ignoring the content of this indication could cause injury or damage to household articles in the vicinity. |
| | PROHIBITED | When using the earphones, be careful not to play the sound too loud. Doing so for a long period of time could affect your hearing. At 80 dB(A) exposure time shall be limited to 40 hours/week, whereas at 89 dB(A) exposure time shall be limited to 5 hours/week. |
| | PROHIBITED | If you experience skin irritation, stop using the product immediately and seek medical attention, or consult with our sales agent. |
| | PROHIBITED | If the sound volume is too loud, sound can be heard by other people. Use care not to disturb other people. |


- The way you position the earphone in your ear affects the sound quality. We recommend trying different positions by moving the earphone around while playing music. This will allow you to find the position that generates your most preferred sound. Once you figure out your favorite position it will be easy to set that position each time. The shapes of a person's right ear and left ear are usually different. Therefore, the best position for each ear is usually different as well.
- When removing the earphone from your ears, always hold the main unit first and then remove. Pulling the cord could cause the wire to become disconnected.
- Do not apply strong impacts to the earphones or put excess force on the cable. If the product fails or wires are broken due to abnormal use, the product warranty is invalidated.
- Leaving the product in locations exposed to direct sunlight, high humidity, or a dusty environment could cause the product to fail.
- If the product fails, do not attempt to disassemble.
- The earphone jack is for stereo reproduction only. If the earphone is connected to a monaural output jack, sound may not come out of one side.

Maintenance

Please take safety precautions and gently remove any build-up from the dust filter by using a cotton swab.

After use, please wipe away dirt and oil with a soft, dry cloth. Although the earphone housing is made of metal, do not use silver cloths or other polishing agents. Also, avoid using wet wipes or other items containing alcohol.

The cable may harden if it comes into contact with certain chemical agents and in particular with the natural oils in human skin. After using the product, please wipe the cable with a soft damp cloth. Please refrain from using wet wipes that contain alcohol; using these may result in hardening of the product. Please also refrain from using alcohol-free wet wipes; these may contain a variety of other additives which may adversely affect the product.



Warranty and After-Sales Service

The warranty for this product is valid for 2 year from the date of purchase. During the warranty period, we will repair the product based on the provisions below. The warranty is only valid in the country in which the product was purchased. Regarding questions pertaining to repairs, please contact the store you purchased the product from or contact us by visiting our "Contact" page.

- During the warranty period, we will repair the product free of charge if the product failed even though it was used in accordance with the instructions in the user's manual and the point of caution sections.
- In the following cases, repairs to the product will be subject to a fee even during the warranty period:
 - (1) Original purchase receipt or other documentation showing the date of purchase are failed to be presented.
 - (2) The product is identified to be modified, disassembled, or repaired by a third party or customer other than our company or our authorized organizations.
 - (3) The earphones were subjected to a strong impact or were allowed to get wet. Product failure resulting from an excessive use of force on the product.
 - (4) Failure due to fire, earthquake, wind, flood, lightning, or other acts of God, human error, theft, or virus and malware infection.
 - (5) Repair of scratches on the surface of the housing or repair of the housing itself
- We shall not be liable for any incidental or consequential damages for breach of any express or implied warranty or condition on this product. Nor shall recovery of any kind against us be greater than the original purchase price of the product from us or an our authorized dealer.


Contacting Us

Please contact us regarding inquiries using the Contact Form on our website:
<https://final-inc.com/pages/lang-contact>

Specifications

| | | | |
|--------------|----------|-----------------------|--------------|
| Product code | FI-S5BSB | Impedance | 47 Ω |
| Housing | Brass | Sensitivity | 111 dB/mW |
| Driver | BA | Weight / Cable length | 28 g / 1.2 m |

各部の名称




同梱品

本体、キャリーケース、イヤーピース、イヤーフックTYPE A

イヤーフック装着方法


イヤーフックをケーブルに装着した後、筐体を耳に挿入し、イヤーフックを耳にかけて、フィット感を調整してください。

※イヤーフックを使うと筐体をさらに安定して装着でき、またタッチノイズを軽減することができます。



着脱式ケーブルの注意点

- 接続端子は頻繁な抜き差しを想定したものではありません。着脱を繰り返すと、端子の摩耗や破損による接触不良を引き起こす事がございますので、ケーブル断線時の交換や弊社別売ケーブルへの交換以外での着脱はお控えください。
- 接続端子の破損を防ぐ為、まっすぐ抜き差しを行なってください。
- 取り外しの際はケーブルを引っ張らず、必ずコネクタ（金属部分）を掴んでください。
- 接続端子に過度の摩耗や破損の形跡が認められた場合は保証期間内でも保証対象外となります。



イヤーピースの注意点

- 指で潰さず、自然な形のままで耳に挿入してください。
- 早期劣化の原因となりますので、アルコールやその他の液体を付着させないでください。
- 湿ってしまった場合は水気を切り、十分に乾燥したことを確認してから、使用・保存してください。
- 汚れた場合は、水洗いやウェットティッシュなどの使用は避け、乾いた清潔な布等で軽く拭いて取り除いてください。
- フォーム素材を使用しています。破損の原因となるため、強く引っ張ったり、潰したりせず、丁寧に扱ってください。擦ったり、先の鋭利な物や粘着テープ等が触れないように注意してください。また、力を加えたまま長時間放置しないでください。変形して元に戻りにくくなるおそれがあります。
- イヤーピースは消耗品です。使用状態や保存状態にかかわらず、経年変化により自然劣化します。劣化すると本来の性能が機能しなくなりますので、お早めに新しいイヤーピースに交換してください。交換目安は3ヶ月です。
- 追加購入をご希望の場合は弊社WEBサイトの「SUPPORT」ページよりお問い合わせください。



キャリーケースについて

裏返して蓋を開けてイヤホンを収納し、蓋を閉じて3箇所あるツメがしっかりと留まっていることを確認してください。過度の衝撃が加わると、蓋が開いてしまう場合がございます。十分にご注意ください。

収納方法は下記リンクもしくはQRコードより動画をご参照ください。



<https://youtu.be/xzhwqs1agTQ>

使用上の注意

| | |
|------|--|
| ⚠ 警告 | この表示を無視して誤った取り扱いをすると、人が死亡または重傷を負う原因となる内容を示しています。 |
| 🚫 禁止 | 自転車や自動車、オートバイなどを運転しながらのイヤホンの使用は絶対に避けてください。交通事故を引き起こす原因となり、重大な結果を引き起こす恐れがあります。 |
| 🚫 禁止 | 運転以外であっても、路切や交差点など、周囲の音が聞こえないと危険な環境では、ご使用にならないでください。 |
| ⚠ 注意 | この表示を無視して誤った取り扱いをすると、人が負傷を負う、または周囲の家財に損害を与える可能性がある内容を示しています。 |
| 🚫 禁止 | イヤホンをご使用の際には、音量を上げすぎないように気をつけてください。長時間、大音量での使用は、難聴を引き起こす可能性があります。80 dB(A)の音量で40時間/週、89 dB(A)の音量で5時間/週を超えないようにしてください。 |
| 🚫 禁止 | イヤホンが肌にあわないと感じられた際には、お早めに使用を中止し、医師もしくは販売店に相談ください。 |
| 🚫 禁止 | 音量を上げすぎると、音は外部に漏れます。周囲の人の迷惑にならないように気をつけてください。 |

・装着位置によって音質が大きく変化いたします。音楽を再生しながら片方ずつ本体を立体的に動かし、最も好ましく聴こえる位置に合わせてください。それがベストポジション（最適位置）です。一度体験すると、二度目からは無理なく位置を合わせることが可能です。通常耳の形状は左右で大きく異なります。そのため、ベストポジションは左右の耳で異なります。

・耳からイヤホンを外す際には、本体を持って外してください。ケーブルを引っ張って外すと、ケーブル断線の原因となります。

・筐体が金属製のため、寒い戸外から室内へ持ち込むなど、急激な温度変化の際、筐体内部で結露します。その際はしばらく時間をおいて、内部が乾燥してからご使用ください。

・イヤホンに強い衝撃を与えたり、ケーブルに無理な力がかからないようにしてください。誤った使用状況下での故障や断線等は保証の対象外となります。

・直射日光の当たる場所、湿気、埃などの多い環境に放置すると、故障の原因となります。


・このイヤホンのプラグはステレオ再生専用となっています。モノラル出力ジャックに接続した場合には、片側から音が出ない可能性があります。

メンテナンス

・ダストフィルターに付着したゴミは、安全について十分ご留意いただき、たとえば綿棒の先端にゴミを付着させるかたちで、ゴミが内部に落下しないようにやさしく取り除いてください。

・使用後は水気のない柔らかい布で皮脂などの汚れをやさしく拭き取ってください。シルバークロスなどの研磨剤が入ったものやウェットティッシュなどのアルコール成分が入ったものは使用しないでください。

・ケーブルは様々な化学物質、特に皮脂と反応し、硬化する場合がございます。製品使用後は、ケーブルを水で少し湿らせた柔らかい布で拭いてください。硬化の原因となりますので、アルコール入りのウェットティッシュのご使用をお控えください。ノンアルコールのウェットティッシュも様々な添加剤が入っている可能性がありますのでご使用をお控えください。



保証とアフターサービス

本製品の保証期間はお買い上げ日より2年間です。保証期間中は以下の保証規定に基づき修理いたします。保証はご購入いただいた国でのみ有効です。修理のお申込みのほか、居住国以外の国でご購入の場合や保証期間後のサポートについては弊社WEBサイトの「SUPPORT」ページよりお問い合わせください。

- 保証期間内に、取扱説明書に記載の警告、注意書きに従った使用状態で故障した場合には、無償修理させていただきます。
- 保証期間内でも次の場合には、有償で修理させていただきます。
 - (1) レシート等、購入日を証明するものをご提示いただけない場合。
 - (2) 弊社および弊社が指定する機関以外の第三者やお客様により改造、分解、修理がなされた場合。
 - (3) 強い衝撃を与えたり、水に濡らした場合。無理な力がかかるような状況下で起こった故障。
 - (4) 火災、地震、風水害、落雷、その他天変地異などによる故障、人災による故障、盗難、ウイルス感染による故障。
 - (5) 筐体表面の傷の修理、筐体自体の修理。
- 本製品のご使用により、お客様に生じた損害については弊社は一切その責任を負わないものとします。また、いかなる場合でも、弊社が負担する損害賠償額は、お客様がお支払いになったこの商品の代価相当額をもって、その上限とします。

お問い合わせ


お問い合わせの際は、弊社WEBサイトの「SUPPORT」ページをご確認ください。

<https://final-inc.com/pages/support-top>

仕様

| | | | |
|-------|----------|------------|--------------|
| 製品コード | FI-S5BSB | インピーダンス | 47 Ω |
| 筐体 | 真鍮 | 感度 | 111 dB/mW |
| ドライバー | BA型 | 重量 / ケーブル長 | 28 g / 1.2 m |

部件名称图




配件

耳机本体、收纳盒、耳胶套、耳钩 TYPE A


耳挂配戴方法

将耳机线压入耳挂的凹槽，配戴耳机后，再将耳挂调整到最服贴的位置。
※使用耳挂有助于稳定耳机的位置，同时减少耳机线的颤噪音。



更换耳机线时的注意事项

- 连接端口不宜频繁拆装，频繁拆装会造成过度磨损导致接触不良等可能情况产生，除非耳机线断线需要交换或者更换本公司另外販售的耳机线以外，请尽量避免拆装。
- 为防止连接端口受损，请垂直安装或拆卸。
- 拆卸时请勿拉扯线材，请务必紧捏连接端口（金属部分）。
- 即使在保修期内因不正当使用造成连接端口的过度磨损或损坏，也不在保修范围之内。



关于耳胶套

- 请勿用手指捏压附属的耳胶套，请保持自然形状插入耳朵。
- 附属的耳胶套使用的海绵材料接触酒精或其他液体会加速劣化，因此请避免接触液体。
- 如果附属的耳胶套弄湿了，请去除水分，确保完全干燥后再进行使用和存放。
- 如果附属的耳胶套变脏，请避免使用水洗或湿纸巾，建议使用干净的干布轻轻擦拭去除污垢。
- 附属的耳胶套采用海绵材料制成，请注意避免摩擦、接触锋利物体或粘性胶带等，以免导致受损或变形。请小心使用，为避免损坏，请勿用力拉扯或挤压。请勿对本产品施加压力的情况下长时间放置，可能会导致变形且难以恢复。
- 附属的耳胶套为消耗品，无论使用状态或保存状况如何，随着时间推移会自然劣化。当劣化导致性能下降时，请尽早更换新的耳胶套。建议每三个月更换一次。
- 如需购买额外数量的耳胶套，请咨询当地的经销商或代理商。



关于收纳盒

将收纳盒盖子打开后，将耳机往内存放，盖子盖上时请确认 3 处卡榫处是否已固定住。受到过度冲击时，有可能造成收纳盒的盖子翻开，使用上请注意。

收纳方式请参阅以下连结或是透过 QR 码参阅影片说明。



<https://youtu.be/Tb0mNscs6s>

使用时的注意事项

| | |
|------|---|
| ⚠ 警告 | 忽略该标示导致使用方式上的错误，有可能造成生命危害或重大的伤害。 |
| 🚫 禁止 | 在自行车、汽、机车等交通工具行驶间，请勿使用耳机，以免造成重大交通意外事故。 |
| 🚫 禁止 | 行驶车辆以外，在平交道、十字路口…等、周遭声音如果听不到有可能造成危险的环境下，请勿使用。 |
| ⚠ 注意 | 如果忽略该标示，可能会导致他人受到伤害，或周边设施财产的损害。 |
| 🚫 禁止 | 使用耳机时，请将音量控制在适当范围。长时间、大音量的使用，有可能造成听力受损。应避免每周以 80dB(A) 音量播放超过 40 小时，每周 89dB(A) 的音量播放超过 5 小时的使用量。 |
| 🚫 禁止 | 在使用耳机的过程中，如肌肤感到不适，请立即停止使用，并尽快向医师或经销商咨询。 |
| 🚫 禁止 | 音量过大时，声音会有外漏的情形，请顾虑旁人的情况，不要造成他人的困扰。 |

· 佩戴位置的不同会在音质上带来很大的变化。建议音乐播放的同时，请将左右耳机一次一边做轻微移动调整，找到听得最清楚到且自己觉得最好的声音位置。这个位置即为该耳机的最佳佩戴位置。一旦找到位置，接下来佩戴时都会自然而然的往这个位置进行调整。通常左右耳朵的形状大小存在这差异性。因此左右耳的最佳佩戴位置也可能会有所不同。

· 当耳机要从耳朵上取下时，请抓住耳机本体后再取下。如果以拉扯耳机线的方式，可能成为造成耳机线接触不良的原因。

· 请勿让耳机受到强力撞击、线材部分承受过度的外力拉扯。不当使用造成产品故障及断线等情况将不在保修范围内。

· 请勿将耳机放置于日照能直射、潮湿及多尘的环境下，有可能导致产品故障。

· 产品故障时请勿自行拆解。


· 耳机线插头属于双声道播放用专用插头。使用于单声道设备时，可能会造成单边耳机静默的情况。

耳机保养

请在采取安全防范措施的情况下，请使用棉签棒轻轻地清扫滤网上所残留的尘埃，耳垢等污迹。

使用后，请使用干燥的柔软布轻轻擦拭油脂等污垢。虽然耳机外壳为金属材质，但请勿使用含有抛光剂或银布等的抛光用具。此外，请避免使用含酒精成分的湿巾。

耳机线材会与化学物质产生反应，特别是与皮肤油脂接触时会产生硬化现象。使用完本产品后，请以柔软的布料稍微沾湿后进行清洁。酒精成分会造成线材的硬化现象，请避免使用。不含酒精的湿纸巾也可能含有各种添加物，请避免使用。



保修以及售后服务

敝社产品的保修期自购买日起二年内有效。保修期内将按照敝社的保修条款提供维修服务。保修对象仅对该产品的购买国家有效。如果您对本产品有任何疑问或寻求售后服务时，请向购买店家或代理商进行咨询。

1. 商品在保修期内，且遵守使用说明，仍产生故障，敝社将免费提供维修服务。

2. 商品在保修期内，但出现以下情况，敝社将酌情收取维修费用：

- (1) 无法提供发票等能证明购买日的文件。
- (2) 敝社及敝社所认可特定机关以外的第三方或是客人自身所进行的改造、分解、修理等情况。
- (3) 商品在使用过程中受到强烈的外力冲击、进水等情况。故障因受到不合理外力而致使断裂的状况。
- (4) 由于火灾、地震、风、洪水、雷电或其他天灾造成的故障，以及由于人为错误、盗窃或病毒和恶意软件感染而造成的故障。
- (5) 表面痕迹清除、单独腔体维修。

3. 本公司对因使用本产品所造成的任何损害概不负责。任何状况之下，承担的损害赔偿金的最高金额是相当于客人购买本产品的价格。

咨询方式

请至敝社网店「连络」的连接页面中「连络表格」处填写相关资讯后发送即可取得连系。

<https://final-inc.com/pages/lang-contact>

规格

| | | | |
|------|----------|-----------|--------------|
| 产品型号 | FI-S5BSB | 阻抗 | 47 Ω |
| 外壳材质 | 黄铜 | 灵敏度 | 111 dB/mW |
| 单元类型 | BA | 重量 / 线材长度 | 28 g / 1.2 m |