Diffuser Cheat Sheet DAVINCI-PENTHOUSE



SET CURRENT DATE & TIME

The diffusers run on military time

Press SET x 1: Select the hour (press up or down arrows)

Press SET x 2: Select the minutes (press up or down arrows)

Press SET x 3: Select the day (little triangle indicates what day is currently selected, uses arrows to change)



SET THE VOLUME, LEVEL & mL/H

Press SET x 4: Adjust volume to 200 (press up or down arrows)
Press SET x 5: Adjust level to 200 (press up or down arrows)
Press SET x 6: Adjust mL/H to 5.0 (press up or down arrows)
Press SET x 7: Takes you back to the home screen and saves the settings

The diffuser should have a green light to indicate that there is a full bottle of oil

SETTING UP EVENTS

Events let the diffuser know when to run. You can set up to 5 unique events

Press MODE x 1: Turn Event 1 ON - THEN

- Press SET x 1: Set the hour the event should START
- Press SET x 2: Set the minute the event should START
- Press SET x 3: Set the day(s) the event should run
 - If you wish to deselect/ select a day, go to that day and press the power button, and the triangle will either appear (select) or disappear (deselect)



SETTING UP EVENTS (cont.)

Press MODE x 2: Turn Event 1 OFF - THEN

- Press SET x 1: Set the hour the event should END
- Press SET x 2: Set the minute the event should END

Press MODE x 3: Set the WORK

• This is the running/misting time during the event

Press MODE x 4: Set the PAUSE

• This is the pause/non-misting time during the event

Repeat steps for 'Setting Up Events' to add additional events



Diffuser Cheat Sheet

RECOMMENDED SETTINGS

Stand Alone

Event 1 ON - 08:00 Event 1 OFF - 22:00

Work: 30 Pause: 170



GOOD TO KNOW

- You can not have any overlapping events, if any events are overlapping, the machine will **not** scent
 - Example:
 - Event 1: Monday-Friday 9 am-5 pm
 - Event 2: Monday- Wednesday 1 pm-3 pm
- You can **lock and unlock the touchscreen** by holding the SET button until the machine beeps. A lock will display on the screen when it is locked
- You can reset the machine by holding the MODE button
- You can turn the light on the diffuser on and off by holding the POWER button
- The color shown on the diffuser indicates how much oil is left in the machine
 - o Green: More than 50% of the oil remaining
 - o Blue: Between 25-50% of the oil remaining
 - Red: Less than 25% of the oil remaining
- If a new bottle of oil is put in the diffuser and the light is still blue or red, reset the volume and level
- Volume is the size of the bottle in the machine, Level is the amount of oil in the machine