

AROMA360

SMART CAR DIFFUSER

Instruction Manual

Before using the Aroma360 Smart Car Diffuser, please read all the instructions carefully to ensure the best scent experience possible.


Warning:

- When using this product, please make sure that your power cords and plugs are not damaged. Damaged cords and plugs can compromise the safety of your diffuser.
- Please do not take this product apart. Doing so will damage the machine and make it unable to scent properly.


Table of Contents

Product and Accessories information	Page 1
How to use your Smart Car Diffuser	Page 2
Helpful Hints for using your Smart Car Diffuser	Page 2
Controlling the intensity of your Scenting Experience	Page 3
The Auto Smart Start and Stop Function	Page 3
Scenting Modes for your Diffuser	Page 4
Troubleshooting for your Diffuser	Page 5

Product and Accessories Information



Aroma360 Smart Car Diffuser



USB Charger



Smart Car Diffuser Refill Bottle




Manual



Silicon Adhesive



Cotton Core



1. Multi Function Button
2. Indicator Lights of Intensity Level
3. Charge Indicator Lights
4. Oil Atomizer
5. Charging Port

How to use your Smart Car Diffuser

Instructions for installing/replacing your Aroma360 Smart Car Diffuser Refill

- 1 While your diffuser is powered off, unscrew the bottom metal cover.
- 2 Note: Do not tilt or turn the diffuser upside down if filled with oil. The oil will spill out.
- 3 Unscrew the Aroma360 Smart Car Diffuser Refill bottle by turning counterclockwise. Clockwise will lock the bottle in.
- 4 Take your new or refill bottle of Aroma360 oil remove the cap and place the cotton core into the hole.
- 5 Using a clockwise rotation, screw the new or refill bottle back into the machine.
- 6 To keep your Aroma360 Smart Car Diffuser working and scenting properly, please make sure to clean the oil atomizer every time the oil is changed. Cleaning is simple. Using a cotton swab lightly dabbed the oil atomizer which will remove any excess oil.

Helpful Hints for using your Smart Car Diffuser

- To prevent oil from leaking, make sure when you replace the bottle that it is securely twisted into the diffuser.
- When using your Aroma360 Smart Car Diffuser, always keep the machine vertical. Placing the unit tilted or inverted will cause the oil to spill.
- When scenting, always use the non-slip mat included under your Diffuser. This will ensure that your Diffuser doesn't move or slip and operates correctly.

Controlling the intensity of your scenting experience

The helpful chart below will show exactly how high the intensity is with each time cycle.

Intensity level and time cycle

Intensity Level	•••••	••••	•••	••	•
Intervals (Seconds)	5	15	60	240	600

The Smart Auto Start and Stop Function

Your Diffuser is equipped with a sensor that automatically knows when your car is moving or turned on. While your Diffuser is powered on, it can automatically sense the vibration of your cars' engine. If it senses that your car is not powered on for 30 seconds, the diffuser is equipped with a sensor that automatically allow it to enter a "stand-by" state. No scent will be diffused in this state. If your Diffuser senses the car to be running while in this "stand-by" state, it will automatically start scenting again at the mode it is set to.


Scenting Modes for your Diffuser

- **Turning On and Off:** To turn your Smart Car Diffuser on, press the power button for 3 seconds. This will turn the machine on. Lights will appear to indicate that the Diffuser is powered. By holding down the power button for 3 seconds, your Smart Car Diffuser will shut down. The indicator lights will disappear at this point.
- **Scenting Mode:** To begin scenting, your Smart Car Diffuser must be powered on. Once the Smart Car Diffuser is powered on, press the power button once. The indicator lights will appear and show the current setting. The number of lights showing will reference the 5 different settings options. Continue to click the power button until you are at the desired amount of light indicators to match the setting wanted.
- **Proper Use:** Always make sure that your Diffuser is either connected to the power cord while the Smart Car Diffuser is powered on or has a proper battery supply. If the battery is low on your Diffuser, the scenting function will be stopped, and the indicator lights will all flicker once, this is to remind you that the battery is low and needs to charge.

Troubleshooting for your Diffuser

Please see the box below before reaching out to customer service.
Most issues can be solved with the following troubleshooting tips.

Problem	Solution
No Scent	<ul style="list-style-type: none">• Check and make sure the indicator lights are displayed, and the Diffuser is on.• Make sure the battery level isn't low• Make sure the atomizer is cleaned with a cotton swab to remove any excess oil• Make sure your bottle isn't empty in the Diffuser.• Make sure that the scenting cotton core is installed properly.
The Scent isn't strong/barely works	<ul style="list-style-type: none">• Check that the cotton core inside the oil bottle is properly installed and that the spring is inside of it.• Make sure the atomizer is cleaned with a cotton swab to remove any excess oil
Fragrance Oil leaks	Check that the bottle is secure.
Abnormal noise from the Diffuser	<ul style="list-style-type: none">• Make sure the cotton core inside the Fragrance Oil is connected.• Make sure your bottle isn't empty in the Diffuser.
Unable to power on	Ensure your Diffuser is charged.



AROMA360

WWW.AROMA360.COM

Phone: 1-855-441-1219

Email: support@aroma360.com