


Samaya ASSAUT2 8K

Pitching of the tent

STEP 1

For each pole, insert the poles' sections into each other, making sure that the narrow part fits completely into the other part.




N.B. During the set up, the black section is inserted first because it comes up against the end of the sleeve, while the «Lock Tip» is inserted into the eyelet.

STEP 2

Insert the grey (left (2)) then right (1)) poles into the sleeves present on each side of the door. Insert first the black section until it reaches the end of the sleeve.

Insert each «Lock Tip» end pole into the corresponding eyelet.



STEP 3

Then insert the small top pole in its sleeve (3).

And insert the «Lock Tip» in its eyelet.




STEP 4

Finalise the set up thanks to the tension webbings present on the eyelets.



STEP 5

All tent anchor points must be used in any weather condition.



Pitching of the vestibule

- Remove the Dyneema® top from the top of your Samaya® to hang the vestibule instead.
- Insert the poles into the inner sleeve of the vestibule.
- Insert both «lock tips» into the corresponding eyelets.
- Use the hooks and adjusters to tighten the vestibule.
- Be sure to use all anchor points and guy lines under all conditions.
- Attach the velcro to hang the vestibule on the structure of your Samaya®.

Samaya.