


Samaya 2.5

Pitching of the tent

STEP 1

For each poles, insert the poles' sections into each other, making sure that the narrow part fits completely into the other one.



N.B. During the set up, the black section is inserted first because it comes up against the end of the sleeve, while the «Lock Tip» is inserted into the eyelet.

STEP 2


Insert the main orange pole into the sleeve with red indicator. The black section of the pole needs to be inserted first.

Push the pole through the sleeve until it reaches the back of the tent, in abutment at the end of the sleeve.



STEP 3

Then insert the two other poles, starting with the left (2) and then the right (3) as shown on the drawing.



STEP 4


Insert each «Lock Tip» of the poles into the corresponding eyelet.

Finalise the set up thanks to the tension webbings.



STEP 5

All tent anchor points must be used in any weather condition.



Pitching of the vestibule

- Remove the Dyneema® top from the top of your Samaya® to hang the vestibule instead.
- Insert the poles into the inner sleeve of the vestibule.
- Insert both «lock tips» into the corresponding eyelets.
- Use the hooks and adjusters to tighten the vestibule.
- Be sure to use all anchor points and guy lines under all conditions.
- Attach the velcro to hang the vestibule on the structure of your Samaya®.

Samaya.