

ALTECH LUPUS R32/R410A


Reservedelsliste



Altech®

ALTECH LUPUS R32/R410A

Indedel - Tegning




ALTECH LUPUS R32/R410A

Indedel - Komponenter

Nummer	Betegnelse	VVS nummer R32	VVS nummer R410A
11	Ventilatormotor	346869994	346869994
17	Ventilatorhjul	346869996	346869996
22	Hovedprint	346869955	346869954
25	Step-motor 1	346869953	346869953
26	Bøsning	346869958	346869958
27	Styrebladshåndtag	346869959	346869959
28	Step-motor 2	346869967	346869967
29	Håndsving	346869968	346869968
30	Vejledningsspjæld 1	346869969	346869969
31	Vejledningsspjæld 2	346869970	346869970
32	Udblæsningsspjæld	346869965	346869964
35	Displayunderenhed	346869971	346869971
36	Displaykort	346869991	346869991
37	Fjernbetjening	346869924	346869923
40	Nedre filter	346869992	346869960
41	Øvre filter	346869961	346869963

ALTECH LUPUS R32/R410A

Udedel - Tegning



ALTECH LUPUS R32/R410A

Udedel - Komponenter

Nummer	Betegnelse	VVS nummer R32	VVS nummer R410A
1	Gitter	346869973	346869973
4	Ventilatorvinge	346869997	346869997
17	Service ventil, 5/8"	346869974	346869974
18	Service ventil, 3/8"	346869975	346869975
12	Ventilatormotor	346869995	346869993
19	Ventil cover	346869976	346869976
36	Hovedprint	346869957	346869956
39	Filterkort	346869977	346869977
-	Spole til ekspansionsventil	346869810	346869810