



Owner's Manual

Introduction

VERB Square Evolution+ is a 7-mode mini digital reverb pedal suitable for any music style. 7 selected reverb effects and onboard controls offers you a wide tonal range, and additional effect tail control is very convenient for using in different scenarios.

Precautions

READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a convenient place for future reference.

Power Supply

Always use a DC 9V center negative AC adapter. Use of an adapter other than that specified could damage the unit or cause malfunction and pose a safety hazard.

Always connect the AC adapter to an AC outlet that supplies the rated voltage required by the adapter.

Disconnect the AC adapter from the AC outlet when during lightning storms or not using the unit for an extended period.

Connections

Always turn off the power before connecting or disconnecting. Make sure to disconnect all cables and AC adapter before moving the unit. This will help prevent malfunction and damages.

Environment Considerations

Avoid using the unit in any of the following conditions that could cause malfunction:

- Extremely hot or cold places
- Under direct sunlight
- Magnetic fields
- Near heaters and other heat sources
- Sandy or dusty places
- Places that are extremely humid or exposed to splashing water
- Places with lots of vibrations

Electrical Interference

Devices that are very susceptible to interference or that emits powerful electromagnetic waves (e.g. radios and TVs) should not be placed near this

unit, as interference could occur.

Electromagnetic interference could cause malfunction and could corrupt or destroy data.

Always operate this unit at a suitable distance from these devices.

Handling

Do not apply excessive force to the switches and other controls, exposing the unit to strong impacts, which could cause it to break.

Do not put foreign objects or liquids into the unit.

Never open the case or attempt to modify the product in any way since this can result in damage to the unit.

Clean only with a soft, dry cloth.

Overview

● 7 In 1 Reverb Pedal

The VERB Square Evolution+ comes with 7 carefully selected reverb effects, allowing you to easily create spatial effects or add sound dimensions to your tone. The light weight, compact-sized housing helps you keep your pedalboard tiny and easy to carry.

● Wide-Range Effect Controls

The VERB Square Evolution+ features an effect type selector and three effect parameter control knobs, gives you fully access to effect details, which makes it suitable for every music genre.

● Effect Tail

Hold the footswitch to switch effect tail

折起朝外

on/off when bypassed. You can keep the ambience going on when switching effects by turning on effect tail, or switch it off to keep everything clear.

● Carefully Selected Components
The VERB Square Evolution+ is designed and built with carefully selected components to ensure best sound quality and road performance. The solid Aluminum-alloy chassis ensures touring reliability.

Features

- Convenient compact size
- Buffer bypass
- 7 reverb effects in one pedal with wide tonal range
- Switchable effect tail
- LED indicator shows working state
- Suitable for any music style


Specifications

Power Requirement: 9V DC center negative
Current Consumption: 100mA
Dimensions: 42x93.5x52mm
Weight: g



www.donnerdeal.com

Connections & Controls



A DC 9V Jack:

For power supply, use a 9-volt DC regulated by AC adapter, 500mA (plug polarity is positive on the barrel and negative in the center).

B E.LEVEL Knob:

Controls the effect level.

C DECAY Knob:

Controls the duration of the reverberation.

D TONE Knob:

Controls the effects tone.

E Mode Selector:

For selecting from 7 effect types:

Mode	Description
ROOM	Simulates the acoustics of a room
HALL	Simulates the acoustics of a hall
CHURCH	Simulates the acoustics of a church
SPRING	Simulates a spring reverberator
PLATE	Simulates a plate reverberator
MOD	Produces a reverb effect with a lush, modulated sound
DARKSEA	Produces a reverb effect with deep, gloomy decay

F Input Jack:

1/4" mono audio jack, for connecting instruments or other pedals.

G Output Jack:

1/4" mono audio jack, for connecting to an amplifier or other pedals.

H Footswitch And LED:

TAP: Turn the pedal on/off, the LED will lit up when the pedal is on.
HOLD: Turn on/off reverb tail, the LED will pulse to indicate change.

折起朝外

技术要求:

120g书纸, 138*100mm, 四色印刷 (折起单面46*100mm)