

Instruction Manual

RECTA

To ensure correct care,
please take some time to review
the enclosed instructions to review
how to operate your watch.



Vol.1.07A EN

RECTA


ALTITUDE

RETROGRADE DUAL TIME

This watch is equipped with a unique
multi-function feature with a second time zone
read out and a 24 hour display feature.

For more details on operating this timepiece
please refer to the enclosed booklet or visit :

im.recta1897.com



(1st click) (2nd click)



CLOSED:

Pushed back and
Water Resistant



1

OPENED:


Not secured
for Water Resistance



2

HOW TO SET THE TIME


1. Pull the crown to position [2]-(**2nd click**).
2. Turn the crown clockwise to set the correct time.
3. Push the crown back to position [0].



* Take a.m./p.m. into consideration when setting the hour and minute hands to the desired time.

HOW TO SET THE DATE


1. Pull the crown to position [1]-(**1st click**).
2. Turn the crown clockwise to set the correct date.
3. Push the crown back to position [0].



* Do not set the date between 9:00 P.M. and 2:00 A.M.

HOW TO SET THE SECOND TIME ZONE

1. Pull the crown to position [1]-(1st click).
2. Turn the crown anti-clockwise to set the Dual Time. (The dual time hand at 6 o'clock position.)
3. Push the crown in, after the 2nd time (24H) has been set.



WATER RESISTANCE

The water resistance indicated on your timepiece serves only as a guide. Actual water resistance may vary depending on a number of important factors including temperature, water salinity, and actual use under water.


The water resistance of your timepiece may eventually be compromised over time with general wear and tear and the use of your watch under adverse conditions.

Always remember to employ the screw down crown (if available) to maintain the water resistance of your timepiece. Warranty may be voided if the screw down crown has not been properly employed.

Note that you should NEVER wear your watch in a jacuzzi, hot shower or steam room where steam may enter the case despite the watertight seals used to protect your watch.

The steam may cause condensation inside your watch, which may affect and damage the inner workings of your watch – which would also not be covered by the warranty.


HOW TO USE A DEPLOYANT CLASP




Press the buttons on the clasp sides.

HOW TO RESIZE METAL BRACELET


On the inside of the bracelet, you will see some small arrows engraved on removeable links.




2.



3.




4.




3

5.




6.




4

7.




8.


Nylon Head
Hammer




9.



10.



11.



12.

