
# Size: 9.45" x 4.72"



# **Instruction Manual**



Companion
Mini Aroma Diffuser

### Features

- Three Scent Settings
- Touch to Change
- Diffuses Oil Intermittently
- Uses a 30ml Bottle

### Power

- Rechargeable DC 5V Battery
- USB-C Cable Included
- Battery Lasts Up to 80 Hours on Low

### Scent Coverage

• Up to 300 sq. ft.


### Please Note:

- Keep the diffuser upright at all times to avoid spilling oil
- In the case of spilled oil, clean immediately with soap and water

Scan to Explore New Fragrances



### Parts



### Setup



1. Remove the atomizer to install the new bottle of oil.



3. Reinsert the atomizer into the diffuser body making sure the air nozzle lines up properly



5. Long press the control button to choose between car mode and home mode

2. Unscrew the empty bottle to remove and replace oil as needed



4. Use the charger and cable to recharge and power the diffuser



6. Enjoy the aroma

### Power on/off your diffuser

- Hold down the control button for three seconds and release
- The diffuser will beep once

### Introduction

- Your companion diffuser can operate in two different modes. Car mode and Home mode.
- When in Car Mode, the diffuser will automatically stop if external vibration has not been detected in the last five minutes. This ensures that you do not over scent your car when not in use. Home Mode works in a continuous cycle and does not utilize the vibration start stop sensors.
- The companion diffuser is designed for mobility. The diffuser utilizes an internal battery. Once the diffuser is activated, it will diffuse until the battery charge has been depleted.
- Simply recharge as needed.

# 6. Changing from Car Mode to Home Mode

- Long press the control button for more than six seconds to change modes.
- Two beeps indicates Car Mode.
- Three beeps indicate Home Mode.

# 7. Changing the Intensity Levels

There are three levels of intensity available for your desired scent settings.

- Level 1 (Low) is indicated by one LED light showing while diffusing It will spray for 5 seconds, then pause for 600 seconds.
- Level 2 (Medium) is indicated by two LED lights showing while diffusing. It will spray for 5 seconds, then pause for 180 seconds.
- Level 3 (High) is indicated by three LED lights showing while diffusing. It will spray for 12 seconds, then pause for 60 seconds.

# 8. Low Battery and Charging Instructions

- When the battery is low, you will see three LED lights flashing continuously. This means it is time to recharge your battery.
- Recharge your diffuser using your 5v USB charger and cable.
- During charging, you will see three LEDs flashing one by one in ascending order.
- Your diffuser is fully charged when all three LEDs are lit.

# 9. Pro Tips

- Keep the diffuser upright at all times to prevent spills and damage to the diffuser.
- Clean spilled oil immediately with soap and water.
- Spilled oil can damage any surface including furniture, plastic, leather, cloth, ect.
- Firmly tighten the oil bottle on the atomizer to reduce the chance of leaks.
- Always keep your diffuser on a level surface.
- When using in the car, place firmly in a cup holder only.
- Keep your diffuser clean.