

## **Operating Instructions**

EN | 3S-2061 3sixT Smart Stylus for iPad

#### **WARNING**

- Read all instructions and warnings before using this product.
  Improper use of this product may result in product damage,
  excessive heat, toxic fumes, fire or explosion, for which damages you
  ("Purchaser") and not 3sixT ("Manufacturer") are responsible.
- Do not store the accessory in a high-temperature environment, including heat caused by intense sunlight or other forms of heat (heaters etc.).
- $\boldsymbol{\cdot}$  Do not place the device in fire or other extremely hot environments.
- Do not disassemble or modify this accessory in any manner.
- Do not attempt to power this device using any other method than as instructed explicitly in this user guide.
- This accessory is intended for adults and not minors. Failure not to follow these warnings is the sole responsibility of the purchaser, who agrees to indemnify the Manufacturer ("3sixT") for any unintended use/misuse by a minor.
- All products must pass through a thorough quality inspection at the time of manufacture. However, if you find that your device is excessively hot, is found to be deformed outside its regular appearance or is emitting smoke, immediately stop using the device and contact 3sixT.

© 2021 3sixT. All rights reserved. 23/136 Keys Road, Cheltenham VIC 3192 Australia.


MADE IN CHINA

# **NAME PARTS** Touch Button -- Charging Port LED Indicator Magnetic Strip – NIP POM Plastic **CHARGING YOUR STYLUS** Computer Port Wall Charger Power Bank

#### **OPERATION**


1

Press the Touch Button, blue light turns on, now the stylus isin working mode




2

The stylus is ready to use for clicking, dragging, sketching, drawing, note-taking, etc. on iPad applications



3

Press the button again, the stylus will shutdown. Stylus will shutdown automatically if it is idle for 5 minutes



### **STYLUS COMPATIBILITY\***

Description	Screen Size	Model No#	iOS Version
iPad Mini Gen 5 (2019)	7.9"	A2126 / A2124 / A2133	12.2 & above
iPad Gen 6 (2018)	9.7"	A1954 / A1893	12.1.4 & above
iPad Gen 7 (2019)	10.2"	A2200 / A2198 / A2232	12.2 & above
iPad Gen 8 (2020)	10.2"	A2428 / A2429 / A2270 / A2430	14.1 & above
iPad Air Gen 3 (2019)	10.5"	A2153 / A2123 / A2154 / A2152	12.2 & above
iPad Air Gen 4 (2020)	10.9"	A2316 / A2324 / A2325 / A2072	14.1 & above
iPad Pro 11 Gen 1 (2018)	11"	A2013 / A1934 / A1980 / A1979	12.2 & above
iPad Pro 11 Gen 2 (2020)	11"	A2068 / A2230 / A2228 / A2231	13.1 & above
iPad Pro 12.9 Gen 3 (2018)	12.9"	A2014 / A1895 / A1876 / A1983	12.2 & above
iPad Pro 12.9 Gen 4 (2020)	12.9"	A2069 / A2232 / A2233 / A2229	13.1 & above

 $\ensuremath{^{\star}}\xspace \text{subject}$  to change/update without notice

#### **SPECIFICATION**

Item/Model No#:	3S-2061	
Input:	5V/2A	
Charging Type:	USB-C	
Length	16.7cm	
Diameter:	0.9cm	
Weight:	16.8g	
Battery:	140mAh Li-Po	
Working Time:	Approx. 9 hours	
Charge Time:	Approx. 1 hour	
Standby Time:	Approx. 1 Year	



www.3sixtgear.com or visit www.3sixtgear.com/support

