

Cona Installation Manual








Luminous Intensity Distribution Curve



OPTIONAL WITH SOLAR SOLUTIONS -FEATURES BELOW

Lighting Mode:Light Induction + Remote Controller



REMOTE CONTROL

Automatic Infrared control to Set-Time Control

AUTO WORKING MODE:

A.0-10 minutes 100% light B.1 hour 70% light C.2 hours 50% light D.3 hours 30% light

E.6 hours 12% light

