

<div data-bbox="181 233 272 279" data-label="Image"> </div> <p>Gripper Lighter</p> <p>USB Arc Lighters are a precision product with high quality and safety standards.</p> <p>HOW TO USE</p> <ol style="list-style-type: none"> 1. Slide the directional switch to the right. This will expose the 4 prongs 2. Press the button with the blue light to ignite 3. After 9 seconds the arc shuts off. Or press the button again to turn off 4. The power to the lighter is disabled after another 9 seconds of non-use. The blue light will go out 	<ol style="list-style-type: none"> 5. To restart the lighter slide switch to left in closed position then to the right in open position. 6. Keep lighter in closed position when not in use by sliding the switch to the left to cover the prongs <p>HOW TO CHARGE</p> <ol style="list-style-type: none"> 1. Connect the mini USB cable to the lighter and plug the cable into any power adaptor DC 5.0 volts. 2. Lighters take 1-2 hours to charge <p>DO NOT keep your lighter plugged in overnight. This prevents overheating and extends the battery life.</p>	<p>HOW TO CLEAN</p> <p>Residues can build up around the tip of the lighter which can affect the operation.</p> <ol style="list-style-type: none"> 1. Make sure the lighter is off and will not turn on while cleaning. 2. Use only a clean dry brush or cloth to gently brush the tip. 3. DO NOT use any abrasives or liquid cleaner. <p>ENSURE the tip of the lighter is clean at all times for best performance.</p> <p>WARNING! Strictly abide by the following safety measures</p>	<div data-bbox="1013 254 1235 310" data-label="Image"> </div> <p>KEEP AWAY from children & pets. Lighters are not toys</p> <p>DO NOT touch the arc when ignited, burn and electrical shock will occur</p> <p>KEEP the lighter away from any persons face, skin or combustible material.</p> <p>DO NOT expose the lighter to temperatures above or below 40C</p> <p>DO NOT place the lighter in direct sunlight while charging.</p>	<p>High temperatures may activate the protection mechanism; preventing the battery from being charged, or cause abnormal current or voltage when charging leading to fire, overheating or explosion.</p> <p>ENSURE the spark is extinguished after using.</p> <p>REMOVE the lighter from the flame once it is lit.</p> <p>For more info see website. www.sizzlelighters.com</p> <p>The Operator and Purchaser of Arc Lighters assume all liability and responsibility while using this product.</p>
--	---	--	---	--