
 <p><b>Survival Lighter</b></p> <p>USB Arc Lighter is a precision product with high quality and safety standards.</p> <p><b>HOW TO USE</b></p> <ol style="list-style-type: none"> <li>1. Pull down the lever and press the tab to flip open the lid.</li> <li>2. Press the black button to ignite the arc.</li> <li>3. Close the lid and ensure the lever is pulled up to lock the lid when not in use as a lighter.</li> <li>4. When the lid is closed press the black button to turn on the flashlight.</li> </ol>	<ol style="list-style-type: none"> <li>5. This lighter is only waterproof when the lid is closed and locked.</li> <li>6. Do not get the arc wet as it is not waterproof when exposed.</li> </ol> <p><b>HOW TO CHARGE</b></p> <ol style="list-style-type: none"> <li>1. Connect the USB cable to the ARC Lighter and plug the cable into any USB port that provides DC 5.0 volts.</li> <li>2. Lighters take 1-2 hours to charge</li> </ol> <p><b>DO NOT</b> keep your lighter plugged in overnight. This prevents overheating and extends the battery life.</p>	<p><b>HOW TO CLEAN</b></p> <p>Residues can build up around the tip of the lighter which can affect the operation.</p> <ol style="list-style-type: none"> <li>1. Make sure the lighter is off and will not turn on while cleaning.</li> <li>2. <b>Use only</b> a clean dry brush or cloth to gently brush the tip.</li> <li>3. <b>DO NOT</b> use any abrasives or liquid cleaner.</li> </ol> <p><b>ENSURE</b> the tip of the lighter is clean at all times for best performance.</p> <p><b>WARNING!</b> Strictly abide by the following safety measures</p>	 <p><b>KEEP AWAY from children &amp; pets.</b> Lighters are not toys</p> <p><b>DO NOT touch</b> the arc when ignited, burn and electrical shock will occur</p> <p><b>KEEP the lighter away</b> from any persons face, skin or combustible material.</p> <p><b>DO NOT expose</b> the lighter to temperatures above or below 40C</p> <p><b>DO NOT</b> place the lighter in direct sunlight while charging.</p>	<p>High temperatures may activate the protection mechanism; preventing the battery from being charged, or cause abnormal current or voltage when charging leading to fire, overheating or explosion.</p> <p><b>ENSURE</b> the spark is extinguished after using.</p> <p><b>REMOVE</b> the lighter from the flame once it is lit.</p> <p><b>For more info see website.</b> <a href="http://www.sizzlelighters.com">www.sizzlelighters.com</a></p> <p>The Operator and Purchaser of Arc Lighters assume all liability and responsibility while using this product.</p>
---	--	--	---	--