

## User Manual STORAGE SHED with FLAT LID 1200L





Make sure fingers don't get squeezed between parts during assembly

## A CARE AND SAFETY

- To avoid any sort of damage, read and implement every step in the instruction manual carefully.
- Keep fingers away from connectors to avoid risk of injury during assembly.
- Be careful when handling components, some parts have sharp edges. It is recommended that you always wear work gloves during assembly.
- It is strictly NOT recommended to stand on the roof of the Storage Shed as the force can cause damage to the product and serious injuries to the user.
- Wash using water and mild detergent solution. Do not use a stiff brush or abrasive cleaners as these may stain or damage the Storage Shed.
- Weather and water resistant.
- Lockable with a padlock (Padlock not included in package).
- Integrated support for shelf, in case a shelf is added (Shelf not included in package).
- Do not keep heavy items against the walls, as this may cause distortion.
- Avoid storing flammable, hazardous, and hot items that may deteriorate the plastic.
- It is strictly not allowed for children to play inside the box as it may cause suffocation.
- In case of fire, do not attempt to extinguish any burning polypropylene with water.

## 2-YEAR LIMITED WARRANTY

Cosmoplast has built its reputation through its commitment to bringing quality, durability, and innovation to its products since 1970. We ensure that the product confirms to highest quality and reliability standards before it reaches the customer. However, in case any defect is noticed during assembly or usage, please contact us through email, social media, or by phone. Our warranty is valid for two years from the initial date of purchase, and a proof of purchase should be presented. Damages caused by: Use of force, incorrect assembly, use of heat, neglect, spilling any form of hazardous liquid, storing above capacity, and natural disasters are excluded from the warranty.

## PRODUCT LIABILITY CLAUSE

Cosmoplast shall not be responsible for any injury caused to the user during assembly, usage, and possession.

Parts	Pieces
Flat Cover Cap <b>(FCC)</b>	2
Flat Top Cover <b>(FTC)</b>	1
Front Door Left <b>(FDL)</b>	1
Front Door Right <b>(FDR)</b>	1
Side Cover Left <b>(SCL)</b>	1
Side Cover Right <b>(SCR)</b>	1
Back Cover <b>(BC)</b>	2
Base <b>(B)</b>	1
Front Door Hinge Left <b>(FDHL)</b>	1
Front Door Hinge Right (FDHR)	1
Bottom Slide <b>(BS)</b>	1
Bottom Hinge <b>(BH)</b>	1
Handle <b>(HD)</b>	1
Hinge and Hinge Bracket <b>(HHB)</b>	1

Parts		Pieces
Top Cover Lock <b>(TCL)</b>		1
Hook (HK)	E S	2
Bottom Hook (BHK)	Q	2
Damper Cylinder <b>(DC)</b>		2
Chain <b>(CH)</b>		2
Metal Rod (MR)		1
Self-tapping Screws (S) 24mm	Bullena	45
Please contact Cosmoplast if you h	nave any problem or discover an	y missing parts.
For further identification of the parts on the inner side of the parts.	s, please refer to the engravings	of the part names
Unpacking		

















