

## **User Manual**

## SHELVING RACK



Note: This assembly instruction manual is applicable for all sizes of our shelving rack



## A CARE AND SAFETY


- To avoid any sort of damage, read and implement every step in the instruction manual carefully.
- Avoid placing hot materials on the shelves.
- Do not exceed the weight load-bearing capacity of 40 Kg per shelf.
- Clamp the shelves from both sides into the wall as an extra safety measure.
- Do not sit, stand, or climb on the shelves under any circumstance.
- It is recommended to keep heavier loads in the bottom shelves.
- In case of fire, do not attempt to extinguish any burning polypropylene with water.

## 2-YEAR LIMITED WARRANTY

Cosmoplast has built its reputation through its commitment to bringing quality, durability, and innovation to its products since 1970. We ensure that the product confirms to highest quality and reliability standards before it reaches the customer. However, in case any defect is noticed during assembly or usage, please contact us through email, social media, or by phone. Our warranty is valid for two years from the initial date of purchase, and a proof of purchase should be presented. Damages caused by: Use of force, incorrect assembly, use of heat, neglect, spilling any form of liquid, storing above capacity, and natural disasters are excluded from the warranty. Lastly, Cosmoplast shall not be responsible for any form of damage by any cause to goods placed on the shelving rack.

Parts		SR - 3	SR - 4	SR - 5
Tray		3	4	5
Pipe	€0	8	12	16
Cap	8	4	4	4
Rack Foot		4	4	4
Accessories				
U Clamp		2	2	2
Screw	_	4	4	4
Bush		4	4	4
Wall Plugs	(hang	4	4	4
A Discourse to the Common local Street Common				

A Please contact Cosmoplast if you have any problem or discover any missing parts.





Manufactured by: Cosmoplast Industrial Co. LLC. Sharjah, United Arab Emirates

Contact Us: (C)+971-4-8800333 Cplast@cosmoplast.com

P.O Box: 50488, Dubai, United Arab Emirates